DE HAVILLAND AIRCRAFT OF CANADA LIMITED

TEMPORARY REVISION

PSM: 1-64-2 **AIRCRAFT: DHC-6** **SERIES: 400**

PUBLICATION: MAINTENANCE MANUAL **TEMP. REVISION NO.: TR26-1**

Insert in 26-00-00 before Page 1

FIRE PROTECTION

REASON FOR ISSUE:

To introduce S.O.O. 6533, Introduction of Halotron Portable Fire Extinguishers.

ACTION:

In Chapter 26, Section 26-00-00, ignore existing Page 1 and insert revised page as shown on Page 2 of this Temporary Revision.

-Continued overleaf-

RECORDING INSTRUCTIONS:

Record this TEMPORARY REVISION NO. and the relevant information in the appropriate columns of the TEMPORARY REVISION INDEX provided at the front of the manual.

Fire Protection – General Data

1. General

Fire detecting and extinguishing systems are installed to combat fire in both engine nacelle accessory compartments. Visual indication of a fire condition in an engine nacelle is provided by a warning light, which illuminates the appropriate fire extinguisher push button, annunciation also available on Primary Flight Displays (PFDs), Crew Alert System (CAS) message and via aural warning. The two warning light/push buttons, when operated, cause the associated fire extinguisher bottle in the engine nacelles to be discharged into its accessory compartment (refer to 26-10-00, Fire Detecting System – General Data and 26-20-00, Fire Extinguishing System – General Data).

A hand-operated HALON fire extinguisher is installed for use within the aircraft. On special order an additional hand operated HALON fire extinguisher may be installed and located in the cabin. (Refer to 26-25-00, Hand-operated Fire Extinguishers – General Data). Aircraft with S.O.O. 6533 incorporated have one Halotron handheld fire extinguisher affixed to the floor structure below and left of the co-pilot seat, and one Halotron fire extinguisher mounted just forward of the rear port side door in the cabin.

For the fire protection system wiring diagram refer to PSM 1-64-2W, 26-10-00 for details.

Fire Protection – General Data

1. General

Fire detecting and extinguishing systems are installed to combat fire in both engine nacelle accessory compartments. Visual indication of a fire condition in an engine nacelle is provided by a warning light, which illuminates the appropriate fire extinguisher push button, annunciation also available on Primary Flight Displays (PFDs), Crew Alert System (CAS) message and via aural warning. The two warning light/push buttons, when operated, cause the associated fire extinguisher bottle in the engine nacelles to be discharged into its accessory compartment (refer to 26-10-00, Fire Detecting System – General Data and 26-20-00, Fire Extinguishing System – General Data).

A hand-operated HALON fire extinguisher is installed for use within the aircraft. On special order an additional hand operated HALON fire extinguisher may be installed and located in the cabin. (Refer to 26-25-00, Hand-operated Fire Extinguishers – General Data).

For the fire protection system wiring diagram refer to PSM 1-64-2W, 26-10-00 for details.

This Page Intentionally Left Blank