Engine – General Data

For the following subjects, refer to PT6A–34 Engine Maintenance Manual for information applicable to these subjects.

1. Engine – General
2. Reduction Gear and Shaft Section
3. Air Inlet Section
4. Compressor Section
5. Combustion Section
6. Turbine Section
7. Accessory Section

This Page Intentionally Left Blank