Controlling – General Data

1. Controlling

   Refer to PT6A–34 Engine Maintenance Manual for information applicable to this subject.

This Page Intentionally Left Blank