Engine Model(s): PT6A

74-20-01

IGNITION CABLES (GLOW PLUGS) - DESCRIPTION AND OPERATION

1. Description and Operation

The two individual ignition cable assemblies carry the electrical energy output from the current regulator to the glow plugs. Each cable assembly consists of an insulated copper wire contained in a flexible metal braiding. The cables are assembled to appropriate connectors for connection to glow plugs at the 4 and 9 o'clock positions on gas generator case, and to receptacles on current regulator. Two mounting flanges, brazed onto the flexible braiding of each cable, provide attachment to the center and rear fireseal mount rings.

Printed on 10/NOV/26 P&WC Proprietary – subject to restrictions in Technical Data Agreement