Engine Model(s): PT6A

79-20-04

OIL-TO-FUEL HEATER CHECK VALVE - DESCRIPTION AND OPERATION

1. Description and Operation

Two check valves are provided for the oil-to-fuel heater. One valve (minimum pressurizing) is fitted in a ported well at the 2 o'clock position on the compressor inlet case, and is interconnected to the oil inlet side of the heater by a steel tube assembly. This valve, which closes at approximately 40 psig, prevents flow of oil to the heater when the engine is shut down in flight with the propeller windmilling.

The second, the oil return check valve (Ref. 73-10-01), is encased in a tubular housing, and is mated to the oil outlet port of the oil-to-fuel heater and bolted to an adapter elbow at the 12 o'clock position on the air inlet case.

Printed on 10/NOV/26 P&WC Proprietary – subject to restrictions in Technical Data Agreement