



DXL 6D INPUT

Assembly Guide



Assembly Guide




PARTS:


- base_0.stl
- base_1.stl
- Dynamixel MX-64

PARTS:

- base.stl
- base_plate.stl



Assembly Guide




PARTS:


- Dynamixel MX-64

PARTS:

- arm_l1_fixed.stl



Assembly Guide




PARTS:


- Dynamixel MX-28

PARTS:

- arm_l2_fixed.stl



Assembly Guide




PARTS:


- Dynamixel MX-28

PARTS:

- FR07-H101K



Assembly Guide




PARTS:


- Dynamixel MX-28

PARTS:

- FR07-S101K
- Dynamixel MX-28



Assembly Guide




PARTS:


- 2 * FR07-S101K

PARTS:

- FR07-H101K



Assembly Guide




PARTS:


- FR07-S101K

PARTS:

- Dynamixel MX-28



Assembly Guide




PARTS:


- gripper_motor_mount.stl

PARTS:

- Aluminium profile
10mmx10mm



Assembly Guide




PARTS:


- gripper_axis.stl

PARTS:

- 2* auxiliar_guide.st



Assembly Guide




PARTS:


- finger_1.stl

PARTS:

- finger_2.stl



Assembly Guide




PARTS:

- gripper_axis_2.stl

PARTS:

- gripper_axis_1.stl



Assembly Guide

