

Tutorial 1: Lập trình chớp tắt LED dùng

Khoa Cơ khí

Bộ môn Cơ điện tử

Tutorial 1: Lập trình chớp tắt LED dùng

ASM trên Proteus

HK242

ME3007-Vi điều khiển

1, Bài toán


PIC16887, sử dụng bộ dao động 4MHz. LED nối vào chân RB0 Lập trình chớp tắt led sau mỗi 1 giây.

2. Các bước thực hiện

Bước 1. Tạo Project mới.

Bước 2. Trong Project Wizard, Phần Firmware, Chọn Create Firmware Project.

Chọn chip PIC16F887. Trong phần complier, chọn ngôn ngữ MPASM (Proteus).



Bước 3. Sau khi hoàn tất project. Trong phần souce code, nhập đoạn code sau


LIST P = 16F887; Define the chip #INCLUDE <P16F887.INC> ; Include memory map CONFIG _CONFIG1, _FOSC_INTRC_NOCLKOUT & _WDTE_OFF & _PWRTE_OFF & _MCLRE_ON & _CP_OFF & _CPD_OFF & _BOREN_ON & _IESO_ON & _FCMEN_ON & _LVP_OFF _CONFIG _CONFIG2, _BOR4V_BOR40V & _WRT_OFF ORG 0x0000; Reset vector GOTO START ; Jump to the start of the program ORG 0x0004; Interrupt vector (not used in this example) RETFIE ; Return from interrupt

Trang 1/4 GV: Phùng Thanh Huy

```
START:
  BSF
         STATUS, RP0
                         ; Bank 1
  CLRF
          TRISB
                       ; Set PORTB as output
  BANKSEL PORTB
  BCF
         STATUS, RP0
                         ; Bank 0
MAIN LOOP:
  BSF
         PORTB, RB0
                         ; Turn on LED on RB0
  CALL
          DELAY
                        ; Call delay subroutine
  BCF
         PORTB, RB0
                         ; Turn off LED on RB0
                        ; Call delay subroutine
  CALL
          DELAY
  GOTO
          MAIN LOOP
                            ; Repeat the loop
DELAY:
  MOVLW 0x9
                      ; Load W with 9 --> Count from 0--9 (10)
                        ; Load register 0x20 with 9
  MOVWF 0x20
DELAY_LOOP_1:
  MOVLW 0xC5
                        ; Load W with 197 (count 0--> 198)
  MOVWF 0x21
                        ; Load register 0x20 with 197
DELAY LOOP 2:
  MOVLW 0xC3
                        ; Load W with 195 (count 0--> 196)
  MOVWF 0x22
                        ; Load register 0x20 with 195
DELAY_LOOP_3:
  DECFSZ 0x22, F
                       ; Decrement register 0x20, skip if zero
  GOTO DELAY_LOOP_3 ; Repeat until register 0x20 is zero
  DECFSZ 0x21, F
                       ; Decrement register 0x21, skip if zero
  GOTO DELAY LOOP 2
                               ; Repeat until register 0x20 is zero
  DECFSZ 0x20, F
                       ; Decrement register 0x21, skip if zero
          DELAY LOOP 1
  GOTO
                               ; Repeat until register 0x20 is zero
                        ; f = 4MHz --> Cycle = 1MHz --> T = 1usec
                        ; estimate delay time (10*(198+2)*(196+4)=1000 millisec.
  RETURN
                        ; Return from subroutine
  END
```

Bước 4. Trên thanh công cụ, chọn Build → Build Project hoặc Ctr+F7.

Bước 5. Quay lại schematic. Thiết lập lại như sau:




Chú ý:

LED dùng phải có ACTIVE


Oscilloscope dùng để kiểm tra thời gian.

Bước 6. Click vào chip PIC16F887. Thiết lập nguồn xung là 4MHz



Trang 3/4

Bước 7. Nhấn chạy mô phỏng dưới góc trái Proteus.



Trang 4/4