Outer Ring

Create the Outer Ring component of the Bearing assembly shown in the figure below. The different views and dimensions are illustrated in the same figure. All dimensions are in mm.

