

# **5320A-LOAD**


# **High Voltage Load Adapter**

# **Technical Data**



The 5320A-LOAD High Voltage Load Adapter is an accessory to the Fluke 5320A Multifunction Electrical Tester Calibrator. It loads a hipot tester to create the leakage current needed to perform hipot tester calibration with the Fluke 5320A Multifunction Electrical Tester Calibrator.

The 5320A-LOAD consists of a series of eight power-rated resistors configured to provide eight resistance taps from 10 k $\Omega$  to 5 M $\Omega$ . Used to provide a resistive load on the test signal generated by a hipot tester, the test voltage and the resulting current through the Load is tested and calibrated by the 5320A calibrator.



Normal hipot calibration connections





The design of the 5320A-LOAD allows it to be placed on top of or under the 5320A calibrator for convenient operation and a small footprint.

#### **General specifications**

Power supply voltage	AC adapter 100-240 V, output voltage 12 V @ 0.4 amps min.		
	<del>                                     </del>		
Warm-up time	Not applicable		
Specifications confidence level	99 %		
Weight	850 g (1.9 lb), including standard accessories, volume		
	approximately 600 cm <sup>3</sup>		
Temperature			
Operating Temperature	5 °C to 40 °C		
Recommended Calibration	23 °C		
Temperature (Tcal)			
Storage Temperature	-20 °C to +70 °C		
Altitude, Maximum			
Operating	3,050 m (10,000 ft)		
Storage	12,200 m (40,000 ft)		
Dimensions	430 mm x 462 mm x 95 mm (16.9 in x 18.2 in x 3.7 in)		
Weight (net)	3 kg (8 lb 4.5 oz)		
Power Consumption	5 W maximum		
Safety class	I according to EN 61010-1		

# **Electrical specifications**

Total resistance range	$10~\text{k}\Omega$ to $5~\text{M}\Omega$	
Number of specific resistance values	8	
Tolerance to Nominal Value	10 % (One year, Tcal $\pm$ 5 °C)	

#### **Maximum ratings**

		Maximum	Maximum Time at
Nominal Value	Maximum Voltage	Dissipation Power	Maximum Power
10 kΩ	1200 V	140 W	Limited to 3 minutes
35 kΩ	2000 V	110 W	Limited to 3 minutes
50 kΩ	2000 V	80 W	Limited to 3 minutes
100 kΩ	5500 V	300 W	Limited to 3 minutes
250 kΩ	5500 V	120 W	Limited to 3 minutes
500 kΩ	5500 V	60 W	No limit
1 MΩ	5500 V	30 W	No limit
5 ΜΩ	5500 V	5 W	No limit

### **Ordering information**

#### **Models**

5320A-LOAD High Voltage Load

Adapter. Includes adapter, power line adapter, grounding cable, and Instruction Sheet.

#### **Accessories**

8508A/CASE Rugged Transit Case

#### **Accredited Calibration**

2724154 Calibration,

**DKD Accredited** 

Fluke. Keeping your world up and running.®

Fluke Corporation

PO Box 9090, Everett, WA USA 98206

Fluke Europe B.V.

PO Box 1186, 5602 BD Eindhoven, The Netherlands

For more information call:

In the U.S.A. (800) 443-5853 or Fax (425) 446-5116 Fax (425) 446-5110 In Europe/M-East/Africa +31 (0) 40 2675 200 or Fax +31 (0) 40 2675 222 In Canada (800)-36-FLUKE or

Fax (905) 890-6866

From other countries +1 (425) 446-5500 or Fax +1 (425) 446-5116 Web access: http://www.fluke.com

©2008 Fluke Corporation. Specifications subject to change without notice. Printed in U.S.A. 4/2008 3315612 D-EN-N Rev A

Pub\_ID: 11424-eng Rev 01