

중간(TR)점검 항목(제6조 관련)

B737 TRANSIT CHECK LIST

점검항목 (대분류)	점검세부항목
ARRIVAL	1. Perform an A/C check for parking and ground safety condition.
WALK AROUND	FUSELAGE/WING/EMPENNAGE
	1. Perform an Inspection of all visible portion of the fuselage, wings, flight control surfaces and empennage for obvious damage, leakage, obstruction, ice, frost condition and security.
	2. Perform a visual inspection of ram air inlet/exhaust doors and cabin pressure outflow valve to ensure there are no obstructions.
	3. Perform a visual inspection for missing or damaged navigation and communication antennae.
	4. Perform a visual inspection of static ports, total air temperature probe, pitot static probes, and angle of attack vanes for obvious damage.
	5. Perform cargo doors security check.
	6. Perform an general visual Inspection of fuselage in areas of drain masts and drains for fluid leakage.
	7. Perform a visual check of tail skid for evidence of a tail strike.
	LANDING GEAR and WHEEL WELL
	1. Perform an inspection of nose and main landing gears (including wheel/tire/door/brake) and wheel well areas for obvious damage, leakage, tire wear, safety condition and security.
	ENGINE and NACELLE
	1. Perform an inspection of all visible areas of engine/nacelle for obvious damage, leakage, obstruction safety condition and security.
	COCKPIT and CABIN
	1. Perform a Flight & Maintenance log check and rectify all flight defects.
	2. Perform an open defer item check, which have maintenance action to be performed each flight or periodically.
	3. Perform a hydraulic fluid level check and add fluid as required.
	4. Perform a crew oxygen system check for correct pressure.
	5. Perform an operation test of CVR (Cockpit Voice Recorder) & FDR (Flight Data Recorder).
	6. Check cabinlog discrepancy and defer item.
DEPARTURE	1. Certify accomplishment of inspection and maintenance in Flight & Maintenance Log.
	2. Make sure that L/G safety lock pins are removed before flight.
	3. Perform an Engine intakes check for free from F.O. material.
	4. Make sure that all access doors, service panels, cargo compartment doors, water fill & drain caps, toilet drain plugs and all engine cowl latches are safely closed & locked.

* 총 점검항목 20개 (ARRIVAL 1개, WALK AROUND 15개, DEPARTURE 4개)

A320F TRANSIT CHECK LIST

점검항목 (대분류)	점검세부항목
WALK AROUND	FUSELAGE/WING/EMPENNAGE
	1. CHECK – All visible exterior areas of the fuselage, empennage and flight control surfaces from the ground level for obvious damage and leakage.
	2. CHECK – All visible exterior areas of tail section from the ground level for obvious damage and leakage.
	3. CHECK – All visible exterior areas of the wing flight control surfaces, wing lower surfaces and tip from the ground level for obvious damage and leakage.
	4. CHECK – Static ports, pitot probes, TAT/AOA sensors for missing and obvious damage
	5. CHECK – Communication & navigation antennas from the ground level for

	missing and obvious damage.
	LANDING GEAR
	1. CHECK – Landing gear and doors for obvious damage and hydraulic leakage.
	2. CHECK – Wheels and tires for wear and obvious damage
	ENGINE
	1. CHECK – Engine cowls, spinner, fan blades and exhaust area for obvious damage and leakage.
	NACELLE/PYLON
	1. CHECK – Nacelle/pylon and access panels for obvious damage and leakage.
	COCKPIT
	1. CHECK – Flight & Maintenance Log and maintenance messages for malfunctions.
	2. CHECK – Hydraulic fluid level on the ECAM HYD page and add as necessary
	3. CHECK- Engine oil quantity on the ECAM ENG page and add as necessary.
	4. Perform a check cabin log discrepancy and defer item.
DEPARTURE	1. Make sure if removed landing gear ground lock pins & sleeves are in the L/G Ground Lock Pin box in the cockpit before flight.
	2. CHECK – Flight & Maintenance Log and make sure all malfunctions have been cleared or deferred
	3. CHECK – All circuit breakers, switches and levers in the cockpit for normal position.
	4. CHECK – Engine cowls and doors for security (If departure check is done within two hours after arrival check, this check is not necessary.).
	5. Perform an Engine intakes check for free from F.O. material (If departure(DEP) check is done within two hours after arrival(ARR) check, this check is not necessary.)
	6. Perform an operation test of CVR (Cockpit Voice Recorder) by using test switch.
	7. Check No fault-message on the ECAM/CFDS related to DFDR
	8. CHECK – Service doors including fueling station doors are closed and latches are locked

* 총 점검항목 21개(WALK AROUND 13개, DEPARTURE 8개)