

ATFM 공통 용어(제25조 관련)

1. ATCC는 정확한 ATFM 업무를 수행하기 위해 인접국가 및 각 기관에 제한사항 발부 시 공통된 픽스명, 어법 및 용어를 사용하여야 하며 세부 용어는 다음을 따른다

가. **WHO** - 제한사항 송신 또는 수신 주체 식별

Examples:

- ① THIS IS DAEGU ATCC (여기는 대구ATCC)
- ② THIS IS DALIAN ACC (여기는 대련 ACC)
- ③ THIS IS FUKUOKA ATMC (여기는 후쿠오카 ATMC)

나. **WHAT** - 제한사항의 목적 식별

Examples:

- ① REQUEST 30 MILES IN TRAIL (항공기간 30마일 분리 요청)
- ② REQUEST 10 MINUTES IN TRAIL (항공기간 10분 분리 요청)
- ③ REQUEST GROUND STOP (지상정지 요청)
- ④ REQUEST FLIGHT LEVEL 330 AT OR BELOW (고도 33,000FT이하 요청)

다. **WHEN** - 제한사항 발령 시간 식별

Examples:

- ① WITH IMMEDIATE EFFECT UNTIL 1700 UTC (현재~1700 UTC 까지)
- ② FROM 2000 UTC TO 2130 UTC (2000 UTC ~ 2130 UTC까지)

라. **WHERE** - 제한사항 대상 지역(공항) 및 항공기 식별(예외 항공기 포함)

Examples:

- ① FOR ALL AIRCRAFT LANDING INCHOEN Airport (인천공항 착륙 모든 항공기)
- ② FOR ALL TRAFFIC LANDING INCHOEN Airport (인천공항 착륙 모든 항공기)
- ③ FOR ALL TRAFFIC FILED VIA G597 (G597항로를 이용하는 모든 항공기)
- ④ FOR ALL TRAFFIC LANDING (BETWEEN ZBAA-ZBAA, ZBTJ-ZBTJ, ZBAA-ZBTJ)
(베이징공항 간, 톈진공항 간, 송산공항 간 착륙하는 모든 항공기)
- ⑤ FOR ALL TRAFFIC ENTERING ZBPE(BEIJING FIR)
(베이징 FIR을 진입하는 모든 항공기 ; ZBAA and ZBTJ and ZBSJ포함)
- ⑥ FOR ALL TRAFFIC ENTERING ZBPE(BEIJING FIR) except ZBAA, ZBTJ, ZBSJ,
(베이징 FIR을 진입하는 모든 항공기 ; ZBAA and ZBTJ and ZBSJ 불포함)
- ⑦ FOR over-flights ZBPE(BEIJING FIR), bound for EUROPE/MONGOLIA
/RUSSIA/MIDDLE EAST/AFRICA.
(베이징 FIR을 통과하는 유럽/몽골/러시아/동남아/아프리카로 가는 항공기)

마. WHY - 제한사항 발행 사유 식별

Examples :

- ① DUE TO SEVERE THUNDERSTORMS(WEATHER) OVER (INCHEON Airport/G597)
(인천공항 / G597항로상에 위험 기상으로 인해)
- ② DUE TO A LONG-RANGE RADAR OUTAGE (장거리레이더 장애로 인해)
- ③ DUE TO EXCESS SECTOR DEMAND (섹터수용량 초과로 인해)
- ④ DUE TO AN AIRCRAFT INCIDENT (항공기 준사고로 인해)

바. 거리분리(Miles-In-Trail)/시간분리(Minutes-In-Trail)

발부 시	THIS IS (DAEGU ATCC). Request (00 minutes/miles in trail) for all aircraft landing (Name of airport/control area) via (Name of FIR FIX/airway). Effective Time from (0000) to (0000). Due to (reason).
취소 시	THIS IS (DAEGU ATCC). CANCEL (00 minutes/miles in trail) for all aircraft landing (Name of airport/control area) via (Name of FIR FIX/airway).
분리기준 변경 시	THIS IS (DAEGU ATCC). REDUCE (CHANGE/AMEND/REDUCE/INCREASE/DECREASE) Your (00 minutes/miles in trail) to (Name of airport/control area) via (Name of FIR FIX/airway) from (00 minutes/miles in trail) to (00 minutes/miles in trail). Effective Time from (0000) to (0000).
적용시간 변경 시	THIS IS (DAEGU ATCC). Effective time for Your (00 minutes/miles in trail) TO (Name of airport/control area) via (Name of FIR FIX/airway) is extended(changed from) until (0000) due to (reason).

사. 지상정지 제한사항(GROUND STOP RESTRICTION)

발부 시	THIS IS (DAEGU ATCC). Request GROUND STOP for all aircraft landing (Name of airport/control area) via (Name of FIR FIX/airway). Effective Time from (0000) to (0000).
취소 시	THIS IS (DAEGU ATCC). CANCEL GROUND STOP for all aircraft landing at (Name of airport/control area) via (Name of FIR FIX/airway).
적용시간 변경 시	THIS IS (DAEGU ATCC). GROUND STOP for all aircraft landing at (Name of airport/control area) via (Name of FIR FIX/airway) is extended(changed from) until (0000) due to (reason).

아. 고도 제한(ALTITUDE RESTRICTION)

발부 시	REQUEST altitude (00,000M/FL000) not available for all aircraft landing at (Name of airport/control area) via (Name of FIR FIX/airway). Effective Time from (0000) to (0000).
취소 시	THIS IS (DAEGU ATCC). CANCEL altitude (00,000M/FL000) not available for all aircraft landing at (Name of airport/control area) via (Name of FIR FIX/airway).
적용시간 변경 시	THIS IS (DAEGU ATCC). altitude (00,000M/FL000) not available for all aircraft landing at (Name of airport/control area) via (Name of FIR FIX /airway). Effective Time from (0000) to (0000).