

```
%% MAE434 - Aircraft Design - Optimization Script
```

```
%Humza Khan
```

```
% Team: Charlie
```

```
% Date: 3/11/2025
```

```
%-----
```

```
%% Project Script Starts Here
```

```
clear all; close all; clc;
```

```
%-----
```

```
%% Input Variables
```

```
alt_ft = 40000; %ft (cruise altitude)
```

```
alt_m = convlength(alt_ft, 'ft', 'm'); %Cruise altitude in meters
```

```
[alt_T, alt_a, P, alt_rho] = atmosisa(alt_m);
```

```
rho_imperial = alt_rho/515.4;
```

```
%velocity calculations
```

```
V_cruise = 515; %ft/s
```

```
alt_a_fts = alt_a*3.281; %ft/s
```

```
M_cruise = V_cruise/alt_a_fts; %mach number
```

```
fprintf('<strong>Initial Velocity Calculations :</strong>\n')
```

```
fprintf('Cruise Velocity: <strong>%5.2f</strong> ft/s\n', V_cruise)
```

```
fprintf('Speed of Sound at 40,000 ft: <strong>%5.2f</strong> ft/s\n', alt_a_fts)
```

```
fprintf('Cruise Mach Number: <strong>%5.2f</strong>\n', M_cruise)
```

```
fprintf('-----\n')
```

```
%Plane/Aerodynamics/Payload specs
```

```
w_pl = 185*18; %lbs (taken from the De Havilland Aircraft - Twin Otter)
```

```
w_crew = 185*2; %lbs (avg pssnger mass = 185, we plan to carry 18 passangers)
```

```
AR = 8; %Estimated Aspect Ratio
```

```
swet_sref = 4.34; % 6.2 and 5 %CAD Reference surface area ratio
```

```
K_ld = 15.5; %Civilian Jets ---> Same Page as table 3.6 Aircraft Design - Raymer
```

```
fprintf('<strong>Engine Aircraft/Aerodynamics/Payload Specifications :</strong>\n')
```

```
fprintf('Payload Weight: <strong>%5.2f</strong> lb\n', w_pl)
```

```
fprintf('Crew weight: <strong>%5.2f</strong> lb\n', w_crew)
```

```
fprintf('Aspect Ratio: <strong>%5.2f</strong>\n', AR)
```

```
fprintf('Reference Surface Area Ratio: <strong>%5.2f</strong>\n', swet_sref)
```

```
fprintf('-----\n')
```

```
%range and loitering
```

```
Range = 3000 * 6076; %we're planning to fly around 3000 Nautical Miles
```

```
L_time = 45*60; %45 min loiter time, converted to seconds
```

```
endurance = Range/V_cruise;
```

```
fprintf('<strong>Range & Loiter Parameters :</strong>\n')
```

```
fprintf('Range: <strong>%5.2f</strong> ft\n', Range)
```

```
fprintf('Loiter time: <strong>%5.2f</strong> seconds\n', L_time)
```

```
fprintf('Endurance: <strong>%5.2f</strong> seconds\n', endurance)
```

```
fprintf('-----\n')
```

```
%Engine Properties - High-bypass turbofan
```

```
C_cruise = 0.5/3600; %1/s %SFC ----> Table 3.3 Aircraft Design - Raymer
```

```
C_loiter = 0.4/3600; %1/s %SFC ----> Table 3.3 Aircraft Design - Raymer
```

```
fprintf('<strong>Engine Properties - High-bypass turbofan :</strong>\n')
```

```
fprintf('C_loiter: <strong>%e</strong>\n',C_loiter)
```

```
fprintf('C_cruise: <strong>%e</strong>\n',C_cruise)
```

```
fprintf('-----\n')
```

```
%Solving for characteristics
```

```
SAM_area = 894+894+59+66+165+373+373+461+297+297+313+489+100; %updated wetted area  
from CAD
```

```
s_wet_body = SAM_area;
```

```
s_ref_sam = 856.8075;
```

```
swet_sref_updated = s_wet_body/s_ref_sam;
```

```
L_D_max = K_ld*sqrt(AR/swet_sref_updated); %loiter l/d ratio
```

```
L_D_cruise = 0.866*L_D_max; %cruise l/d ratio for jet
```

```
fprintf('<strong> L/D Calculation :</strong>\n')
```

```
fprintf('L/D (MAX): <strong>%5.2f</strong>\n',L_D_max)
```

```
fprintf('L/D (CRUISE): <strong>%5.2f</strong>\n',L_D_cruise)
```

```
fprintf('-----\n')
```

```
%5-stage fuel characteristics
```

```
w_10 = 0.97; %Take off
```

```
w_21 = 0.985; %Climb
```

```
w_32 = exp(-(Range*C_cruise)/(V_cruise*L_D_cruise)); %cruise
```

```
w_43 = exp(-(L_time*C_loiter)/(L_D_max)); %Loiter
```

```
w_54 = 0.995; %landing (Raymer)
```

```
w_50 = w_10*w_21*w_32*w_43*w_54; %total weight decrease ratio
```

```
w_f0 = 1.06*(1-w_50); %fuel to weight ratio ----> 6% residual weight allowance
```

```
fprintf('<strong>5-Stage Fuel & Weight Fraction Calculation :</strong>\n')
```

```
fprintf('weight fraction during takeoff: <strong>%5.4f</strong>\n',w_10)
```

```
fprintf('weight fraction during climb: <strong>%5.4f</strong>\n',w_21)
```

```
fprintf('weight fraction during cruise: <strong>%5.4f</strong>\n',w_32)
```

```
fprintf('weight fraction during loiter: <strong>%5.4f</strong>\n',w_43)
```

```
fprintf('weight fraction during landing: <strong>%5.4f</strong>\n',w_54)
```

```
fprintf('weight fraction (total weight decrease ratio): <strong>%5.4f</strong>\n',  
w_50)
```

```
fprintf('weight fraction (fuel with 6-percent residual weight allowance): <strong>%  
5.4f</strong>\n',w_f0)
```

```
fprintf('-----\n')
```

```
%-----
```

```
%% determining takeoff weight (Sensitivity analysis)
```

```
a = 0.32; %table 6.1
```

```
b = 0.66; %table 6.1
```

```
C1 = -0.13;
```

```

C2 = 0.3;
C3 = 0.06;
C4 = -0.05;
C5 = 0.05;
K_vs = 1.0; %constant sweep
guess_to_weight = 12500; %lb %initial weight guess from the Twin Otter
w_drop = 0;
rhs = 1;
t_w_ratio = 1.18; %can be 1.18 depending on the iteration we use
w_os = 45; %wingloading
M_max = M_cruise; %recalling mach number
tolerance = abs((1 - (guess_to_weight/rhs))*100); %tolerance condition
iteration = 0;

%while loop is going to iterate a solution for the empty weight of the
%aircraft
while tolerance > 0.01
    guess_to_weight = guess_to_weight + 0.1; %increasing weight by 5lb
    w_e0 = (a + ((b*guess_to_weight^C1) * (AR^C2) * (t_w_ratio^C3) * (w_os^C4) * (M_max^C5))) * K_vs; %estimating empty weight ratio based on the initial guess
    rhs = w_pl + w_crew + w_drop + (guess_to_weight*w_f0) + w_e0*guess_to_weight; %
    updating the right hand of the equation
    tolerance = abs((1 - (guess_to_weight/rhs))*100); %tolerance condition updated
    iteration = iteration + 1;
end

%weight calculations (empty and fuel)
w_fuel = rhs*w_f0;
w_e = rhs - w_fuel;

fprintf('<strong>Weight Calculation Results below :</strong>\n')
fprintf('The Total Take-off Weight of the aircraft is estimated at: <strong>%5.2f</strong> lbs\n', rhs)
fprintf('The Fuel Weight of the aircraft is estimated at: <strong>%5.2f</strong> lbs\n', w_fuel)
fprintf('The Empty Weight of the aircraft is estimated at: <strong>%5.2f</strong> lbs\n', w_e)
fprintf('-----\n')
%-----

%% Wing Design and Parameters
WS = w_os; %lb/ft^2 %table 5.5 transport jet value (we had to reduce it to reduce the take off distance and also that 120 from the book was not reasonable as if was of a full-scale bomber)
taper_ratio = 0.8; %estimated from the CAD Design
s_ref = rhs/WS; %reference area
wing_span = sqrt(AR*s_ref); %wingspan
%root_chord = (2*s_ref)/(wing_span*(1-taper_ratio)); %optimal root chord
%tip_chord = taper_ratio*root_chord; % optimal tip chord

```

```

%mean_chord = ((2/3)*root_chord*(1+taper_ratio+taper_ratio^2))/(1+taper_ratio);
mean_chord = s_ref/wing_span;
wing_area = s_ref;
cl_cruise = (2*guess_to_weight)/(rho_imperial*V_cruise^2*wing_area);
s_wet = swet_sref_updated*s_ref; %wing wetted surface area
fprintf('<strong>Wing Area Calculation ASSUMING Rectangular Wings  Results below :) \n'
</strong>\n')
fprintf('Estimated Coefficient of Lift (cruise): <strong>%8.4f</strong>\n',cl_cruise)
fprintf('The reference area of the wings is estimated at: <strong>%8.4f</strong> \n'
ft^2\n',s_ref)
fprintf('Estimated Wetted Surface Area of the wing: <strong>%8.4f</strong> ft^2\n',
s_wet)
fprintf('Estimated Wetted Surface Area of the body: <strong>%8.4f</strong> ft^2\n',
s_wet_body)
fprintf('Estimated wing span of the aircraft is: <strong>%8.4f</strong> ft\n',
wing_span)
fprintf('Estimated mean aerodynamic chord of the wings is: <strong>%8.4f</strong> \n'
ft\n',mean_chord)
fprintf('Estimated Taper Ratio (Not Applied) of the wings is: <strong>%8.4f</strong>\n',taper_ratio)
fprintf('-----\n')
%-----

%% Take-off distance calculator
%%SG - initial take off roll, before rotation
alt_landing = 0;
[alt_T_land, alt_a_land, P_land, alt_rho_land] = atmosisa(alt_landing);
rho_imperial_landing = alt_rho_land/515.4;
TW = 1.187; %minimizing takeoff distance
CL_to = 1.5;
CL_max = 2.5; %jet flaps/slats/flaps/
CD0 = 0.03;
e = 0.8;
K = 1/(pi*e*AR); %K-factor from Raymer takeoff distance eqns

vstall = sqrt(2*WS/(rho_imperial_landing*CL_max)); %stall speed calculation

pseudo_speed = sqrt(2*WS/(rho_imperial_landing*CL_to));
Vto = 1.2*pseudo_speed; %take off speed calculation

%from raymer pg 673

mu = 0.05; %rolling resistance
KT = TW - mu;
KA = rho_imperial_landing/((2*WS))*(mu*(CL_to)-(CD0)-(K*CL_to));

SG = (1/(2*32.2*KA))*log((KT+KA*Vto^2)/(KT));

```

```
%-----
TakeOffDistance = (Vto^2)/(2*32.2*(23000/rhs - mu - 0.01)); %SG*1.3... 0.01 is the D/W
value
fprintf('<strong>Takeoff distance calculation :</strong>\n')
fprintf('Estimated stall speed: <strong>%8.4f</strong> ft/s\n',vstall)
fprintf('Estimated takeoff speed: <strong>%8.4f</strong> ft/s\n',Vto)
fprintf('Estimated takeoff distance: <strong>%8.4f</strong> ft\n',TakeOffDistance)
fprintf('-----\n')
%-----

%% -----
% Exam 2 starts here
%-----

%% Thrust to Weight Ratio
arbi_time = endurance/2; %arbitrary half time where the plane is guaranteed be in
cruise
t_w_cruise = 1/(L_D_cruise); %thrust to weight ratio during cruise
cruise_wt = w_10*guess_to_weight; %weight of aircraft during cruise
t_cruise = t_w_cruise*cruise_wt; %estimated thrust required during cruise
t_w_takeoff = t_w_cruise*w_10*(23000/t_cruise); %math checks out
t_takeoff = t_w_takeoff*rhs; %take off thrust
fprintf('<strong>Thrust-to-weight Ratio (Takeoff) Calculation :</strong>\n')
fprintf('Thrust to Weight Ratio (takeoff): <strong>%8.4f</strong>\n',t_w_takeoff)
fprintf('Thrust at cruise: <strong>%8.4f</strong> lbs\n',t_cruise)
fprintf('Weight during cruise: <strong>%8.4f</strong> lbs\n',cruise_wt)
fprintf('Thrust at Takeoff: <strong>%8.4f</strong> lbs\n',t_takeoff)
fprintf('-----\n')
fprintf('<strong>Script Ends Here For Now </strong>\n')
%-----

%% Wing Loading
%-----
%% Script Ends here as of now.
```