	T	
Brand	Shanghai ELIZA	General Factories in China
core structure bearing seat system	Based on USA Milnor's advanced	Unreasonable integrated
	separate shaft and seat system, sealing	shaft seat design. The front
	cover and direct drain design are	shaft seat is directly linked to
	creatively added(unique in the world).	the backplate of the washing
	The front shaft seat is some distance	cabinet. If the water seal
	away from the backplate of the washing	leaks, water will directly
	cabinet. Thus, water can drain out	corrode bearing and tear
	directly along drainage pipe when the	linen, resulting in heavy
	water seal wears out and leaks. As a	repair, and the replacement
	result, there will be no affection on	of water seal, oil seal and
	bearing, motor and inverter.	bearing.
	boaring, motor and mitorion.	Oil must be added
core structure bearing seat system		frequently. Bearing will burn
	World unique engine gearbox type	out due to forgetting adding
	design. Oil can be kept for long time	oil, then water seal and oil seal will be damaged. As a
	once it is added into the bearing seat. It	
	avoid the burning of bearing seat due to lack of oil.	result, heavy repair happen,
		and there will be huge cost.  Within 24 months. It takes
core structure replacement time for normal use of bearing	Imported bearing can work for 10 years without heavy repair with oil and can be replaced within 4 hours.	
		over 3 days to replace. After
		that, it must be replaced
		each year.
core structure water seal system	Water seal system is adjustable according to its wearing and can work	Water seal can't be used
		anymore once it is worn out.
	for a long time.	
core structure		It will corrode bearing.
broken water seal's	It has no affection on main motor, shaft and inverter.	
affectcion on motor shaft		
bearing		
core structure replacement time for	It can normally work for 10 years. Replacement can be finished within 4	1year and half. It takes 3
		days to finish replacement.
normal use of water seal	hours.	After that, it must be
mornial add of water dear	nours.	replaced each year.
core structure		
replacement time for	10years	Within 18 months. It takes
normal use of oil seal	ioyeais	over 3 days to finish
		replacement.
	The 5 belts can be replaced within 5 minutes.	Belts can't be directly
Replacement time for belt		replaced. It takes over 2 days
Replacement time for beit		to uninstall bearing seat and
		finish replacement.
Drain valve structure and service life	The drain valve's connecting rod is free from water anytime, and will not break.	
		It is in high temperature
		water with acid and base and
	So it can be used for a long time.	is easy to get corroded.
7		