
## **MODEL RC1016**

## **SPOTNAILS**®

DIVISION OF PEACE INDUSTRIES, LTD.
1100 Hicks Rd
Rolling Meadows, IL 60008
Phone: 847-259-1620



## **SPOTNAILS MODEL RC1016**

	Ref No.	Part No.	Description
	01	P-70043	Exhaust Deflector
	02	P-64392	O-Ring
	03	P-24358	Cap Screw
	04	P-60201	Cap
•	05	P-15199	Exhaust Seal
•	06	P-64332	O-Ring (2)
	07	P-22167	Poppet Valve Guide
•	80	P-64393	O-Ring
•	09	P-62085	Gasket
	10	P-18226	Poppet Spring
•	11	P-64385	Poppet O-Ring
	12	P-63049	Poppet
•	13	P-64233	Piston Stop O-Ring
•	14	P-64389	Cylinder Seal O-Ring
	15	P-32256	Retaining Ring
•	16	P-64512	Piston O-Ring
	17	AS-06092	Piston & Driver Assembly
	18	P-06221	Driver Blade
•	19	P-64387	Cylinder O-Ring
	20	P-05120	Cylinder
•	21	P-64242	O-Ring
	22	P-15242	Bumper
	23	P-01288	Body
	24	P-15198	Return Seal
•	25	P-64240	O-Ring
	26	P-10285	Stationary Front Plate
	27	P-08467	Wear Plate
	28	P-07357	Step Pin
	29	P-10286	Removable Front Plate
	30	P-04062	Quick Clear Latch
	31	P-18333	Latch Spring
	32	P-07262	Pin

	Ref No.	Part No.	Description
	33	P-53165	Safety Guide
	34	P-18328	Spring
	35	AS-53049	Safety Assembly
	36	P-22144	Trigger Valve Cap
•	37	P-64333	O-Ring
•	38	P-64334	O-Ring
•	39	P-64335	O-Ring
	40	P-22145	Pilot Valve
•	41	P-64336	O-Ring
	42	P-18227	Spring
•	43	P-64383	Plunger O-Rings (2)
	44	AS-22037	Plunger Assembly
•	45	P-64328	O-Ring
	46	P-18267	Spring
	47	AS-21019	Restrictive Trigger
	48	P-07327	Trigger Pin
	49	P-13109	Bracket
	50	P-32211	Flat Washer
	51	P-24301	Screw
	52	P-24433	Screw
	53	P-12406	Magazine Cover (A)
	54	P-07331	Negator Spring Pin
	55	P-18334	Negator Spring
	56	P-07333	Pin
	57	P-12407	Magazine Cover (B)
	58	P-12409	Magazine
	59	P-07332	Pin
	60	P-09185	Pusher
	61	P-12411	Cover Mounting Bar
	62	AS-21008	Trigger Assembly
	63	P-97454	Filter (Optional)

Parts Included In AS-97325

O-Ring & Seal Kit