## **Customer Service Centres**

### Karachi

- B-78, Block H, Near Hyderi Market, North Nazimabad, Karachi
- Ground Floor, Plot No.117 C, East Street, Phase 1 DHA, Karachi
- House No. 4/23, Hashim Raza Road, Model Colony, Near Amin Masjid, Karachi

#### Lahore

- B-78, Block H, Near Hyderi Market, North Nazimabad, Lahore
- Ground Floor, Plot No.117 C, East Street, Phase 1 DHA, Lahore
- House No. 4/23, Hashim Raza Road, Model Colony, Near Amin Masjid, Lahore

### Islamabad

- B-78, Block H, Near Hyderi Market, North Nazimabad, Islamabad
- Ground Floor, Plot No.117 C, East Street, Phase 1 DHA, Islamabad
- House No. 4/23, Hashim Raza Road, Model Colony, Near Amin Masjid, Islamabad

### Rawalpindi

- B-78, Block H, Near Hyderi Market, North Nazimabad, Rawalpindi
- Ground Floor, Plot No.117 C, East Street, Phase 1 DHA, Rawalpindi
- House No. 4/23, Hashim Raza Road, Model Colony, Near Amin Masjid, Rawalpindi

### Faisalabad

- B-78, Block H, Near Hyderi Market, North Nazimabad, Faisalabad
- Ground Floor, Plot No.117 C, East Street, Phase 1 DHA, Faisalabad
- House No. 4/23, Hashim Raza Road, Model Colony, Near Amin Masjid, Faisalabad

### Multan

- B-78, Block H, Near Hyderi Market, North Nazimabad, Multan
- Ground Floor, Plot No.117 C, East Street, Phase 1 DHA, Multan
- House No. 4/23, Hashim Raza Road, Model Colony, Near Amin Masjid, Multan

### Hyderabad

- B-78, Block H, Near Hyderi Market, North Nazimabad, Hyderabad
- Ground Floor, Plot No.117 C, East Street, Phase 1 DHA, Hyderabad
- House No. 4/23, Hashim Raza Road, Model Colony, Near Amin Masjid, Hyderabad

### Gujranwala

- B-78, Block H, Near Hyderi Market, North Nazimabad, Gujranwala
- Ground Floor, Plot No.117 C, East Street, Phase 1 DHA, Gujranwala
- House No. 4/23, Hashim Raza Road, Model Colony, Near Amin Masjid, Gujranwala

UAN: (021) 111-234-567 Web:www.lenwoodpakistan.com

LENWOOD


# LENWOOD

KWM-10002FAT-W

KWM-10002FAT-S

KWM- 12002FAT -S

## Instructions




### Air Fresheners

The Air Freshener Control is designed to help control odors that might develop in the trash. There are many solid air fresheners available on the market.



### TU 8100 Model Series

- Raise the door
- Put in solid air freshener
- Set dial to NORMAL
- Move to MAXimum or MINimum if needed




### TF 4600/TU 4100 Model Series

- Put "adjustable" air freshener in compartment
- · Adjust according to directions
- · Check air freshener occasionally, it should last 4 to 6 weeks

# How the compactor works (in NORMAL Cycle)







The compacting ram does not go to the drawer bottom. You will not see compacting of the first few loadings.

Compaction starts after the drawer is The trash in a full compactor bag will about ½ full. You may hear a noise be about ¼ the size of its original bulk.

The trash in a full compactor bag will be about ½ the size of its original bulk.

Bottles or cans not placed in center may become caught between the ram and the drawer. The Drawer Munitor Switch senses a "misload," and will cause the ram to return to the "up" position without compacting. Load bulky trash, bottles and cans in the **center** of the drawer.

## **CONTENTS**

SA	AFETY INSTRUCTIONS
•	Safety Instructions

•	Product Description	7
•	Installation Area	8
•	Unpacking the Compactor	8

## **OPERATIONS**

**INSTALLATION** 

•	Preparation Before Compacting	9
•	Compacting	10
•	Control Pane	11
•	Options	12

### **MAINTENANCES**

•	Cleaning and Care	13
•	Cleaning the Filter	14
•	Troubleshooting	15
•	Technical Information	16