
Lifting Mainsail Operation

Instructions

- 1. Unzip boom bag
- 2. Climb steps on mast to access and release the shock cord holding mainsail down and release the other shock cord connected to the lazy jacks
- 3. Release main halyard clutch brake
- 4. Wrap two turns around windlass
- 5. Remove chain from capstan before pushing down on the footswitch





Lifting Mainsail

- 1. Whilst the anchor winch can lift the mainsail all the way up to save time initially pull the sail up as far as possible by hand
- 2. Check the cam brakes on the boom to ensure they are free to allow the reefing lines to run smoothly as the sail is lifted
- 3. Ensure the boat is facing into the wind as you lift the mainsail. For night sailing always put a reef in the mainsail.

