

Trường Đại học Bách Khoa Hà Nội Khoa Điện tử Viễn thông

Thông tin di động

Mobile Communications

TS. Đỗ Trọng Tuấn Bộ môn Kỹ thuật thông tin

Hà Nội, 8-2010

1

2/17/2014

Nội dung

- · Tổng quan về thông tin di động số tế bào.
- Hệ thống TTDĐ 2G (GSM,GPRS)
- Hệ thống TTDĐ 3G (UMTS,HSDPA)
- Mang không dây WiFi WiMax
- Quy hoạch và định cỡ mạng 3G/UMTS

Tài liệu tham khảo

- Giáo trình thông tin di động, ĐHBK Hà Nội
- Lý thuyết về kênh vô tuyến Thầy Nguyễn Văn Đức
- Tính toán mạng thông tin di động số cellular Thầy Vũ Đức Thọ
- Principles of Mobile Communication, Gordon L. Stüber
- · Wireless Communications Principles and Practice, T Rappaport
- Understanding UMTS Radio Network Modelling, Planning and Automated Optimisation, Maciej J. Nawrocki, Mischa Dohler, A. Hamid Aghvami
- http://www.google.com

3


2/17/2014

CHƯƠNG 1 Tổng quan về thông tin di động số tế bào

(Cellular Mobile Communications)

Introduction

Cellular mobile communication systems, or just mobile systems are communication systems with many access points, or base stations. Each base station supports its nearby geographical area, called a *cell*. The user can move around with his mobile phone and communicate through the nearest base station




5

2/17/2014


5

Cellular Mobile Systems



Cellular Concept

- Geographic Service divided into smaller "cells"
- Neighboring cells do not use same set of frequencies to prevent interference
- Often approximate coverage area of a cell by a idealized hexagon
- Increase system capacity by frequency reuse.



7

2/17/2014

7

Cellular Networks

- · Propagation models represent cell as a circular area
- Approximate cell coverage with a hexagon allows easier analysis
- Frequency assignment of F MHz for the system
- The multiple access techniques translates F to T traffic channels
- Cluster of cells K = group of adjacent cells which use all of the systems frequency assignment



Pattern



Grid Design



Grid Layout



Cellular Concept

- Why not a large radio tower and large service area?
 - Number of simultaneous users would be very limited (to total number of traffic channels T)
 - Mobile handset would have greater power requirement
- Cellular concept small cells with frequency reuse
 - Advantages
 - lower power handsets
 - · Increases system capacity with frequency reuse
 - Drawbacks:
 - · Cost of cells
 - Handoffs between cells must be supported
 - Need to track user to route incoming call/message

9

2/17/2014

9


Cellular Concept (cont)

Let T = total number of duplex channels


K cells = size of cell cluster (typically 9,12, 21)


N = T/K = number of channels per cell

- For a specific geographic area, if clusters are replicated M times, then total number of channels
 - system capacity = M x T
 - Choice of K determines distance between cells using the same frequencies => termed "co-channel" cells
 - K depends on how much interference can be tolerated by mobile stations and path loss




2/17/2014






2/17/2014



Tế bào lớn - Large cell

Vị trí thiết kế các cell lớn:

- Sóng vô tuyến ít bị che khuất (vùng nông thông, ven biển . . .)
- Mật độ thuê bao thấp
- Yêu cầu công suất phát lớn.



Bán kính phủ sóng ~ n km ÷ n * 10 km (GSM: <= 35 Km)

15

2/17/2014

Tế bào nhỏ - Small cell

Vị trí thiết kế các cell nhỏ:

- Mật độ thuê bao cao
- Sóng vô tuyến bị che khuất.
- Yêu cầu công suất phát nhỏ.




Bán kính phủ sóng ~ n * 100 m (GSM: <= 1 Km)

16

CuuDuongThanCong.com

https://fb.com/tailieudientucntt




2/17/2014



Phương thức phủ sóng

Phát sóng định hướng -> sectorization (1200···)

- Anten có hướng tính sẽ tập trung năng lượng trong một không gian nhỏ hơn.
- Cải thiện chất lượng tín hiệu.
- Tăng dung lượng thuê bao.



1 Site = 3 cell 120°


19

2/17/2014

Số lượng cell bao phủ một vùng địa lý

Các yếu tố ảnh hưởng đến số lượng cell trong một vùng địa lý

- Mật độ thuê bao
- Yếu tố địa hình : các tòa nhà, cây cối, hồ nước, đồi núi . . .




Nhận xét

• Trên thực tế, hình dạng cell là không xác định, việc quy hoạch vùng phủ sóng (coverage area) cần quan tâm đến các yếu tố địa hình và mật độ thuê bao, từ đó sẽ xác định số lượng trạm gốc BTS, kích thước cell và phương thức phủ sóng thích hợp.

21

2/17/2014

Cellular Concepts: Cells




Large cells are used to serve low traffic areas.

Microcells are used for high traffic demand regions.

Umbrella cells are used in areas where users are moving fast from one cell to another (eg. freeways)

Cellular Concepts: Cells




Umbrella cell: by using different antenna heights (often on the same building or tower) and different power levels, it is possible to provide "large" and "small" cells which are co-located at a single location.


23

2/17/2014


Exercise

Considering radio coverage in a PLMN, could you identify the topology of the different areas?





2/17/2014



Đơn vị công suất

 $P \rightarrow W \iff dB; mW \iff dBm$

 $P (dBm) = 10 log_{10} [P (mW)]$

P(mW)	P(dBm)
10	10
1	0
10 ⁻¹	-10
10 ⁻²	-20

$$P(dBm) = P(dB) + 30$$

27

2/17/2014

Chuyển đổi giá trị chỉ thị cường độ tín hiệu theo tỷ lệ phần trăm sang dBm

Hai bước ánh xạ RSSI [x %] sang dBm

- 1. Xác định RSSI_Max của nhà sản xuất Vendor.
- -> RSSI[x %] = x (%) * RSSI_Max / 100
- 2. Tra giá trị dBm tương ứng với giá trị RSSI vừa xác định trong bảng chuyển đổi hoặc công thức chuyển đổi do nhà sản xuất cung cấp.
- [*] Lưu ý: bảng chuyển đổi không phải khi nào cũng biến đổi theo quy luật tuyến tính.


Chuyển đổi giá trị chỉ thị cường độ tín hiệu theo tỷ lệ phần trăm sang dBm

Ví dụ:

- Atheros: RSSI_Max =60; -> dBm = RSSI 95;
- Phạm vi biến đổi của dBm : -35dBm đến -95 dBm
- Cường độ tín hiệu thu nhận tại 802.11 NIC là x = 30 % tương ứng với công suất thu là bao nhiêu dBm ?

29

2/17/2014



Chuyển đổi giá trị chỉ thị cường độ tín hiệu theo tỷ lệ phần trăm sang dBm

Ví dụ:

- Cisco: RSSI_Max =100;
- Phạm vi biến đổi của dBm: -10 dBm đến -113dBm
- Cường độ tín hiệu thu nhận tại 802.11 NIC là x = 30 % tương ứng với công suất thu là bao nhiêu dBm ?

31

2/17/2014

Độ nhạy thu - Receive Sensitivity

Khái niệm:

- Độ nhạy thu là mức công suất tối thiểu mà tại đó máy thu
 vẫn nhận được tín hiệu với mức độ chất lượng xác định
- Đơn vị: [dBm]

Ví dụ:

Card mạng WLAN theo chuẩn 802.11 có độ nhạy thu là -96 dBm ~ ? mW


-96 (dBm) ~ 0.000000002511 (mW)


Sử dụng lại tần số Cellular Frequency Reuse



Cell







Mục đích: tăng dung lượng hệ thống (increase capacity)

33

2/17/2014

Sử dụng lại tần số

- Hệ thống Cellular bao gồm S kênh vô tuyến RFC
 - (RFC: Radio Frequency Channel)
- Mỗi cell được cấp phát k RFC (k < S)
- S kênh được chia sẻ cho N cells.

S = kN

Sử dụng lại tần số

- N cells hình thành một cluster (N cluster size)
- Một cluster được lặp lại M lần trong một hệ thống cellular tại các vị trí địa lý khác nhau
- Khi đó dung lượng hệ thống C = tống số kênh RFC trong hệ thống (capacity)

$$C = MkN = MS$$


35

2/17/2014

Sử dụng lại tần số

- Thông thường cluster có kích thước N = 4, 7, 12
- Với : $N = i^2 + ij + j^2$
- Cell sử dụng cùng kênh tần số
 - Co-channel đồng kênh
 - Cần có sự thỏa hiệp giữa :
 dung lượng và nhiễu

[Trade-off : capacity vs interference]



Ví dụ 1.1

If a total of 33 MHz of bandwidth is allocated to a particular FDD cellular telephone system which uses two 25 kHz simplex channels to provide full duplex voice and control channels, compute the number of channels available per cell if a system uses

(a) 4-cell reuse, (b) 7-cell reuse (c) 12-cell reuse.

37

2/17/2014

Mẫu sử dụng lại tần số

Ký hiệu tổng quát : mẫu N/M

Trong đó:

N = tổng số site / cluster

M = tổng số cell / cluster

- Hệ số sử dụng lại tần số: 1/M
- => Mỗi cell được cấp phát 1/M tổng số kênh tần số vô tuyến trong 1 cluster.

Các nguồn nhiễu Sources of Interference

- Intra cell: Nhiễu từ các MS khác trong cùng cell.
- Inter cell: Nhiễu tức các MS đang tiến hành gọi từ các cell lân cận (neighboring cell)
- Nhiễu từ các trạm gốc sử dụng cùng băng tần.
- Nhiễu từ các hệ thống khác Noncellular systems

39

2/17/2014

Interference and System Capacity


- Interference is a limiting factor in the performance of cellular systems
- Co-Channel interference (CCI) is caused by signals at the same frequency
- Adjacent channel interference (ACI) is caused by signals from neighbouring frequencies
- In traffic channels, interference causes crosstalk from undesired users
- In control channels, interference causes errors which result in wrong instructions
- To reduce co-channel interference, co-channel cells must be separated sufficiently

Nhiễu đồng kênh Co-Channel Interference

- Co-Channels:
 - · Các cells sử dụng cùng kênh tần số
- Nhiễu đồng kênh : Co-Channel Interference:
 - Gây nên do việc sử dụng lại tần số (cell reuse)
 - -> Interference between "Co-cells"
- Phương thức giảm nhiễu đồng kênh:
 - Tăng khoảng cách sử dụng lại tần số.
 - Tăng tỷ số SNR.

41

2/17/2014



Hệ số tái sử dụng tần số Co-Channel Reuse Ratio

$$Q = \frac{D}{R} = \sqrt{3N}$$

	Cluster Size (N)	Co-channel Reuse Ratio(Q)
i = 1, j = 1	3	3
i = 1, j = 2	7	4.58
i = 2, j = 2	12	6
i = 1, j = 3	13	6.24

- D = Khoảng cách giữa tâm hai cell đồng kênh gần nhất.
- R= Bán kính cell
- N= Kích thước cluster
 - Q nhỏ: Dung lượng tăng (N giảm)
 - Q lớn: Chất lượng truyền dẫn vô tuyến tốt hơn.

43

2/17/2014

Tỷ số tín hiệu trên nhiễu Signal-to-Interference Ratio

• In general Signal-to-Interference ratio can be written as;

$$S_r = P_{desired} / \Sigma_i P_{interference,i}$$

- P_{desired} is the signal from the desired BS and P_{interference,i} is the signal from the ith undesired BS
- The signal strength falls as some power of α called power-distance gradient or path loss component
- If P_t is the transmitted power, d is the distance then, received power will be

$$P_r = P_t L d^{-\alpha}$$

Where, d is in meters
L is the constant depending on frequency

Tỷ số tín hiệu trên nhiễu Signal-to-Interference Ratio

$$\frac{S}{I} = \frac{S}{\sum_{i=1}^{i_0} I_i}$$

- S: Công suất tín hiệu mong muốn
- I_i: Công suất tín hiệu nhiễu từ kênh cùng tần số thứ i

45

2/17/2014

Công suất thu trung bình Average Received Power

$$P_r = P_0 \left(\frac{d}{d_0} \right)^{-n}$$

 $P_r(dBm)=P_0(dBm) - 10nlog(d/d_0)$


- P₀: Công suất thu tại khoảng cách tham chiếu d₀
- n: Hệ số tổn thất đường truyền, 2<n<4
- * Với các hệ thống cellular n ≈ 4

Lớp nhiễu đồng kênh thứ nhất First Layer of Co-Channels

$$\frac{S}{I} = \frac{(D/R)^n}{i_0} = \frac{(\sqrt{3N})^n}{i_0}$$
first tier
$$\frac{S}{I} = \frac{P_t R^{-n}}{i_0 P_t D^{-n}} = \frac{(D/R)^n}{i_0}$$

47

2/17/2014



Ví dụ 1.2


If a signal to interference ratio of 15 dB is required for satisfactory forward channel performance of a cellular system, what is the frequency reuse factor and cluster size that should be used for maximum capacity if the path loss exponent is

(a)
$$n = 4$$
, (b) $n = 3$?

Assume that there are 6 co-channels cells in the first tier, and all of them are at the same distance from the mobile. Use suitable approximations.

49

2/17/2014



Ví dụ 1.4

Measurements of a cellular network show that there is significant interference in a particular location in the network. It is identified that there are 6 main interfering base stations and that they are located at a distance of 8.15 km, 8.3km, 7.9 km, 7.7 km , 7.5 km and 8.9 km respectively from the location of the test mobile. The distance from the test mobile to wanted cell is 2.7 km. Estimate the Carier to Interfence Ratio at the mobile.

Use a path loss exponent of n = 3.5

51

2/17/2014

Improving Capacity in Cellular **Systems**

- Aim: To provide more channels per unit coverage area
- Techniques: Three techniques are used to improve capacity
- **SECTORING:**
 - Use directional antennas to further control the interference and frequency reuse of channels.
 - Examples: Omni, 120°, 60° and 90°



(a). Omni



(b). 120° sector



(c). 120° sector (alternate) (d). 90° sector





(e). 60° sector

Sectored Cells


• Some commonly used sectored cells:







• The output power of an antenna in a sectored cell:



53

2/17/2014

Sectoring

- Anten định hướng Directional
- Phân dải quạt : 60° hoặc 120°/sectors
- Giảm nhiễu interferers
- SIR tăng
- Cần bổ sung anten




120° sectoring


- Increase SIR
 - → Decrease cluster size
 - → Increase capacity

54

CuuDuongThanCong.com

Sectoring improves SIR





(a) 120° sectoring; (b) 60° sectoring.

55

2/17/2014

Sectoring improves SIR






Figure 3.11 Illustration of how 120° sectoring reduces interference from co-channel cells. Out of the 6 co-channel cells in the first tier, only two of them interfere with the center cell. If omnidirectional antennas were used at each base station, all six co-channel cells would interfere with the center cell.



2/17/2014


Sectoring

- The sectoring is done by replacing a single omni-directional antenna with 3 directional antennas (120° sectoring) or with 6 directional antennas (60° sectoring)
- In this scheme, each cell is divided into 3 or 6 sectors. Each sector uses a directional antenna at the BS and is assigned a set of channels.
- The number of channels in each sector is the number of channels in a cell divided by the number of sectors. The amount of co-channel interferer is also reduced by the number of sectors.
- · Drawbacks:
- Increase the number of antennas at each BS
- The number of handoffs increases when the mobile moves from one sector to another.




2/17/2014





An omnidirectional cell cluster is sectored using hexagonal sectors as shown in the figure 1.

- a. Skecth the cell plan for a 7-cell reuse cluster identifying the strongest interference base stations to the mobile located as in Fig .1
- b. Identify on the cell plan for (a) the approximately distances from those strongest interfering base stations to the mobile
- c. Calculate the carrier to interference ratio using the information in (a) and (b) . Take the path loss exponet to be n = 4.




2/17/2014

Chia cell Cell Splitting


- Chia cell hiện tại thành nhiều cell có diện tích nhỏ hơn
- Giảm chiều cao anten và công suất phát
- Tăng số kênh sử dụng lại tần số
 (Increase channel reuse)



- More base stations
- · Co-channel interference constant



2/17/2014



Cell Splitting

- Cell splitting is the process of splitting a mobile cell into several smaller cells. This is usually done to make more voice channels available to accommodate traffic growth in the area covered by the original cell
- If the radius of a cell is reduced from R to R/2, the area of the cell is reduced from Area to Area/4. The number of available channels is also increased.
- Cell splitting is usually done on demand; when in a certain cell there
 is too much traffic which causes too much blocking of calls. The cell
 is split into smaller microcells.

65

65

2/17/2014

Paradigm From 1G to Beyond 3G

First Generation

- Analogue
- Circuit switched
- Basic voice telephony
- Low capacity
- Limited local and regional coverage

Second Generation

- Di
 - Circuit switched
- Voice plus basic data applications
 Low data speed
- Enhancements towards
 - packet switching
- Trans-national and global roaming


Third Generation

- Digital
- Packet and circuit switched
- Advanced data (multimedia) applications
- Fast data access
- Global coverage
- Global roaming


Beyond Third Generation

- Digital
- Packet switched
- All IP based (IPv6)
- More advanced multimedia
- applications
- User in control
 Flexible platform of complementary access systems
- High speed data
- Improved QoS
- Global coverage
- Global roaming

2/47/2044




2/17/2014



2G — TDMA

Time Division Multiple Access




69

2/17/2014

2G & 3G — CDMA

Code Division Multiple Access

- · Spread spectrum modulation
 - Originally developed for the military
 - Resists jamming and many kinds of interference
 - Coded modulation hidden from those w/o the code
- All users share same (large) block of spectrum
 - One for one frequency reuse
 - Soft handoffs possible
- Almost all accepted 3G radio standards are based on CDMA
 - CDMA2000, W-CDMA and TD-SCDMA



2/17/2014

