Electronics Workshop Setup the Raspberry Pi

Bill Dornbush AA6BD



Today's Workshop



- Set up a Raspberry Pi from scratch
- Using Raspberry Pi Model 4 B
 - Pi 5 requires Bookworm
- Using Raspberry Pi OS Buster
 - Bookworm not yet stable
- Using 32 bit version
 - Not all apps work on 64 bit version

12/17/2023 CARC AA6BD 2

Why a Pi?



- Two is one and one is none
 - Backup to desktop
- Portable / low power solution (Pi and tablet/phone)
 - Winlink, APRS, FT8
- · Dedicated to a function
 - APRS station
 - APRS Digipeater
 - Winlink Gateway
 - WSPR
 - Hotspot / Allstar

12/17/202

CARC AA6BD

Bill of Materials - 1



- Computer: Windows, Mac, Linux
 - · Make SD card from image file
 - RealVNC client to Pi RealVNC Server
 - For RealVNC client, also tablet or smartphone
- Raspberry Pi 4 B
 - I am using 4GB version
- Power supply, 5v, 3A, USB-C
 - Mine came with an on-off switch

12/17/2023

Bill of Materials - 2



- MicroHDMI to HDMI cable (Pi 4 or 5)
 - For connecting monitor to Pi
- MicroSD card
 - I recommend selecting one card and sticking with it
 - Sandisk Ultra 32GB usually the least expensive option
- Optional
 - Case
 - Fan
 - Heatsinks

12/17/2023

CARC AA6BD

Bill of Materials - 3



- https://rpilocator.com
- Links to web site of supplier with in-stock
- I just found one with a Pi 5 4GB in stock
- Option 1: monitor, keyboard, mouse
- Option 2: computer with RealVNC client
- USB to MicroSD card reader
- More SD cards for backup

12/17/2023 CARC AA6BD

Bill of Materials - 4



- Optional GPS
 - VK-162 USB GPS receiver
 - GlobalSat BU-353S4 USB receiver
- TNC (Terminal Node Controller)
 - May be a "real TNC"
 - May be a sound card/ audio interface
 - More later on this

12/17/2023


CARC AA6BD


Network for today



- CARC-Demo
- Also CARC-demo-5G
- Password: fuzzysox

12/17/2023









OS Customization



- SERVICES
 - Enable SSH
 - Use Password Authentication
- OPTIONS
 - Eject Media when finished

12/17/2023

CARC AA6BD

Walk around the Pi Broadcom CPU GPIO Header LPDR4 POE Header Gigabit SDRAM Controller Controller Controller Controller Controller Gigabit Ethernet DSI Display USB 3.0 Ports Connector State Main Secondary Micro HDMI 12/17/2023 CARC AABED 14

Linux Notes



- All commands are case-sensitive
 - Ssh != ssh
- Command prompt: pi@AA6BD:~ \$
 - Username
 - Hostname
 - Directory
 - ~ means at the user directory (/home/pi/)
- Commands in this document shown with a \$
- Do not type the \$

12/17/2023

CARC AA6BD

1 – Monitor, keyboard, mouse



- Plug microHDMI cable into HDMI 0 port, nearest power port (Pi 4 or 5)
- Plug in keyboard and mouse
- Insert microSD card
- Option: Plug in GPS before powering on
- Insert power cord and turn on power
- Observe IP address

12/17/2023

1 - Pi Configuration



• Start:

- Start > Preferences > Raspberry Pi Configuration
- Interfaces
- Enable VNC

12/17/2023

CARC AA6BD

2 – Use VNC



- RealVNC is built into Pi
- Create RealVNC account at https://www.realvnc.com/en/
- Download viewer to your computer
- Insert microSD card
- Option: Plug in GPS before powering on
- Insert power cord and turn on power

12/17/2023 CARC AAGBD

2 – Connect VNC



- On your computer, open Command window
 - · Windows: cmd
 - \$ ssh pi@<hostname>.local (or .lan)
 - pi@AA6BD.lan
 - OR
 - \$ ssh pi@<ip address>
 - Enter password it does not echo

12/17/2023


CARC AA6BD

2 – Configure VNC



- \$ sudo raspi-config
 - "sudo" Execute as root user
- Interface Options
 - VNC <YES>
- Display Options > VNC Resolution
 - 1920x1080
 - Or other resolution
- Tab to <Finish>
- Reboot <Yes>

12/17/2023



Update Software



- PI OS does not update automatically
- Either



- Or
 - \$ sudo apt-get update && sudo apt-get full-upgrade
 - Two commands on one line
- Build-a-Pi/73Linux runs update whenever you install any new software
- BACKUP BEFORE installing software and/or updating

12/17/2023 CARC AAGBD 22

Shut down Pi



- If you turn off power without shutting down OS, you can damage SD card
- Start > Shutdown > shutdown
- Wait for green light flashing on and off ~8 times
- Remove power

12/17/2023 CARC AAGBD

Pushbutton Switch



- Configure /boot/config.txt to support switch
- Push once to shutdown OS
- Push again to start OS



023

24

Backup SD card



- Insert second SD card into USB reader
- Insert into USB port
- Start > Accessories > SD Card Copier
- Press Start

12/17/2023

CARC AA6BD

Patch USB bug



- CHECK IF NEEDED:
- Insert USB device like GPS
- •\$ ls /dev/serial/by-id
- If you see something like usb-Prolific_Technology_Inc_USB_Serial_Controller..
 No patch is needed
- If "Is: cannot access '/dev/serial/by-id': No such file or directory" see next slide
- CAUTION: OS Updates may change this

12/17/2023 CARC AA6

Patch details



- \$ cd /lib/udev/rules.d/
 - Ending / indicates directory
- •\$ sudo cp 60-serial.rules 60-serial.backup
- •\$ sudo mousepad 60-serial.rules
- Replace contents of file with https://github.com/systemd/systemd/blob/main/rules.d/60-serial.rules
- Ctrl-S and Ctrl-Q
- Reboot

12/17/2023

CARC AA6BD

Check patch



- Insert USB device like GPS
- \$ ls /dev/serial/by-id

12/17/2023

Ham Radio Applications



- Build-a-Pi >> 73Linux
- Will support Pi and x86_64 Linux systems
- Browse to https://github.com/km4ack/73Linux
- Under Install
- Click
- •\$ gi lone https://github.com/km4ack/73Linux.git \$HOME/73Linux && bash \$HOME/73Linux/73.sh
- Enter Terminal window and paste (right-click paste)
- Follow prompts

12/17/2023

CARC AA6BD

First apps



- CONKY
- GPS
- GPSUPDATE
- HAMCLOCK
- First, PI OS will update itself
- Then, apps will be installed
- Reboot when requested

12/17/2023 CARC AA6BD

Check GPS



- \$ cgps
- Or
- •\$ xgps
- \$ gpsupdate
 - If needed
 - Or apply patch

12/17/2023


CARC AA6BD

Hamclock



- Start > Hamradio > Hamclock
- Configure

12/17/2023



Q

Hamclock web interface



- Hamclock includes a web interface so you can see it on other computers on your LAN.
- Browse to http://<pi address>:8081/live.html
- For example, http://192.168.234.89:8081/live.html

12/17/2023

CARC AA6BD

Conky



• See patch in document for selecting display size


12/17/2023 CARC AA6BD

Winlink



- Hardware: TNC or sound card
 - DRA-30
 - Signalink
 - Mobilinkd
 - Digirig
 - more

12/17/2023 CARC AA6BD



Install Pat (Winlink)



- Start > Hamradio > 73Linux > 73Linux
 - PAT
 - PATMENU
- For VHF:
 - DIREWOLF
 - AX25
- For HF
 - ARDOP
 - ARDOPGUI

12/17/2023

CARC AA6BD

Continue installation



- Six character grid square
- Winlink Password
 - Blank if you don't yet have an account
- Install/Update selected
- Reboot

12/17/2023 CARC AA6BD

Configure Direwolf for your system



- Confirm your soundcard
 - \$ arecord -l (Lima, not one)
 - Card 3: Device [USB PnP Sound Device]. Device 0: USB Audio [USB Audio]
- Edit direwolf.conf
 - \$ mousepad direwolf.conf
 - Depends on your soundcard for how it gets PTT
 - Example: DRA-30 Uncomment: (remove the leading #) PTT CM108
 - Example: Signalink: no editing needed
 - Ctrl-s Ctrl-q

12/17/2023

CARC AA6BD

Send email using Winlink



- Start > Hamradio > Pat Meu
- Click Start/Stop Modem
- Click Start Packet Modem
- Modem will start and browser will open window
- Allow show notifications
- Action > Compose
 - Create email
 - Optional: Forms (Template)
 - POST

12/17/2023

Send - 2



- Action > Connect
 - Transport AX25
 - Target AK4ZX-12
 - Radio 145.050 (rig control not yet enabled)
 - Connect
- Also: Telnet (using just the Internet)
- If you don't yet have a Winlink account, see notes

12/17/2023 CARC AA6BD

Send - Pi to IC-7100



- Re-install Direwolf with hamlib support
- Edit direwolf.conf: #Uncomment line below for PTT with CAT through FLRIG PTT RIG 2 localhost:4532
- Flrig: config > setup > transceiver
 - Select IC-7100
 - Select/dev/serial/by-id/usb-Silicon_Labs_CP2102_USB_to_UART_Bridge_Controller_IC-7100_02007036_A-if00-port0
- Hamlib: \$ rigctld -m 3070 -r /dev/ttyUSB0
- Then Action > Connect as before

2/17/2023 CARC AA6BD 42

Change Pat port



- · Conflict with Hamclock!
- Start > Hamradio > Pat Menu
- Click Settings/Config
- Click Current Config Settings
- Change Pat Port from 8080 to 5000.
- Click Update.
- Click Main Menu.

12/17/2023 CARC AA6BD

Change - 2



- Open a Terminal window.
- \$ pat configure
- Editor is Nano
- In the line "http addr": "127.0.0.1:8080" Change "8080" to "5000"
- Type Ctrl-o, Hit enter, and Ctrl-x
- Reboot

12/17/2023 CARC AAGBD

Winlink Catalog



- Pat Menu > Pat Catalog
- Weather
- Radar
- Position
- Propagation
- News
- SMS

12/17/2023

CARC AA6BD

My Pi Apps



- Pat Winlink
- WSPR
- YAAC APRS
- PiGate RMS / LinBPQ
- MMDVM hotspot
- (Allstar)
- (Packet BPQ)

12/17/2023 CARC AA6BD

APRS Control and more



- Use APRS to send a message from one radio to another and use that message to control another radio, such as turn it on and off.
- Check this out: https://www.youtube.com/watch?v=F8EmZNcbKT0
- Radio to TXT
- Digipeater
- Pi Display

12/17/2023

CARC AA6BD

Other apps



- APRS: YAAC, Xastir, PIAPRS
- Hotspot
- Hamlib, flrig
- Fldigi, flarq, flwrap, flmsg: NBEMS
- WSJT-X, FT8
- JS8CALL
- QSSTV
- LinBPQ
- Utilities

12/17/2023

Support

Amateus Rodio Ci

- https://groups.io/g/KM4ACK-Pi
 - Forum postings
- https://github.com/km4ack/73Linux/issues
 - To post any issues or research known ones
- Documentation at https://github.com/km4ack/pi-build
- https://www.youtube.com/@KM4ACK/videos
 - Explains many BAP features and a lot more
- Raspberry Pi official documentation
 - https://www.raspberrypi.com/documentation/

12/17/2023

CARC AA6BD

What's Next



- Raspberry Pi further projects
- Arduino projects
- Something else?
 - ESP32 CW Keyboard/decoder

12/17/2023 CARC AA6BD

Comments / Questions



12/17/2023