
HowToUseHotkeyOnMT8382(4key)

1. Default hotkey config:


P.S If you device not barcode device, T key will not function




- 2. Custom define hotkey config
 - 2.1. Open APP (MT8382HotkeyDefine)



2.2. Open Custom Hotkey item




2.3. Setting 1 key




Click APP


P.S My example is select "Brower APP"



Setting Key 1 success can see this photo




2.4. Setting 2 key




Click APP


P.S My example is select "Calculator"



Setting Key 2 success can see this photo




2.5. Setting 3 key




Click APP


P.S My example is select "Filemanager"



Setting Key 3 success can see this photo




2.6. Setting 4 key




Click APP


P.S My example is select "gpstest"



Setting Key 4 success can see this photo




2.7. Save your config Click Save button




After reboot device

P.S If setting end, need reboot devices




2.8. Verify

P.S Press 1 key, 2 key, 3 key or 4 key verify function
P.S My example result , press 1 key should start Brower APP



P.S My example result , press 3 key should start File Manager APP




3. Clear Custom define

3.1. Open APP (MT8382HotkeyDefine)




After you can see old config


P.S My old config example is "Brower" and "File Manager"



3.2. Click "Set Default Config" button



After need reboot device



3.3. Verify


P.S 1 Key ~ 4 key should not function

4. Use default Hotkey


4.1. Open APP (MT8382HotkeyDefine)



4.2. Off Custom Hotkey item




After need reboot



4.3. Verify

P.S Hotkey setting should is default config(can use keyevent APP verify)
P.S If you device not barcode device, T key will not function



5. End