m) Do not subject flexible lighting to continuous flexing. Do not Exceed The Length in Feet Permitted By The Marking.

n) Do disconnect power before adding segments.

o) Only use extension segments provided with the entire set of product.

p) Connect a Maximum of 150 feet together.

q) To preclude the entry of water, Do Make sure that all connections and the end cap in the last segment are tightly secured.

This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock.

This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless plug can be fully inserted. Do not alter or replace the plug.

s) SAVE THESE INSTRUCTIONS

WARNING: When using outdoor use portable lighting products, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and personal injury, including the following:

Replace the fuse.

- a) Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
- b) Open fuse cover. Slide open fuse access cover on top of attachment plug towards blades.

c) Remove fuse carefully.

- d) Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse (provided with product).
- e) Close fuse cover. Slide closed the fuse access cover on top of attachment plug.
- f) Risk of fire. Do not replace attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if the attachment plug is damaged.

Read all instructions

- a) Ground Fault Circuit Interrupter (GFCI) protection should be provided on the circuits or outlet to be used for the outdoor
 use flexible lighting product. Receptacles are available having built-in GFCI protection for this measure of safety.
- b) Use only outdoor extension cords, such as type SW, SOW, STW, STOW, SJW, SJOW, SJTW, or SJTOW. This
 designation is marked on the wire of extension cord.

WARNING - Risk of fire and electric shock. Uncoil flexible light prior to plugging into receptacle.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical products, basic precautions should always be followed including the following:


a) Electrical ratings 0.3 A;

b) DIRECTION FOR MOUNTING THE ROPE LIGHT

1. POWER CONNECTOR

Assembling the power female connector, rubber ring and male connector with locknut.







3. END WATERPROOF SEAL

Assembling female connector, rubber ring end cap with locknut.









c) Fuse replacement rating 5 A.

2. SPLICING CONNECTOR

Assembling female connector, rubber ring and male connector with locknut.








★ EXTENDING ★ EXTENSION SEGMENTS: SS-2W10-E PRODUCTED BY SHENSHING

4. ROPE LIGHTS FIXATION CLAMP INSTALLATION

Mounting Rope Light with mounting U-clips or S-clasp





d) READ AND FOLLOW ALL SAFETY INSTRUCTIONS.

e) Do not cover this product as the covering may cause the flexible light to overheat and melt or ignite.

f) Do not operate with the flexible light tightly coiled.

g) Do not puncture, cut, shorten, or splice the flexible lighting.

h) Do not route the cord or flexible lighting through walls, doors, windows or any like part of the building structure.

i) Do not use if there is any damage to the light or cord insulation. Inspect periodically.

) Do not submerge flexible light in liquids, or use the product in the vicinity of standing water or other liquids.

k) Secure this flexible light using only the hangers or clips provided. Do not secure this product or its cord with staples, nails, or like means that may damage the insulation.

Do not subject flexible lighting to continuous flexing.