Introduction

Background

什么是 computer architecture

Computer architecture, like other architecture, is the art of determining the needs of the user of a structure and then designing to meet those needs as effectively as possible within economic and technological constraints

需要大量的工作,长久的经验累积,富有创造性......

- 一个架构师的角色可以分为四个方面
 - look backward (to the past): 理解和分析过去的设计
 - look forward (to the future):设计新的架构,推动技术发展
 - look up (towards the problems to solve): 理解问题, 解决问题
 - look down (towards device technology): 理解现有技术的能力, 预测将来技术的发展, 超前设计

Introduction to Computer Architecture

Layered design

计算机架构的分层:软件-ISA-硬件

分层是为了分治,减少复杂度

体系结构中两个重要的层

- ISA (Instruction Set Architecture) 是软件和硬件的接口,编译器使用 ISA 告知 微处理器需要的操作, 微处理器使用 ISA 了解需要实现的内容
- Microarchitecture (uarch) 是实现 ISA 的硬件结构

作为架构师,需要有跨越层次的眼光,需要理解软件之下的硬件是如何工作以及影响软件的运行

Performance

衡量系统性能的两个重要指标

• 执行时间

• 吞吐量

除此之外还有衡量能耗,成本,可靠性等的指标

没有完美的设计,设计就是要做 tradeoff

提高一个指标的同时一般会降低其他的指标(Pareto Optimum)

边际效应

一个 tradeoff 的例子: 考虑有 N 个不同的指标 x_i , 需要最大化

 $\prod x_i$

等价于最大化

$$\sum \log x_i$$

且有限制

$$\sum c_i x_i = B$$

则最终的解为

$$c_i x_i = rac{B}{N}$$

Quantitative Approach

Back of the envelope calculations

基本思想:简单但不简略的计算,留有余量

e.g. CPI (Clock Per Instruction),通过用程序的时钟周期数除以程序的执行指令数得到

模拟也可以用于量化分析,但快速的模拟过于粗糙,而 RTL 模拟的时间消耗是不可接受的

有三个指标可以评估模拟器

- 速度
- 灵活性
- 准确性

高层次的模拟就是牺牲一部分准确性换来速度和灵活性的提升

Trends

过去的十年内 Moore's law 和 Dennard scaling 都达到了瓶颈,单核性能的提升极为有限

现在主要的系统: 移动系统, 大型的机房

现在主要的瓶颈: memory wall, power wall, ILP wall