

Contents

Confidentia	ality	4
Introductio	n	5
1. Scan to	unregistered destination	6
1.1	Unregistered Destination to File	6
1.2	Unregistered Destination to Email	8
2. How to change the Scan Settings		
3.	How to change Scan Options Page 1 of 2	11
4.	How to change Scan Options Page 2 of 2	15
5.	File Formats	17

Confidentiality

The information contained within this Training Document is confidential, and is supplied solely to training delegates for your internal purposes. You agree that you will only disclose this information to such of your employees as is necessary. You further agree not to disclose this information or any part of it to any other party without our express written consent.

This shall not apply to information, which is published or becomes known legitimately from another source, other than Canon (UK) Limited or any of its subsidiaries.

Copyright © Canon (UK) Limited 2017

Introduction

This guide has been designed to provide users of your new Canon imageRUNNER Advance device(s) with all of the information needed to gain the most out of your investment. The following sections will take you through, in detail, the steps you need to take to scan and send a hard copy document from your imageRUNNER Advance Multi-Functional Device.


For further support please contact the Software Support Centre

1. Scan to unregistered destination

The section below will show you how to scan to unregistered destinations for scanning to file and email.

1.1 Unregistered Destination to File


After selecting the Scan & Send button, press New Destination.




Press File



2. Press the Protocol drop-down list and select Windows SMB and then select Browse




3. Select the desired Workgroup




- 4. Select the desired file server and press down.
- 5. If the Enter Network Password Screen is displayed enter your user name and network password (one that never expires).
- 6. Press Down and select the folder on the specified server to which you want to send your documents and press ok.
- 7. Confirm your settings and press ok.

1.2 Unregistered Destination to Email

2. After setting the Scan & Send button press New Destination.



3. Press Email




- 4. Enter the Email address and press ok
- 5. Place documents in the Feeder or onto the Platen Glass, and once you have selected your settings, press the green start button.




2. How to change the Scan Settings

Using the settings panel on the right hand side of the destination screen you can configure scan settings for a particular scan job in the following way;



• Auto (Colour/Gray) - Press this button to change your colour settings.




The document can be scanned using the following options;

- Black & White produces a Black and White document aimed at enhancing text quality with the minimum file output size.
- Grayscale produces a Black and White document using Grayscale shading for better image quality, particularly useful for Black and White images.
- Full Color scans every page of the document as a colour page, even if the page is Black and White, this will result in a larger file size but provides the best shading quality for pictures or posters.
- Auto Color / Gray will determine which pages have colour and which are Black and White and scan them in the appropriate
 manner. This will result in the best scan quality at the minimum file size for mixed documents.


Select the setting you require so it becomes highlighted and press OK.

300x300 dpi – Resolution can be changed to a minimum of 100x100 dpi or a maximum of 600x600dpi* (Dots per inch)

(* increases file size so be aware if you have a maximum file size limit using e-mail)




• Auto size - Auto will automatically detect the paper size e.g. A4, A3. Select any other size to manually restrict the scan area size.




- PDF (Compact) This is the default file format. It will be sent as a .PDF but compacted to reduce the file size. See below for other File Formats
- <u>2 Sided Original</u> Select this option to scan 2 sided. See details in **Scan Options Page 1 of 2**.
- <u>File Name</u> * This can be entered once a destination has been specified. Name the scanned document with a limit of 24 characters. See details in Scan Options Page 2 of 2.

- 3. How to change Scan Options Page 1 of 2
- 1. Select the Options button in the bottom right corner of the screen.




2. The below screen will be displayed.



Please see detailed information on scanning options.

below for more







 You can scan the original by erasing the background colour.

This mode enables you to scan by erasing the background colour of the original. This feature is especially useful for scanning originals, such as catalogues and paper that have turned yellow from age.

Adjust

Press $[\]$ to move the indicator to the left to make the exposure lighter, or press $[\]$ to move it to the right to make the exposure darker.

Auto

If you want to automatically adjust the density for originals that may bleed or originals with background colour.

Adjust each Colour If you want to adjust RGB colours independently, press \rightarrow adjust colours independently for background density using [-] or [+].





 This mode enables you to scan original images with a sharper or softer contrast.

Low

If you scan original containing halftones, such as a printed image, using the Photo mode, the moiré effect (a shimmering, wavy pattern) may occur. In this case, you can lessen this moiré effect by this setting to produce a clearer image.


High

This setting enhances the edges of original images so that faint or fine text is scanned with a sharper contrast. This setting is particularly suited for scanning blueprints and faint pencil drawn images.








The machine offers you a variety of preset zoom ratios to reduce or enlarge standard size originals to another standard record size



4. How to change Scan Options Page 2 of 2








5. File Formats

The default settings will be set to PDF (Compact). However, you can change to any other option by touching the PDF (Compact) button.



- PDF Sends the file in the PDF format regardless of the color mode.
- XPS Sends the file in the XPS format regardless of the color mode.
- OOXML Open Office XML enables user to lift text, images and logo's from a scanned Document, then reuse them.
- JPEG Sends the file in the JPEG format, if you select a color mode other than B & W
- TIFF Sends the file in the TIFF format, only if you select the Black-and-White mode.
- **Divide Into Pages** Select this option to separate multiple pages and send them as separate files.
- **Reader Extensions** Enables the recipient of the document to annotate PDF's without a fully licensed version of Adobe.
- OCR Fully Searchable text.
- Trace and Smooth Creates vector files which can be imported into Illustrator and be edited.
- Compact Compresses the file without affecting the image and makes the file size smaller for transferring.
- Encrypt Document encryption for security.

Add Digital Sig. Will allow you to send an electronic signature attached to the document either
 Device specific or user specific, this is to enable enhanced encryption for
 document security.