

KEY2->GPIOA28 用户按键

KEY6->GPIOB9 用户按键

PWM0->LCD Backlight

PWM2->BEEP 蜂鸣器

PWM:

LED:

D7->GPIOE13


D8->GPIOC17


D9->GPIOC8


D10->GPIOC7


D11->GPIOC12


KEY3->MCU_KEY_VOLUP/GPIOB30 用户按键 KEY4->MCU_KEY_VOLDN/GPIOB31 用户按键 KEY5->MCU_PWRKEY/ 电源待机按键































www.gec-edu.org						
Title G:	EC6818_BASE_V1.1					
Size A3	Document Number <doc></doc>					Rev <rev< th=""></rev<>
Date:	Wednesday, July 19, 2017	Sheet	_	- of	12	-














LED