Comfort Zone 9-inch Box Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 123957

Original source file(s): 123957&CZ12396.pdf

Source SHA-256: 79c5dc3b49e7cf71cbc4f319de007a9a2b7c63f5c4038bb4464492c96b172003

Original PDF pages: 5 | Recovered reading units: 5

Source page 1 - OCR transcription (OCR)

Wig

NC

9" Box Fan

Features:

* Rotary Knob with 3 Speed Settings

® Quiet Vibration-Free Performance

soon encom

Source page 2 - OCR transcription (OCR)

Comfort Zone.

INTENDED USE: “sana om READ & SAVE THESE

This product is intended for indoor residential and office use only,

not for industrial or other commercial applications. Use only with I NSTR U CTI ONS

electrical wiring that is in good working order and that meets

applicable codes and ordinances. If you have any questions WARNING: SHOCK HAZARD

whether your wiring is adequate, consult a qualified electrician. Use your fan only in dry environments. This fan is not intended

for use in a bathroom, laundry area, or similar locations, or near

While using your fan, you should follow the IMPORTANT sinks, washing machines, swimming pools or other sources of

INSTRUCTIONS listed below. As part of those instructions, we water. Never locate fan where it may fall into a bathtub or other

have used the word "WARNING" to indicate the level of hazard: water receptacle. Do not use in damp environments such as

WARNING indicates a hazard which, if not avoided, could result flooded basements.

in injury or death.

WARNING: HOT SURFACES

IMPORTANT INSTRUCTIONS Do not touch fan motor when in use. This motor is hot when in

use, to avoid burns, do not let bare skin touch hot surfaces.

As with all electrical appliances, basic safety precautions should

always be followed to reduce the risk of electric shock, fire, or WARNING: FIRE HAZARD

injury to persons, including the following precautions: Fans have arcing or sparking parts inside. Do not use near

combustible materials or flammable gases or sources of heat.

* Read all the instructions before using this fan. DO NOT USE in areas where gasoline, paint or flammable

Use this fan only as described in this manual. Any other use not materials are used or stored. To prevent a possible fire, do not

recommended by the manufacturer may cause electrical shock, block air intakes or exhaust in any manner. Do not insert or allow

fire or injury to persons. foreign objects to enter any ventilation or exhaust opening as this

* Do not operate the fan with a damaged power cord or after the may cause an electric shock, fire, or damage the fan.

fan malfunctions or has been dropped in any manner.

* Use of extreme caution is necessary when any fan is used by or | WARNING: ELECTRICAL SHOCK HAZARD

near children, disabled persons or pets and whenever the fan is Do not use with damaged cord or plug. Use with adequate

left operating unattended. electrical system that is up to code.

* Do not place the fan on a small, unlevel, uneven or any surface

which might allow fan to tip or fall. CAUTION: To Prevent Electric Shock, this product has a

* For proper operation, fan should be placed on a smooth, polarized two prong plug (one blade is wider than the other) that

non-combustible, level surface. must be fully inserted in to a matching properly grounded outlet.

+ Always unplug fan when not in use, when moving from place This plug is designed to fit a polarized outlet only one way. If the

to place, when assembling or disassembling parts, and before plug does not fit fully into the outlet, teverse the plug. If the plug

cleaning. still does not fit, contact a qualified electrician. Do not attempt to

* The use of attachments, not recommended or sold by the defeat this safety feature

. manufacturer may cause hazards. WARNING: TO REDUCE THE RISK OF FIRE OR

7 ELECTRIC SHOCK, do not use this product with any

* Do not use fan in window. Rain may cause electrical hazard solid-state speed control device.

(for non-window models).

* Do not operate the fan with blade guards or any safety device DO NOT operate any fan with a damaged cord or plug or after

removed. fan malfunctions, has been dropped or damaged in any manner.

* Avoid the use of extension cords due to risk of fire. If an Do not operate fan with a broken blade, safety cage or any visual

extension cord must be used, the cord must be minimum imperfections. Disconnect power before servicing. For repairs

14 AWG and rated not less then 1875 watts. covered under warranty, see warranty statement. For all other

* Do not run power cord under carpeting. Do not cover cord with repairs contact Comfort Zone® Customer Service by telephone or

throw rugs, runners or the like. Arrange cord away from traffic mail for information and assistance.

area where it will not be tripped over.

* Do not insert or allow any object to enter any openings on the DO NOT run power cord under carpeting. DO NOT cover cord

fan. Doing so may cause electric shock and/or fire hazard. with throw rugs, runners or the like. Arrange cord away from

Avoid contact with moving parts. traffic area where it will not be tripped over. Avoid the use of

* This appliance is not intended for use by persons (including extension cords due to risk of fire. If an extension cord must

children) with reduced physical, sensory or mental capabilities be used, the cord must be minimum 14 AWG and rated not

or lack of experience and knowledge, unless they have less then 1875 watts. Do not use an extension cord unless the

been given supervision or instruction concerning use of the plug can be completely inserted into its receptacle. Unplug

appliance by a person responsible for their safety. the fan when not in use. Do not operate fan with its ventilation

* Children should be supervised to ensure they do not play with obstructed.

the appliance.

Source page 3 - OCR transcription (OCR)

‘6)) www.comfortzoneproducts.com »

USAGE: Note: Some models come with a plug where you can replace a

" fuse. If your model has this, please read and follow the below

instructions to replace the fuse.

Fan Operation: Always operate the fan in the upright position

following all instructions and recommendations listed in this This product employs overload protection (fuse). A blown fuse

manual. indicates an overload or short-circuit situation. If the fuse blows,

unplug the product from the outlet. Replace the fuse as per

Fan Location: Place the fan in the area of the room that will the user servicing instructions (follow product marking for

provide proper fan cooling. proper fuse rating) and check the product. If the replacement

fuse blows, a short-circuit may be present and the product

Fan Connection: Plug fan directly into 120 volt A.C., 60 Hz wall shoul be alscarded or returned to an authorized service facility

outlet. Be sure plug fits tightly in outlet. A loose connection may for examination and/or repair.

cause overheating and damage to the plug or fan. .

Note: To prevent overloading a circuit, do not plug the fan intoa | Fuse Replacement:

circuit that is servicing other electrical needs. 1. Grasp plug and remove from the receptacle or other outlet

device. Do not unplug by pulling on cord.

Turning Fan On: To start the fan, turn the knob located on the front of the fan, from the OFF position to the desired fan speed, low, medium, or high.

Turning Fan Off: To turn the fan off, turn the knob back to the OFF position. Remove plug from outlet when not in use.

Care and Maintenance

Cleaning: CAUTION-Before cleaning the fan be sure to disconnect power cord from the plug. Clean the grille surface with a clean damp cloth. Do not use harsh chemical or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN WATER. Allow fan to dry completely before use.

Periodic grille cleaning with a vacuum will prevent dust build up.

The motor is sealed and does not require any interior maintenance, cleaning or lubrication.

Maintenance: The Internal motor bearings are permanently lubricated at the factory and do not require any additional lubrication.

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY.

Storage: Keep original carton for storage of the fan. Coil and tie the power cord to avoid damage during storage.

2. Open fuse cover by sliding open fuse access cover on top of front of the fan, from the OFF position to the desired fan speed, attachment plug towards blades. See Fig. 2.

3. Remove fuse carefully. Use a small tool to pry the end of the fuse from holder cavity. Be careful not to break glass window.

4. Replace fuse. WARNING: Risk of fire. Replace fuse only with identical 5.0 Amp, 125 Volt fuse (3.6mm x 10mm). Be sure Oooo fuse is properly seated within its cavity.

5. Close fuse cover by sliding it back to its original closed position.

Fig 1 Fig 2 Fig 3

4 att Slide Cover to Open

Source page 4 - OCR transcription (OCR)

O Comfort Zone.

www.comfortzoneproducts.com

LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one

year from the date of original retail purchase. Some states do not allow limitations on how long an implied **warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising** from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Mr. Brands LLC

1414 Radcliffe St Suit 105

Bristol, PA 19007

1-877-420-7555

www.mrbrands.com

www.comfortzoneproducts.com

support@mrbrands.com

LM cosine

Cancer and Reproductive Harm --

www.P65Warnings.ca.gov

Rev. 08/22/2024

oo OOO

Source page 5 - OCR transcription (OCR)

() Comfort Zone.

America’s Heating and Cooling Choice

PROTECT YOUR PURCHASE

Scan to Register for Your

FREE Extended Warranty!

[=] a done <[m]

te eee 2"

-o rien iho

A "F = a r

; Teo er

forge hata

ol cit Of... r_!

SCAN HERE