EZ Chill 2-in-1 Desk & Clip-On Fan

Mr Brand - image-free searchable transcription

Pictures and diagrams were intentionally removed to reduce size. Readable labels, captions, specifications, warnings, and instructions were transcribed where recoverable. Keep the original manufacturer document for wiring, assembly geometry, part placement, and other visual-only details.

Product ID(s): 01280

Original source file(s): 01280.Instruction Manual.01.pdf

Source SHA-256: 5689931671d262026db8424a88e0943caf405e11ac87222d93a97eef3ddeadbd

Original PDF pages: 1 | Recovered reading units: 5

Source page 1 (embedded text)

Mr. Brands LLC

01280

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied **warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising** from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited **warranty is given in lieu of all other warranties.**

Source page 1 - Panel 1 (top left) (OCR)

Reading orientation normalized by 180 degrees.

yaqaquy

@® MOZ ZHO9 AOZL~OLL

age fs >,

O07 >

ESS </ggegs

ee (eae

Cag Yy SSF

CG, \ es

‘ KX /} ri eK

Qa

08210 "ON WALI

Nv4 NO dI19 8 MSaG EL NIZ

IVNNVW S.uaNMO

WL

Source page 1 - Panel 2 (top right) (OCR)

INTENDED USE: WARNING: HOT SURFACES

This product is intended for indoor residential and office Do not touch fan motor when in use. This motor is hot when in

use . only, not for industrial or other commercial use, to avoid burns, do not let bare skin touch hot surfaces.

applications. Use only with electrical wiring that is in

jood working order and that meets applicable codes

Snd ordinances, If you have any questions whether WARNING: FIRE HAZARD

your wiring is adequate, consult a qualified electrician Fans have arcing or sparking parts inside. Do not use near

combustible materials or flammable gases or sources of heat.

While using your fan, you should follow the DO NOT USE in areas where gasoline, paint or flammable

IMPORTANT INSTRUCTIONS listed below. As part of materials are used or stored. To prevent a possible fire, do

WARNING | eee Se ne oe dh not block air intakes or exhaust in any manner. Do not insert

WARNING indicates a hazard which, if not avoided or allow foreign objects to enter any ventilation or exhaust

could result in injury or death. , , opening as this may cause an electric shock, fire, or damage

the fan

IMPORTANT INSTRUCTIONS WARNING: ELECTRICAL SHOCK HAZARD

As with all electrical appliances, basic safety Do not use with damaged cord or plug. Use with adequate

precautions should always be followed to reduce the electrical system that is up to code

tisk of electric shock, fire, or injury to persons, including

the ielowing I dies ubat before using this fan, CAUTION-TO PREVENT ELECTRIC SHOCK, this appliance

* Use this fan only as described in this manual. Any has a two prong plug that must be inserted into a matching

other use not recommended by the manufacturer properly grounded outlet to reduce the risk of electrical

may cause electrical shock, fire or injury to shock. This fan has a polarized plug (one blade is wider then

persons. the other). To reduce the risk of electric shock, this plug is

* Do not operate the fan with a damaged power cord designed to fit a polarized outlet only one way. If the plug

or after the fan malfunctions or has been dropped does not fit fully into the outlet, reverse the plug. If the plug

. Uso of extrome caution is necessary when any fan still does not fit, contact a qualified electrician. Do not attempt

is used by or near children, disabled persons or to defeat this safety feature

pets and whenever the fan is left operating

unattended. This product employs overload protection (fuse). A blown

© Do not place the fan on a small, unlevel, uneven or fuse indicates an overload or short-circuit situation. If the fuse

any surface which might allow fan to tip or fall blows, unplug the product from the outlet. Replace the fuse

* For proper operation, fan should be placed on a as per the user servicing instructions (follow product marking

. Aloe unig fan ution net hue, for proper fuse rating) and check the product. If the

* Do not operate the fan with blade guards or any replacement fuse blows, a short-circuit may be present and

safety device removed. the product should be discarded or returned to a qualified
* DO NOT run cord under carpeting. Do not service facility for examination and/or repair.
cover cord with throw rugs, runners or the like.
Do not route cord under furniture or appliances. DO NOT operate any fan with a damaged cord or plug or
Arrange cord away from traffic area and where after fan malfunctions, has been dropped or damaged in any
it will not be tripped over. manner. Do not operate fan with a broken blade, safety cage
* Do not insert or allow any object to enter any or any visual imperfections.
openings on the fan. Doing so may cause electric
shock and/or fire hazard. Unplug the fan when not in use. Do not operate fan with
its ventilation obstructed.
Please Save These Instructions NOTE: There are no serviceable parts in this unit. Do
not attempt to disassemble.

WARNING: Never use this fan with any solid-state

WARNING: SHOCK HAZARD A A 7

Use your fan only in dry environments. This fan is not speed control device. Doing so may cause a fire and/
intended for use in a bathroom, laundry area, or similar or shook hazard.
locations, near sinks, washing machines, swimming
pools or other sources of water. Never locate fan where
it may fall into a bathtub or other water receptacle. Do
not use in damp environments such as flooded
basements.
Page 2

Source page 1 - Panel 3 (bottom left) (OCR)

USAGE:

FAN OPERATION: Always operate the fan in the upright position following all instructions and recommendations listed in this manual FAN LOCATION: Place the fan in the area of the room that will provide proper fan cooling. FAN CONNECTION: Plug fan directly into 120 volt A.C., 60 Hz wall outlet. Be sure plug fits tightly in outlet. A loose connection may cause overheating and damage to the plug or fan. NOTE: To prevent overloading a circuit, do not plug the fan into a circuit that is servicing other electrical needs.

TURNING FAN ON/OFF: Clip fan to a stable location. Plug fan into outlet. To start the fan,
slide power switch to desired speed button: LOW, HIGH.

FAN ASSEMBLY: Simple assembly is required to use this fan.

Bal]
Ss
J nN 4
é wy N i)
jo \ 1) shal
ee Step #2 Lal
Step #1 P
t t 4
q 4

: Insert Thumbscrew

and Tighten

Place Clip Base

On to Fan

- ba |

Desk Base

Page 3

Source page 1 - Panel 4 (bottom right) (OCR)

CARE AND MAINTENANCE FUSE REPLACEMENT:

CLEANING: CAUTION-Before cleaning the fan be 1. Grasp plug and remove from the receptacle or

sure to disconnect power cord from the plug. other outlet device. Do not unplug by pulling on cord.

Clean the grill surface with a clean damp cloth. Do 2. Open fuse cover. Slide open fuse access cover on

not use harsh chemical or abrasive cleaners. DO top of attachment plug towards blades. (see fig. 1)

NOT IMMERSE THE FAN OR ANY WIRES IN 3. Remove fuse carefully. Remove the fuse by prying

WATER. Return front grill before fan use. Allow fan it out carefully. (see fig.2)

to dry completely before use. Periodic grill 4. Risk of fire. Replace fuse only with identical 2.5 or

cleaning with a vacuum cleaner will prevent dust 5 Amp, 125 Volt fuse (3.6mm x 10mm).

build up. The motor is sealed and does not 5. Close fuse cover. Slide closed the fuse access

require any interior maintenance, cleaning or cover on top of attachment plug. (see fig.3).

lubrication. 6. Risk of fire. Do not replace attachment plu:

MAINTENANCE: The Internal motor bearings are . : rep plug

tly lubricated at the fact d di t Contains a safety device (fuse) that should not be

permanently lubricated’ at the factory and do no removed. Discard product if the attachment plug is

require any additional lubrication damaged

REPAIR: DO NOT OPERATE THE FAN WITHOUT .

THE GRILL IN PLACE. DO NOT USE THE FAN IF Fig. #1 Fig. #2 Fig. #3

IT HAS MALFUNCTIONED OR BECOME

DAMAGED IN ANY WAY.

igi a > | Ne =

STORAGE: Keep original carton for storage of the = a -| - =

fan. Coil and tie the power cord to avoid damage ‘lie Cover to Opon

during storage.

Warranty:

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, to Mr. Brands LLC for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than Mr. Brands LLC are not covered in this warranty. Mr. Brands LLC will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of

merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied **warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising** from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do Not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited **warranty is given in lieu of all other warranties.**

CUSTOMER ASSISTANCE:

FOR IMMEDIATE CUSTOMER SERVICE,CALL:1-877-420-7555.

A CUSTOMER SERVICE REPRESENTATIVE WILL ASSIST YOU WITH ANY QUESTIONS REGARDING YOUR FAN.

Made in China

Distributed by:

Mr. Brands LLC

L\ nen Page 4

Cancer and Reproductive Harm --

www.P65Warnings.ca.gov