



1. Double click on the object to which you want to assign variable



2. Click on Add Variable






3. Adding temporary variable


		Select Variable for Pin:0	>
Scope: Select Variable:	Global	V OK Cancel V Add Variable Help	
Variable Name: Variable Type: Data Type: Retention:	GVar0 VAR_TEMP BOOL NO	Address: %MX0 Initial Value:	
Description:			



4. Assigning Physical Input



5. Assigning Physical Output






5. After adding variable.



6. After simulation the ladder diagram appear as follows



7. If double click on DI_0 then below result will be appear

