CPE 323: The MSP430 Assembly Language Programming

Aleksandar Milenkovic

Electrical and Computer Engineering The University of Alabama in Huntsville

milenka@ece.uah.edu


http://www.ece.uah.edu/~milenka

Outline

- Introduction
- Assembly language directives
- SUMI/SUMD
 - Adding two 32-bit numbers (decimal, integers)
- CountEs: Counting characters 'E'
- Subroutines
 - CALL&RETURN
 - **Subroutine Nesting**
 - Passing parameters
 - Stack and Local Variables
- Performance



Assembly Programming Flow



Assembly Directives

- Assembly language directives tell the assembler to
 - Set the data and program at particular addresses in address pace
 - Allocate space for constants and variables
 - Define synonyms
 - Include additional files
- Typical directives
 - Equate: assign a value to a symbol
 - Origin: set the current location pointer
 - Define space: allocate space in memory
 - Define constant: allocate space for and initialize constants
 - Include: loads another source file



- CCStudio ASM430 has three predefined sections into which various parts of a program are assembled
 - .bss: Uninitialized data section
 - .data: Initialized data section
 - text: Executable code section

Description	ASM ₄₃ o (CCS)	A430 (IAR)
Reserve size bytes in the uninitialized sect.	.bss	-
Assemble into the initialized data section	.data	RSEG const
Assemble into a named initialized data sect.	.sect	RSEG
Assemble into the executable code	.text	RSEG code
Reserve space in a named (uninitialized) section	.usect	-
Align on byte boundary	.align 1	-
Align on word boundary	.align 2	EVEN



Examples

```
; IAR
        RSEG DAT16 N ; switch to DATA segment
        EVEN
                         ; make sure it starts at even address
MyWord: DS 2
                         ; allocate 2 bytes / 1 word
MyByte: DS 1
                         ; allocate 1 byte
; CCS Assembler (Example #1)
MyWord: .usect ".bss", 2, 2 ; allocate 1 word
MyByte: .usect ".bss", 1 ; allocate 1 byte
; CCS Assembler (Example #2)
        .bss MyWord, 2, 2; allocate 1 word
        .bss MyByte,1 ; allocate 1 byte
```



Constant Initialization Directives

Description	ASM430 (CCS)	A430 (IAR)
Initialize one or more successive bytes or text strings	.byte or .string	DB
Initialize 32-bit IEEE floating-point	.float	DF
Initialize a variable-length field	.field	-
Reserve size bytes in the current location	.space	DS
Initialize one or more 16-bit integers	.word	DW
Initialize one or more 32-bit integers	.long	DL

LO MADO

Directives: Dealing with Constants

```
b1:
            .byte
                              ; allocates a byte in memory and initialize it with 5
                    5
b2:
            .byte
                    -122
                              ; allocates a byte with constant -122
b3:
            .byte
                    10110111b; binary value of a constant
b4:
            .byte
                    0xA0
                              ; hexadecimal value of a constant
b5:
            .byte
                    123q
                              ; octal value of a constant
tf:
            .equ 25
```

Word view of Memory

Byte view of Memory

	Label	Address	Memory[15:8]	Memory[7:0]	Label	Address	Memory[7:0]
	b1	0x3100	0x86	0x05	b1	0x3100	0x05
	b3	0x3102	0xA0	0xB7	b2	0x3101	0x86
	b5	0x3104		0x53	b3	0x3102	0xB7
	b4 0x3103 0xA0						
b5						0x3104	0x53

Directives: Dealing with Constants

```
.word
                                ; allocates a word constant in memory;
w1:
                    21
w2:
            .word -21
w3:
            .word tf
dw1:
                                 ; allocates a long word size constant in memory;
            .long 100000
                                 ; 100000 (0x0001_86A0)
dw2:
            .long 0xFFFFFEA
```

Label	Address	Memory[15:8]	Memory[7:0]
w1	0x3106	0x00	0x15
w2	0x3108	0xFF	OxEB
w3	0x310A	0x00	0x19
dw1	0x310C	0x86	0xA0
	0x310E	0x00	0x01
dw2	0x3110	0xFF	OxEA
	0x3112	0xFF	OxFF



Directives: Dealing with Constants

```
.byte 'A', 'B', 'C', 'D'; allocates 4 bytes in memory with string ABCD
s1:
          .byte "ABCD", ' '; allocates 5 bytes in memory with string ABCD + NULL
s2:
```

Label	Address	Memory[15:8]	Memory[7:0]
s1	0x3114	0x42	0x41
	0x3116	0x44	0x43
s2	0x3118	0x42	0x41
	0x311A	0x44	0x43
	0x311C		0x00
	0x311E		

Table of Symbols

Created by the assembler (think about this as a table of synonyms)

Symbol	Value [hex]
b1	0x3100
b2	0x3101
b3	0x3102
b4	0x3103
b5	0x3104
tf	0x0019
w1	0x3106
w2	0x3108
w3	0x310A
dw1	0x310C
dw2	0x3110
s1	0x3114
s2	0x3118



Directives: Variables in RAM

```
; allocates a byte in memory, equivalent to DS 1
.bss v1b,1,1
.bss v2b,1,1
                 ; allocates a byte in memory
                 ; allocates a word of 2 bytes in memory
.bss v3w,2,2
                 ; allocates a buffer of 2 long words (8 bytes)
.bss v4b,8,2
.bss vx,1,1
```

Label	Address	Memory[15:8]	Memory[7:0]
v1b	0x1100		
v3w	0x1102		
v4b	0x1104		
	0x1106		
	0x1108		
	0x110A		
vx	0x110C		

Symbol	Value [hex]
v1b	0x1100
v2b	0x1101
v3w	0x1102
v4b	0x1104
VX	0x110C



Decimal/Integer Addition of 32-bit Numbers

Subroutines

- **Problem**
 - Write an assembly program that finds a sum of two 32-bit numbers
 - Input numbers are decimal numbers (8-digit in length)
 - Input numbers are signed integers in two's complement
- Data:
 - lint1: DC32 0x45678923
 - lint2: DC32 0x23456789
 - **Decimal sum:** 0x69135712
 - Integer sum: 0x68ac31ac
- Approach
 - Input numbers: storage, placement in memory
 - Results: storage (ABSOLUTE ASSEMBLER)
 - Main program: initialization, program loops
 - Decimal addition, integer addition



Decimal/Integer Addition of 32-bit Numbers

```
File
           : LongIntAddition.asm
Function
           : Sums up two long integers represented in binary and BCD
Description: Program demonstrates addition of two operands lint1 and lint2.
             Operands are first interpreted as 32-bit decimal numbers and
             and their sum is stored into lsumd;
             Next, the operands are interpreted as 32-bit signed integers
             in two's complement and their sum is stored into lsumi.
           : Input integers are lint1 and lint2 (constants in flash)
Input
           : Results are stored in lsumd (decimal sum) and lsumi (int sum)
Output
           : A. Milenkovic, milenkovic@computer.org
Author
Date
           : August 24, 2018
          .cdecls C,LIST,"msp430.h"
                                          ; Include device header file
          .def
                  RESET
                                           ; Export program entry-point to
                                          ; make it known to linker.
          .text
                                           ; Assemble into program memory.
                                            Override ELF conditional linking
          .retain
                                           ; and retain current section.
          .retainrefs
                                           ; And retain any sections that have
                                            references to current section.
```

ntro Assembly Directives SUMD/SUMI CountEs Subroutines Perform

THE UNIVERSITY OF ONLARS AND IN HUNTSVILLE

Decimal/Integer Addition of 32-bit Numbers (cont d) INTERITY OF THE UNIVERSITY OF TH

Assembly Directives SUMD/SUMI CountEs Subroutines

Decimal/Integer Addition of 32-bit Numbers (cont d)

```
; Main code here
            clr.w
                    R2
                                            ; clear status register
                    lint1, R8
                                            ; get lower 16 bits from lint1 to R8
            mov.w
                                            ; decimal addition, R8 + lower 16-bit of lint2
            dadd.w
                    lint2, R8
                    R8, 1sumd
                                            ; store the result (lower 16-bit)
            mov.w
                    lint1+2, R8
                                            ; get upper 16 bits of lint1 to R8
            mov.w
            dadd.w
                    lint2+2, R8
                                            ; decimal addition
            mov.w
                    R8, lsumd+2
                                            ; store the result (upper 16-bit)
                    lint1, R8
                                            ; get lower 16 bite from lint1 to R8
            mov.w
            add.w
                    lint2, R8
                                            ; integer addition
                    R8, lsumi
                                            ; store the result (lower 16 bits)
            mov.w
                    lint1+2, R8
                                            ; get upper 16 bits from lint1 to R8
            mov.w
                    lint2+2, R8
            addc.w
                                            ; add upper words, plus carry
            mov.w
                    R8, lsumi+2
                                            ; store upper 16 bits of the result
           jmp $
                                             ; jump to current location '$'
                                             ; (endless loop)
```

Intro Assembly Directives SUMD/SUMI CountEs Subroutines Performan

Decimal/Integer Addition of 32-bit Numbers (conted) IN HUNTSVILLE

```
; Decimal addition
                     #lint1, R4
                                             ; pointer to lint1
            mov.w
                     #1sumd, R8
                                              ; pointer to lsumd
            mov.w
                                              ; R5 is a counter (32-bit=2x16-bit)
                    #2, R5
            mov.w
            clr.w
                     R10
                                              ; clear R10
1da:
                    4(R4), R7
                                              ; load lint2
            mov.w
                     R10, R2
                                              ; load original SR
            mov.w
                                              ; decimal add lint1 (with carry)
            dadd.w
                     @R4+, R7
                                              ; backup R2 in R10
                     R2, R10
            mov.w
                     R7, 0(R8)
                                              ; store result (@R8+0)
            mov.w
            add.w
                    #2, R8
                                              ; update R8
            dec.w
                     R5
                                              ; decrement R5
            jnz
                     1da
                                              ; jump if not zero to lda
```

```
Integer addition
                    #lint1, R4
                                              ; pointer to lint1
            mov.w
                                                pointer to lsumi
                    #lsumi, R8
            mov.w
                                              ; R5 is a counter (32-bit=2x16-bit)
                    #2, R5
            mov.w
            clr.w
                    R10
                                              : clear R10
lia:
                    4(R4), R7
                                              ; load lint2
            mov.w
                    R10, R2
                                              ; load original SR
            mov.w
            addc.w
                                              ; decimal add lint1 (with carry)
                    @R4+, R7
                                              ; backup R2 in R10
                    R2, R10
            mov.w
                    R7, 0(R8)
                                              ; store result (@R8+0)
            mov.w
            add.w
                    #2, R8
                                              ; update R8
            dec.w
                    R5
                                              : decrement R5
            jnz
                    lia
                                              ; jump if not zero to lia
                                              ; jump to current location '$'
            jmp
                    $
                                              ; (endless loop)
```



Count Characters 'E'

Problem

- Write an assembly program that processes an input string to find the number of characters 'E' in the string
- The number of characters is "displayed" on the port 1 of the **MSP430**

Example:

- mystr="HELLO WORLD, I AM THE MSP430!", "
- P10UT=0x02

Approach


- Input string: storage, placement in memory
- Main program: initialization, main program loop
- Program loop: iterations, counter, loop exit
- Output: control of ports



Programmer's View of Parallel Ports ALABAMA IN

- Parallel ports: x=1,2,3,4,5, ...
- Each can be configured as:
 - Input: PxDIR=0x00 (default)
 - Output: PxDIR=0xFF
- Writing to an output port:
 - PxOUT=x02
- Reading from an input port:
 - My port=P1IN

Port Registers







Count Characters 'E'

```
File
            : Lab4 D1.asm (CPE 325 Lab4 Demo code)
 Function : Counts the number of characters E in a given string
 Description: Program traverses an input array of characters
              to detect a character 'E'; exits when a NULL is detected
            : The input string is specified in myStr
 Input
            : The port P10UT displays the number of E's in the string
 Output
 Author
            : A. Milenkovic, milenkovic@computer.org
 Date
            : August 14, 2008
        .cdecls C,LIST,"msp430.h" ; Include device header file
        .def
               RESET
                                       ; Export program entry-point to
                                       ; make it known to linker.
       .string "HELLO WORLD, I AM THE MSP430!", ''
myStr:
        .text
                                       ; Assemble into program memory.
                                       ; Override ELF conditional linking
        .retain
                                       ; and retain current section.
        .retainrefs
                                       ; And retain any sections that have
                                       : references to current section.
RESET:
               # STACK END, SP
                                      ; Initialize stack pointer
       mov.w
               #WDTPW|WDTHOLD,&WDTCTL ; Stop watchdog timer
        mov.w
```

Count Characters 'E' (cont'd)

```
Main loop here
main:
        bis.b
                #0FFh,&P1DIR
                                         ; configure P1.x output
                                         ; load the starting address of the string into R4
        mov.w
                #myStr, R4
        clr.b
                                         ; register R5 will serve as a counter
                R5
        mov.b
                @R4+, R6
                                         ; get a new character
gnext:
                #0,R6
                                         : is it a null character
        cmp
        jeq
                lend
                                         ; if yes, go to the end
                #'E',R6
                                         ; is it an 'E' character
        cmp.b
        jne
                                         ; if not, go to the next
                gnext
                R5
                                         ; if yes, increment counter
        inc.w
                                         ; go to the next character
        jmp
                gnext
lend:
        mov.b
                R5,&P10UT
                                         ; set all P1 pins (output)
        bis.w
                #LPM4,SR
                                         ; LPM4
                                         ; required only for Debugger
        nop
  Stack Pointer definition
        .global __STACK_END
        .sect
                .stack
  Interrupt Vectors
                 ".reset"
         .sect
                                         ; MSP430 RESET Vector
         .short
                 RESET
         .end
```

The Case for Subroutines: An Example

Subroutines

- **Problem**
 - Sum up elements of two integer arrays
 - Display results on P2OUT&P1OUT and P4OUT&P3OUT
- Example
 - int 1, 2, 3, 4, 1, 2, 3, 4; the first array arr1
 - arr2 .int 1, 1, 1, 1, -1, -1 ; the second array
 - Results
 - P2OUT&P1OUT=0x000A, P4OUT&P3OUT=0x0001
- Approach
 - Input numbers: arrays
 - Main program (no subroutines): initialization, program loops



Intro

SUMD/SUMI

Sum Up Two Integer Arrays (ver1)

```
: Lab5 D1.asm (CPE 325 Lab5 Demo code)
 File
 Function
             : Finds a sum of two integer arrays
 Description: The program initializes ports,
              sums up elements of two integer arrays and
               display sums on parallel ports
             : The input arrays are signed 16-bit integers in arr1 and arr2
 Input
             : P10UT&P20U displays sum of arr1, P30UT&P40UT displays sum of arr2
 Output
             : A. Milenkovic, milenkovic@computer.org
 Author
             : September 14, 2008
  Date
            .cdecls C,LIST, "msp430.h"; Include device header file
            .def
                    RESET
                                            ; Export program entry-point to
                                            ; make it known to linker.
                                            ; Assemble into program memory.
            .text
                                            ; Override ELF conditional linking
            .retain
                                            ; and retain current section.
            .retainrefs
                                            ; And retain any sections that have
                                            ; references to current section.
RESET:
                    # STACK END, SP
                                       ; Initialize stack pointer
             mov.w
                     #WDTPW|WDTHOLD, &WDTCTL ; Stop watchdog timer
StopWDT:
             mov.w
```



Performance



Sum up two integer arrays (ver1)

```
; Main code here
main:
                    #0xFF,&P1DIR
                                            ; configure P1.x as output
            bis.b
            bis.b
                   #0xFF,&P2DIR
                                            ; configure P2.x as output
                                            ; configure P3.x as output
            bis.b
                   #0xFF,&P3DIR
            bis.b
                   #0xFF,&P4DIR
                                            ; configure P4.x as output
            ; load the starting address of the array1 into the register R4
                    #arr1, R4
            mov.w
            ; load the starting address of the array1 into the register R4
                    #arr2, R5
            mov.w
            ; Sum arr1 and display
            clr.w
                                            ; Holds the sum
                    R7
                                                 ; number of elements in arr1
                         #8, R10
            mov.w
lnext1:
                         @R4+, R7
                                                 ; get next element
            add.w
                    R10
            dec.w
            jnz
                    lnext1
            mov.b
                    R7, P10UT
                                            ; display sum of arr1
            swpb
                    R7
                    R7, P20UT
            mov.b
```



Sum up two integer arrays (ver1)

```
; Sum arr2 and display
           clr.w
                                          ; Holds the sum
                   R7
                                          ; number of elements in arr2
                   #7, R10
           mov.w
1next2:
           add.w
                   @R5+, R7
                                          ; get next element
           dec.w
                   R10
           jnz
                   lnext2
                   R7, P30UT
                                          ; display sum of arr1
           mov.b
           swpb
                   R7
           mov.b
                   R7, P40UT
                   $
           jmp
            int 1, 2, 3, 4, 1, 2, 3, 4; the first array
arr1:
            .int 1, 1, 1, -1, -1, -1; the second array
arr2:
; Stack Pointer definition
           .global __STACK_END
           .sect .stack
 Interrupt Vectors
                  ".reset"
                                          ; MSP430 RESET Vector
            .sect
                   RESET
            .short
            .end
```

Subroutines

Subroutines

- A particular sub-task is performed many times on different data values
- Frequently used subtasks are known as subroutines
- Subroutines: How do they work?

SUMD/SUMI

- Only one copy of the instructions that constitute the subroutine is placed in memory
- Any program that requires the use of the subroutine simply branches to its starting location in memory
- Upon completion of the task in the subroutine, the execution continues at the next instruction in the calling program




Subroutines (cont'd)

Subroutines

- **CALL** instruction: perform the branch to subroutines
 - SP \leq SP = 2; allocate a word on the stack for return address
 - M[SP] <= PC ; push the return address (current PC) onto the stack
 - PC <= TargetAddress; the starting address of the subroutine is moved into PC
- **RET** instruction: the last instruction in the subroutine
 - PC <= M[SP] ; pop the return address from the stack
 - $SP \le SP + 2$; release the stack space



Subroutine Nesting





Mechanisms for Passing Parameter's

Subroutines

- Through registers
- Through stack
 - By value
 - Actual parameter is transferred
 - If the parameter is modified by the subroutine, the "new value" does not affect the "old value"
 - By reference
 - The address of the parameter is passed
 - There is only one copy of parameter
 - If parameter is modified, it is modified globally



Subroutine: SUMA RP

- Subroutine for summing up elements of an integer array
- Passing parameters through registers
 - R12 starting address of the array
 - R13 array length
 - R14 display id (0 for P2&P1, 1 for P4&P3)



Assembly Directives > SUMD/SUMI > CountEs > Subroutines > Performance

Subroutine: SUMA RP

```
: Lab5 D2 RP.asm (CPE 325 Lab5 Demo code)
; File
; Function : Finds a sum of an input integer array
; Description: suma_rp is a subroutine that sums elements of an integer array
; Input
             : The input parameters are:
                   R12 -- array starting address
                   R13 -- the number of elements (>= 1)
                   R14 -- display ID (0 for P1&P2 and 1 for P3&P4)
; Output
             : No output
            : A. Milenkovic, milenkovic@computer.org
; Author
             : September 14, 2008
 Date
            .cdecls C,LIST,"msp430.h" ; Include device header file
            .def suma_rp
            .text
```



Subroutine: SUMA RP

```
suma_rp:
            push.w R7
                                    ; save the register R7 on the stack
            clr.w
                                    ; clear register R7 (keeps the sum)
                   R7
lnext:
           add.w
                   @R12+, R7
                                    ; add a new element
            dec.w
                   R13
                                    ; decrement step counter
            jnz
                   lnext
                                    ; jump if not finished
            bit.w
                   #1, R14
                                    ; test display ID
                                    ; jump on lp34 if display ID=1
            jnz
                   1p34
                   R7, P10UT
                                    ; display lower 8-bits of the sum on P10UT
            mov.b
            swpb
                   R7
                                    ; swap bytes
           mov.b
                   R7, P20UT
                                    ; display upper 8-bits of the sum on P2OUT
                   lend
                                    ; skip to end
            jmp
1p34:
            mov.b
                   R7, P30UT
                                    ; display lower 8-bits of the sum on P3OUT
            swpb
                   R7
                                    ; swap bytes
            mov.b
                   R7, P40UT
                                    ; display upper 8-bits of the sum on P40UT
lend:
                                    : restore R7
                   R7
            pop
                                    ; return from subroutine
            ret
            .end
```



Main (ver2): Call suma_rp

```
; Main code here
                                            ; configure P1.x as output
main:
            bis.b
                   #0xFF,&P1DIR
            bis.b
                    #0xFF,&P2DIR
                                            ; configure P2.x as output
            bis.b
                   #0xFF,&P3DIR
                                            ; configure P3.x as output
            bis.b
                   #0xFF,&P4DIR
                                            ; configure P4.x as output
                                            ; put address into R12
                    #arr1, R12
            mov.w
                   #8, R13
                                            ; put array length into R13
            mov.w
                    #0, R14
                                            ; display #0 (P1&P2)
            mov.w
            call
                    #suma rp
                   #arr2, R12
            mov.w
                                            ; put address into R12
                                            ; put array length into R13
                    #7, R13
            mov.w
                                            ; display #0 (P3&P4)
                    #1, R14
            mov.w
            call
                    #suma rp
                    $
            jmp
             .int
arr1:
                      1, 2, 3, 4, 1, 2, 3, 4 ; the first array
                      1, 1, 1, -1, -1, -1; the second array
             .int
arr2:
```

Subroutine: SUMA_SP

Subroutines

- Subroutine for summing up elements of an integer array
- Passing parameters through the stack
 - The calling program prepares input parameters on the stack



Main (ver3): Call suma_sp (Pass Through Stack)

;; Main code	e here			Address	Stack
;		#0vff	. configure D1 v on output	0x0800	OTOS
тати:	bis.b	#0xFF,&P1DIR #0xFF,&P2DIR	<pre>; configure P1.x as output ; configure P2.x as output</pre>	0x07FE	#arr1
	bis.b bis.b	#0xFF,&P3DIR #0xFF,&P4DIR	<pre>; configure P3.x as output ; configure P4.x as output</pre>	0x07FC	8000
	push	#arr1	; push the address of arr1	0x07FA	0000
	push push	#8 #0	<pre>; push the number of elements ; push display id</pre>	0x07F8	Ret. Addr.
	call add.w	#suma_sp #6,SP	; collapse the stack		
	push push	#arr2 #7	<pre>; push the address of arr1 ; push the number of elements</pre>		
	push call	#1 #suma_sp	; push display id		
	add.w	#6,SP	; collapse the stack		
	jmp	\$			
arr1:	.int	1, 2, 3, 4, 1, 2, 3, 4	; the first array		
arr2:	.int	1, 1, 1, 1, -1, -1, -1	; the second array		

Subroutine: SUMA_SP

```
: Lab5 D3 SP.asm (CPE 325 Lab5 Demo code)
; File
; Function : Finds a sum of an input integer array
; Description: suma_sp is a subroutine that sums elements of an integer array
 Input
            : The input parameters are on the stack pushed as follows:
                 starting addrress of the array
                 array length
                 display id
          : No output
; Output
            : A. Milenkovic, milenkovic@computer.org
 Author
            : September 14, 2008
 Date
           .cdecls C,LIST,"msp430.h" ; Include device header file
           .def
                   suma_sp
           .text
```





Subroutine: SUMA_SP (cont'd)

<pre>suma_sp:</pre>					
			; save the registers on the stack	Address	Stack
	push	R7	; save R7, temporal sum	0x0800	OTOS
	push	R6	; save R6, array length	UXUSUU	0103
	push	R4	; save R5, pointer to array	0x07FE	#arr1
	clr.w	R7	; clear R7	UXU/IL	#all I
	mov.w	10(SP), R6	; retrieve array length	0x07FC	0008
lnext:	mov.w add.w	12(SP), R4 @R4+, R7	<pre>; retrieve starting address ; add next element</pre>	OXO71 C	0000
THEXT.	dec.w	шк4+, к7 R6	; decrement array length	0x07FA	0000
	jnz	lnext	; repeat if not done	0,107171	0000
	mov.w	8(SP), R4	; get id from the stack	0x07F8	Ret. Addr.
	bit.w	#1, R4	; test display id		
	jnz	1p34	; jump to lp34 display id = 1	0x07F6	(R7)
	mov.b	R7, P10UT	; lower 8 bits of the sum to		
P10UT				0x07F4	(R6)
	swpb	R7	; swap bytes		
	mov.b	R7, P2OUT	; upper 8 bits of the sum to P2Q	0x07F2	(R4)
	jmp	lend	; jump to lend		
1p34:	mov.b	R7, P30UT	; lower 8 bits of ths sum to P30UT		
	swpb	R7	; swap bytes		
	mov.b	R7, P40UT	; upper 8 bits of the sum to P40UT		
lend:	pop	R4	; restore R4		
	pop	R6	; restore R6		
	pop	R7	; restore R7		
	ret		; return		
	.end				
					1.7

The Stack and Local Variables

Subroutines

- Subroutines often need local workspace
- We can use a fixed block of memory space static allocation – but:
 - The code will not be relocatable
 - The code will not be reentrant
 - The code will not be able to be called recursively
- Better solution: dynamic allocation
 - Allocate all local variables on the stack
 - STACK FRAME = a block of memory allocated by a subroutine to be used for local variables
 - FRAME POINTER = an address register used to point to the stack frame



Subroutine: SUMA SPSF

```
: Lab5 D4 SPSF.asm (CPE 325 Lab5 Demo code)
; File
 Function : Finds a sum of an input integer array
 Description: suma spsf is a subroutine that sums elements of an integer array.
              The subroutine allocates local variables on the stack:
                  counter (SFP+2)
                  sum (SFP+4)
            : The input parameters are on the stack pushed as follows:
 Input
                  starting address of the array
                  array length
                  display id
 Output
            : No output
            : A. Milenkovic, milenkovic@computer.org
 Author
            : September 14, 2008
 Date
          .cdecls C,LIST,"msp430.h" ; Include device header file
                  suma spsf
           .def
           .text
```



SUMD/SUMI



Subroutine: SUMA_SPSF (cont'd)

Subroutines

suma_sp	sf:			Address	Stack
	; save the registers on the stack				OTOS
	push mov.w	R12 SP, R12	; save R12 - R12 is stack frame pointer ; R12 points on the bottom of the stack frame		
	sub.w	#4, SP	; allocate 4 bytes for local variables	0x07FE	#arr1
	push	R4	; pointer register	0x07FC	0008
	clr.w	-4(R12)	; clear sum, sum=0		
	mov.w	, , , , , , , , ,	; get array length	0x07FA	0000
	mov.w		; R4 points to the array starting address		
<pre>lnext:</pre>	add.w	, ,	; add next element	0x07F8	Ret. Addr.
	dec.w jnz	-2(R12) lnext	; decrement counter ; repeat if not done R17	0,0756	(D12)
	bit.w	#1, 4(R12)	; repeat if not done R12	→ 0x07F6	(R12)
	jnz	1p34	; jump to lp34 if display id = 1	0x07F4	counter
	mov.b	• • • • • • • • • • • • • • • • • • •	; lower 8 bits of the sum to P10UT	0,0714	counter
	mov.b	-3(R12), P20UT	; upper 8 bits of the sume to P2OUT	0x07F2	sum
	jmp	lend	; skip to lend		
1p34:	mov.b	-4(R12), P30UT	; lower 8 bits of the sum to P3OUT SP =	→ 0x0731	(R4)
	mov.b	-3(R12), P40UT	; upper 8 bits of the sume to P40UT		
lend:	pop	R4	; restore R4		
	add.w	#4, SP	; collapse the stack frame		
	рор	R12	; restore stack frame pointer		
	ret		; return		
	.end				





Performance

- Performance: how fast a task can be completed
- Performance(X) = 1/ExecutionTime(X)
- ET: ExecutionTime

$$ET = IC \cdot CPI \cdot CCT = \frac{IC \cdot CPI}{CF}$$

- IC: Instruction Count the number of instructions executed in the program
- CPI: Cycles Per Instruction the average number of clock cycles it takes to execute an instruction
- CCT: Clock Cycle Time the duration of one processor clock cycle
- CF: Clock Frequency (1/CCT)

Performance: An Example

```
# STACK END, SP
RESET:
           mov.w
                                             ; 4cc
                   #WDTPW | WDTHOLD , &WDTCTL
StopWDT:
                                             ; 5cc
           mov.w
                   R14
                                             ; 3 cc (table 3.15)
           push
                   SP, R14
                                             ; 1 cc
           mov.w
                   #aend, R6
                                             ; 2 cc
           mov.w
                   R6, R5
                                             ; 1 cc
           mov.w
                  #arr1, R5
                                            ; 2 cc
           sub.w
                   R5, SP
           sub.w
                                            ; 1 cc
                                             ; 1 cc x 9
lnext:
           dec.w
                   R6
           dec.w
                   R14
                                             ; 1 cc x 9
                   @R6, 0(R14)
                                            ; 4 cc x 9
           mov.b
                                            ; 1 cc x 9
           dec.w
                   R5
                                             ; 2 cc x 9
           jnz
                   lnext
           jmp
                   $
        .byte 1, 2, 3, 4, 5, 6, 7, 8, 9
arr1
aend
        .end
TOTAL NUMBER OF CLOCK CYLES:
                                            4+5+3+1+2+1+2+1+9x(1+1+4+1+2) = 19+9x9 = 100 cc
TOTAL NUMBER OF INSTRUCITONS
                                             8+9x5 = 53 instructions
CPI
                                            100/53 = 1.88 cc/instruction
```