

se_lnx

Esc

Q

W

F

P

B

Tab

&hml LGUI A

&hml LALT R

&hml LSHFT S

&hml LCTRL T

G

Alt

Z

X

C

D

V

Alt

<_spc 1 0

Enter

J

L

U

Y

;

-

M

&hmr RCTRL N

&hmr RSHFT E

&hmr RALT I

&hmr RGUI O

Enter

K

H

,

.

/

Bspc

num

&smart_num 3 0

Magic

se_mac

Esc

Q

W

F

P

B

Tab

&hml LALT A

&hml LGUI R

&hml LCTRL S

&hml LSHFT T

G

Alt

Z

X

C

D

V

Alt

<_spc 1 0

Enter

J

L

U

Y

;

-

M

&hmr RSHFT N

&hmr RCTRL E

&hmr RALT I

&hmr RGUI O

Enter

K

H

,

.

/

Bspc

num

&smart_num 3 0

Magic

nav

Esc

Close

PWin

NWin

Tab

Gui

Alt

Shift

Ctrl

Alt

©_lnx

&paste_lnx

PgUp

Bspc

↑

Del

-

PgDn

&mt_home 0 LEFT

↓

&mt_end 0 RIGHT

Enter

Enter

Ins

Tab

Bspc

Cancel

fn

Esc

F12

F7

F8

F9

Tab

&hml LGUI F11

&hml LALT F4

&hml LSHFT F5

&hml LCTRL F6

Alt

F10

F1

F2

F3

&hmr LCTRL LG(LC(LEFT...

&hmr RSHFT C_VOL_DN

&hmr LALT LG(LC(RIGH...

-

Enter

Bspc

PinA.

PinW.

Alt+`

num

Esc

7

8

9

Tab

&hml LGUI N0

&hml LALT N4

&hml LSHFT N5

&hml LCTRL N6

Alt

1

2

3

-

Enter

Bspc

sys

Esc

base_mac toggle

Tab

BT 1

BT 2

BT 3

BT 4

BT CLR

Alt

Boot

Enter

Boot

Bspc

mouse

Esc

Tab

Alt

PgUp

Mouse ↑

PgDn

-

Scroll ←

Mouse ←

Mouse ↓

Mouse →

Scroll →

Enter

Left Click

Middle Click

Right Click

Bspc

Scroll ↑

Scroll ↓