- 1. **Cellular Communication**: Communication method that uses a network of cells, or geographic areas, with individual antennas to support mobile device connectivity.
- 2. **Mobile Communication**: Wireless transmission of voice, data, and video using mobile devices.
- 3. **Radio Waves**: Electromagnetic waves used to transmit signals for communication over distances without cables.
- 4. **Base Station**: A fixed point in a cell network with an antenna and transceiver to connect mobile devices within a specific area.
- 5. **Control Channel**: A dedicated radio channel that carries instructions and data for managing network access and connections.
- 6. **Forward Channel**: A channel used by the base station to send information to a mobile device.
- 7. **Full Duplex**: Communication that allows simultaneous two-way data transmission.
- 8. **Half Duplex**: Communication that allows two-way data transmission, but only one direction at a time.
- 9. **Handoff**: Process of switching a call or data session from one cell tower to another as a user moves.
- 10. **Mobile Station**: A mobile device like a cell phone or tablet, which connects to a cellular network.
- 11. **MSC (Mobile Switching Center)**: Central system in cellular networks that routes calls and data to and from mobile devices.
- 12. **Page**: A signal broadcast to locate and establish a connection with a specific mobile device.
- 13. **Reserve Channel**: A backup channel that can be used when primary channels are busy or unavailable.
- 14. **Roamer**: A mobile device operating on a network outside of its home carrier's area.
- 15. **Simplex**: Communication that occurs in only one direction, like a broadcast.
- 16. **Subscriber**: A person who uses a network's mobile services, typically through a subscription plan.
- 17. **Transceiver**: Device that can both transmit and receive signals, used in radios and mobile devices.
- 18. **FDD** (Frequency Division Duplex): Technology that uses separate frequency bands for sending and receiving data simultaneously.

- 19. **TDD** (**Time Division Duplex**): Communication method that uses the same frequency for both sending and receiving data by alternating time slots.
- 20. **Paging System**: A system that sends a signal to a specific device to notify it of incoming messages or calls.
- 21. **Cordless Telephone**: A home phone that uses radio signals to communicate with a base station connected to a landline.
- 22. **PSTN (Public Switched Telephone Network)**: The global network for traditional landline telephony.
- 23. **Cell**: A geographic area in a cellular network, served by a base station for mobile communication.
- 24. **Frequency Reuse**: Technique of using the same frequency in different cells to increase network capacity.
- 25. **Frequency Reuse Factor**: A value that indicates how often frequencies are reused across cells in a network.
- 26. **Footprint**: The area covered by a cell tower's signal.
- 27. **Cluster**: A group of cells arranged to minimize interference and support frequency reuse.
- 28. **Channel Assignment Strategies**: Methods for allocating frequency channels to cells in a network.
- 29. **Dynamic Strategies**: Adaptive methods for assigning channels based on network demand.
- 30. **Handoff**: The transfer of an active call or data session between cells as a user moves through the network.
- 31. **Hard Handoff**: A break-before-make approach where a call connection is switched completely before establishing a new one.
- 32. **Soft Handoff**: A make-before-break approach where a new connection is established before the old one is released.
- 33. **Cochannel Interference**: Interference between cells using the same frequency.
- 34. **Adjacent Channel Interference**: Interference caused by frequencies that are close to each other.
- 35. **Trunking**: A method of pooling channels to be dynamically assigned to users, optimizing network resources.
- 36. **GoS (Grade of Service)**: A measure of service quality in terms of call drops or blockages.
- 37. **Busy Hour**: The peak time during the day when network usage is highest.
- 38. **Busiest Hour**: The specific hour with the highest traffic load within a given period.

- 39. **Setup Time**: The time taken to establish a call connection.
- 40. **Holding Time**: The duration of an active call.
- 41. **Traffic Intensity**: The total call time used in a cell, usually measured in Erlangs.
- 42. **Load**: The total demand on a network or system, including active and queued requests.
- 43. **Request Rate**: The frequency at which calls or data connections are requested.
- 44. **Cell Splitting**: Dividing a cell into smaller cells to increase network capacity.
- 45. **Sectoring**: Dividing a cell into sectors, each with its own antenna to reduce interference.
- 46. **Coverage Zone Approach**: A strategy to ensure complete coverage by overlapping adjacent cells.
- 47. **Microcell**: A small cell used for areas with high user density, like cities.
- 48. **Large Cell and Small Cell Propagation**: Signal propagation for larger or smaller cells based on coverage needs.
- 49. **Basic Propagation Mechanisms (Reflection, Diffraction, and Scattering)**: Ways signals travel and interact with obstacles; reflection bounces, diffraction bends, and scattering spreads in various directions.
- 50. **Free Space Propagation**: Signal travel without interference, typically in open areas.
- 51. **Outdoor Propagation**: Signal behavior in open environments with obstacles like buildings or trees.
- 52. **Fading**: Variation in signal strength caused by environmental factors.
- 53. **Doppler Shift**: A frequency change due to the movement of a signal source or receiver.
- 54. **Phase Shift**: Change in the phase of a signal wave, which can affect signal quality.
- 55. **Small-Scale Fading Types**: Variations in signal strength over small distances due to factors like movement and obstructions.

- 1. Cellular Communication (সেলুলার যোগাযোগ): মোবাইল ডিভাইসগুলোর মাধ্যমে তথ্য বিনিময়ের একটি পদ্ধতি, যেখানে নেটওয়ার্কটি ছোট ছোট সেল বা কোষে বিভক্ত থাকে এবং প্রতিটি সেলে একটি বেস স্টেশন থাকে।
- 2. **Mobile Communication (মোবাইল যোগাযোগ)**: মোবাইল ডিভাইসের মাধ্যমে বেতার তরঙ্গ ব্যবহার করে শব্দ, ডেটা এবং ভিডিও প্রেরণ।
- 3. Radio Waves (রেডিও তরঙ্গ): ইলেক্ট্রাম্যাগনেটিক তরঙ্গ যা তারবিহীন যোগাযোগের জন্য ব্যবহৃত হয়।
- 4. **Base Station (বেস স্টেশন)**: একটি নির্দিষ্ট সেলের মধ্যে মোবাইল ডিভাইসের সাথে সংযোগ স্থাপনের জন্য নির্ধারিত স্থায়ী স্টেশন।
- 5. Control Channel (কর্ট্রোল চ্যানেল): নেটওয়ার্ক অ্যাক্সেস এবং সংযোগ ব্যবস্থাপনার জন্য প্রয়োজনীয় নির্দেশনা ও ডেটা বহনকারী বিশেষ চ্যানেল।
- 6. Forward Channel (ফ্রও্মার্ড চ্যানেল): বেস প্টেশন থেকে মোবাইল ডিভাইসের দিকে তথ্য প্রেরণের জন্য ব্যবহৃত চ্যানেল।
- 7. Full Duplex (ফুল ডুপ্লেক্স): দুটি ডিভাইসের মধ্যে একই সময়ে দ্বিমুখী তথ্য বিনিময়ের সক্ষমতা।
- 8. Half Duplex (হাফ ডুপ্লেক্স): একই চ্যানেলে দ্বিমুখী তথ্য বিনিময়, তবে এক সময়ে একদিকে।
- 9. **Handoff (হ্যান্ডঅফ)**: ব্যবহারকারী এক সেল থেকে অন্য সেলে চলে গেলে কল বা ডেটা সেশন ট্রান্সফার করার প্রক্রিয়া।
- 10. Mobile Station (মোবাইল স্টেশন): সেলুলার নেটওয়ার্কে সংযুক্ত মোবাইল ডিভাইস, যেমন একটি মোবাইল ফোন।
- 11. MSC (Mobile Switching Center): সেলুলার নেটওয়ার্কে কল ও ডেটা রাউটিংয়ের জন্য ব্যবহৃত কেন্দ্র।
- 12. Page (পেজ): নির্দিষ্ট মোবাইল ডিভাইসের সাথে সংযোগ স্থাপনের জন্য প্রেরিত সংকেত।
- 13. **Reserve Channel (রিজার্ভ চ্যানেল)**: ব্যাকআপ হিসাবে ব্যবহারের জন্য সংরক্ষিত চ্যানেল, যা প্রায়শই ব্যস্ত অবস্থায় ব্যবহৃত হয়।
- 14. Roamer (রোমার): এমল একটি মোবাইল ডিভাইস যা তার হোম লেটওয়ার্কের বাইরে কাজ করছে।
- 15. Simplex (সিমপ্লেক্স): একমুখী যোগাযোগ পদ্ধতি, যেমন একটি ব্রডকাস্ট।
- 16. **Subscriber (সাবস্কাইবার)**: নেটওয়ার্কের মোবাইল পরিষেবার ব্যবহারকারী।
- 17. Transceiver (ট্রান্সমিভার): এমন একটি ডিভাইস যা সংকেত প্রেরণ ও গ্রহণ করতে সক্ষম।
- 18. FDD (Frequency Division Duplex): পৃথক ফ্রিকোমেন্সি ব্যান্ড ব্যবহার করে ডেটা প্রেরণ ও গ্রহণের প্রযুক্তি।
- 19. **TDD (Time Division Duplex)**: একই ফ্রিকোয়েন্সি ব্যবহার করে ভিন্ন সময়ে ডেটা প্রেরণ ও গ্রহণের পদ্ধতি।

- 20. Paging System (পেজিং সিস্টেম): নির্দিষ্ট ডিভাইসকে বার্তা বা কলের বিষয়ে জানানোর জন্য সংকেত প্রেরণের ব্যবস্থা।
- 21. Cordless Telephone (কর্ডলেস টেলিফোন): এমন ফোন যা বেতার সংকেত ব্যবহার করে বেস স্টেশনের সাথে যোগাযোগ করে এবং ল্যান্ডলাইনের সাথে সংযুক্ত থাকে।
- 22. PSTN (Public Switched Telephone Network): বিশ্বের ঐতিহ্যবাহী ল্যান্ডলাইন টেলিফোনের জন্য ব্যবহৃত নেটওয়ার্ক।
- 23. Cell (সেল): একটি সেলুলার নেটওয়ার্কের একটি ভৌগোলিক এলাকা, যেখানে বেস স্টেশন মোবাইল যোগাযোগের জন্য সেবা দেয়।
- 24. Frequency Reuse (ক্রিকোমেন্সি রিইউজ): একই ক্রিকোমেন্সি বিভিন্ন সেলে ব্যবহার করে নেটওয়ার্কের ক্ষমতা বৃদ্ধি করার কৌশল।
- 25. Frequency Reuse Factor (ফ্রিকোমেন্সি রিইউজ ফ্যাক্টর): একটি নেটওয়ার্কে ফ্রিকোমেন্সি পুনরায় ব্যবহারের হার নির্দেশক একটি মান।
- 26. Footprint (ফুটপ্রিন্ট): একটি সেল টাওয়ারের সংকেত দ্বারা আচ্ছাদিত এলাকা।
- 27. **Cluster (क्राम्टाর)**: একটি গ্রুপ সেল, যা পারস্পরিক হস্তক্ষেপ কমাতে এবং ফ্রিকোয়েন্সি পুনঃব্যবহারের জন্য ব্যবহৃত হয়।
- 28. Channel Assignment Strategies (চ্যা**রেল অ্যাসাইনমেন্ট কৌশল**): নেটওয়ার্কের সেলগুলোভে ফ্রিকোয়েন্সি চ্যা**রে**ল বরাদ্দের পদ্ধতি।
- 29. **Dynamic Strategies (ডাইনামিক কৌশল)**: নেটওয়ার্কের চাহিদার উপর ভিত্তি করে চ্যানেল বরাদ্দ করার পদ্ধতি।
- 30. Hard Handoff (হার্ড হ্যান্ডঅফ): একটি কল সংযোগ সম্পূর্ণ বন্ধ করে নতুন সংযোগ স্থাপন করার পদ্ধতি।
- 31. **Soft Handoff (সফট হ্যান্ডঅফ)**: নতুন সংযোগ আগে স্থাপন করে পুরানো সংযোগ ছেড়ে দেয়ার পদ্ধতি।
- 32. Cochannel Interference (কোচ্যানেল হয়ক্ষেপ): একই ক্রিকোয়েন্সি ব্যবহারে সেলগুলোর মধ্যে হয়ক্ষেপ।
- 33. Adjacent Channel Interference (অ্যাজেসেন্ট চ্যানেল হস্তক্ষেপ): পাশাপাশি ক্রিকোয়েন্সির ব্যবহারে সৃষ্ট হস্তক্ষেপ।
- 34. **Trunking (ট্রাংকিং)**: ব্যবহারকারীদের জন্য চ্যানেলগুলোকে ডাইনামিকভাবে বরাদ্দ করার একটি পদ্ধতি।
- 35. GoS (Grade of Service): কল ড্রপ বা ব্লক হওয়ার মাধ্যমে পরিষেবার গুণগত মান পরিমাপ।
- 36. Busy Hour (বিজি আওয়ার): দিনের সেই সময় যথন নেটওয়ার্ক ব্যবহার সর্বাধিক থাকে।
- 37. Setup Time (সেটআপ টাইম): একটি কল সংযোগ স্থাপনে প্রয়োজনীয় সময়।
- 38. Holding Time (হোল্ডিং টাইম): একটি সক্রিয় কলের স্থায়ীত্বকাল।

- 39. **Traffic Intensity (ট্রাফিক ইন্টেলসিটি)**: একটি সেলে মোট কল সময়, সাধারণত এটিকে "Erlangs" এ মাপা হয়।
- 40. Load (লোড): নেটওয়ার্কের উপর মোট চাহিদা, সক্রিয় এবং অপেক্ষমান অনুরোধসহ।
- 41. Request Rate (বিকোমেন্ট বেট): কল বা ডেটা সংযোগের অনুরোধের হার।
- 42. **Cell Splitting (সেল স্মিটিং)**: নেটওয়ার্ক ক্ষমতা বৃদ্ধি করতে একটি সেলকে ছোট ছোট সেলে বিভক্ত করা।
- 43. **Sectoring (সেক্টরিং)**: একটি সেলকে সেক্টরে বিভক্ত করা এবং প্রতিটি সেক্টরের জন্য আলাদা অ্যান্টেনা ব্যবহার করা।
- 44. Coverage Zone Approach (কাভারেজ জোন পদ্ধতি): একাধিক সেলের মধ্যে আচ্ছাদন নিশ্চিত করার পদ্ধতি।
- 45. Microcell (মাইক্রোসেল): উচ্চ ব্যবহারকারী ঘনত্বযুক্ত এলাকা, যেমন শহরের জন্য ব্যবহৃত ছোট সেল।
- 46. Large Cell and Small Cell Propagation (বড় সেল ও ছোট সেল প্রোপাগেশন): বড় বা ছোট সেলের ক্ষেত্রে সংকেত বিস্তারের পদ্ধতি।
- 47. Basic Propagation Mechanisms -
- Reflection (প্রতিফলন): সংকেত বাধায় প্রতিফলিত হয়।
- Diffraction (বিকিরণ): সংকেত বাঁক নিয়ে অতিক্রম করে।
- Scattering (ছডালো): সংকেত বাধার উপর পড়ে বিভিন্ন দিকে ছডিয়ে পড়ে।
- 48. Free Space Propagation (ফ্রি স্পেস প্রোপাগেশন): খোলা জায়গায় বিনা বাধায় সংকেত চলাচল।
- 49. **Outdoor Propagation (আউটডোর প্রোপাগেশন)**: বাইরে সংকেতের আচরণ যেখানে বিল্ডিং বা গাছ বাধা হিসেবে কাজ করে।
- 50. Fading (কেডিং): পরিবেশগত কারণে সংকেত শক্তির পরিবর্তন।
- 51. **Doppler Shift (ডপলার শিফট)**: সংকেত উৎস বা গ্রহণকারীর গতির কারণে ফ্রিকোয়েন্সি পরিবর্তন।
- 52. Phase Shift (কেজ শিকট): সংকেত তরঙ্গের পর্যায়ে পরিবর্তন, যা সংকেতের গুণমানকে প্রভাবিত করতে পারে।
- 53. Small-Scale Fading (ছোট-স্কেল কেডিং): সংকেত শক্তিতে ছোট দূরত্বের মধ্যে পরিবর্তন, যা মূলত বাধা এবং গতির কারণে