REMINGTON COCONUT SMOOTH HAIR DRYER D5901 USER MANUAL

Congratulations on your purchase of the Remington Coconut Smooth Hair Dryer D5901! This user manual will guide you on how to effectively and safely use your hair dryer for effortless and smooth hair drying. Please read this manual carefully before using the product.

Product Overview: The Remington Coconut Smooth Hair Dryer D5901 is a powerful and innovative hair styling tool that combines advanced drying technology with the nourishing benefits of coconut oil. This hair dryer is designed to provide efficient drying, reduce frizz, and leave your hair feeling smooth and shiny. With its ergonomic design and multiple heat and speed settings, you can customize your drying experience for optimal results.

Important Safety Precautions:

- 1. Read all instructions before using the hair dryer and keep them for future reference.
- 2. This hair dryer is for household use only. Do not use it in a bathroom or near water sources.
- 3. Unplug the hair dryer when not in use and before cleaning.
- 4. Do not immerse the hair dryer in water or any other liquids.
- 5. Do not block the air intake or exhaust vents during operation.
- 6. Keep the hair dryer away from heat sources and flammable materials.
- 7. Use the hair dryer on dry hair only. Do not use it on wet or damp hair.
- 8. Do not use the hair dryer if the cord or plug is damaged.
- 9. Do not use the hair dryer with an extension cord.
- 10. Do not direct the airflow onto your face, eyes, or any other sensitive areas.

Usage Instructions:

1. Preparation:

- Ensure your hair is clean and towel-dried to remove excess moisture.
- Comb or brush your hair to detangle any knots or tangles.

2. Heat and Speed Settings:

- Locate the heat and speed controls on the hair dryer.
- Choose the desired heat setting (low, medium, high) based on your hair type and styling needs.
- Select the appropriate speed setting (low, medium, high) for the airflow intensity.

3. Attachments (if applicable):

- If your hair dryer includes attachments, such as a concentrator nozzle or diffuser, securely attach them to the dryer according to the manufacturer's instructions.
- The concentrator nozzle helps to focus the airflow for precise drying and styling.
- The diffuser attachment helps to distribute the airflow evenly for gentle drying and enhanced natural curls.

4. Drying Process:

- Hold the hair dryer by the handle, keeping a comfortable grip.
- Point the airflow in the desired direction, either downward for smooth drying or upward for added volume.
- Keep the hair dryer at a suitable distance from your hair to avoid excessive heat exposure.
- Move the hair dryer continuously to prevent overheating specific areas.
- Use a brush or comb to guide the airflow and style your hair as you dry.

5. Cool Shot:

- The hair dryer may include a cool shot button. Use this feature to release a blast of cool air to set your hairstyle and add shine.
- Press the cool shot button as needed during or after drying for the desired effect.

6. After Use:

- Turn off the hair dryer and unplug it from the power source.
- Allow the hair dryer to cool down before storing it.
- Clean the air intake vents and the attachments (if applicable) regularly to ensure optimal performance and longevity.

Care and Maintenance:

- Regularly clean the air intake vents and the rear grille using a soft, dry cloth.
- Remove any hair or debris that may accumulate around the vents.
- Do not use abrasive cleaners or immerse the hair dryer in water.
- Store the hair dryer in a cool, dry place when not in use