ACME AX-100 Service Manual R1

Error E-43: oil level is below the limit.

Isolate electrical power before maintenance.

Fill the tank with 3 litres of oil.