




QUICK START

- Press the mode button (COOL / HEAT / DRY / FAN) to turn on the air conditioner.

⚠ NOTE

In winter, if you increase the temperature suddenly to 30°C, the air conditioner may not start.