



Upgrade Bios & Software in VL GEO2



Bios

You can update the GEO2 BIOS firmware with new improvements when they are released.

1. Press **ON** to activate the GEO2 instrument.
2. Use the mini USB cable to connect the Instrument to a computer.
 - a. The instrument will switch to USB mode automatically.
 - b. The Instrument will show up as a removable drive on Windows computers and as a mounted volume on Mac computers.
3. Copy the firmware file to the instrument's root library for example: "**VLGEO2_V30.VLB**".




4. Disconnect the USB cable.
5. Turn the instrument off.
6. **Hold the SEND button** while the instrument is off and **plug in the USB cable** to start the upgrade. Let go of the **SEND** button.

When the upgrade is done, unplug the USB cable.

Software

Install a new application by copying an application file, for example "**GEO2 V34.VL7**", to "**VL_GEO2:\PRG**" folder.

1. Press **ON** to activate the GEO2 instrument.
2. Use the mini-USB cable to connect the Instrument to a computer.
 - a. The instrument will switch to USB mode automatically.
 - b. The Instrument will show up as a removable drive on Windows computer and as a mounted volume on Mac computers.



3. Copy the application file, for example "**GEO2 V37.VL7**", to "**VL_GEO2:\PRG**" folder.
4. Unplug the USB cable.
5. Go to the menu "**SETTINGS**" in the application and press ON.
6. Choose menu "**SELECT PROG**" and press ON.
7. Pick the application from the list and press ON.
8. Choose "**START**" and press ON.