

Section 51. 12-Bit A/D Converter with Threshold Detect

HIGHLIGHTS

| This se | ection of the manual contains the following major topics: | |
|---------|---|-------|
| 51.1 | Introduction | 51-2 |
| 51.2 | A/D Terminology and Conversion Sequence | 51-4 |
| 51.3 | Registers | 51-6 |
| 51.4 | A/D Module Configuration | 51-19 |
| 51.5 | Initialization | 51-23 |
| 51.6 | Controlling the Sampling Process | 51-24 |
| 51.7 | Controlling the Conversion Process | 51-24 |
| 51.8 | A/D Results Buffer | 51-30 |
| 51.9 | Extended DMA Operations | 51-34 |
| 51.10 | Threshold Detect Operation | 51-37 |
| 51.11 | Conversion Sequence Examples | 51-44 |
| 51.12 | A/D Sampling Requirements | 51-53 |
| 51.13 | Transfer Functions | 51-54 |
| 51.14 | A/D Accuracy/Error | 51-56 |
| 51.15 | Operation During Sleep and Idle Modes | 51-56 |
| 51.16 | Effects of a Reset | 51-57 |
| 51.17 | Register Maps | 51-58 |
| 51.18 | Electrical Specifications | 51-59 |
| 51.19 | Design Tips | 51-60 |
| 51.20 | Related Application Notes | 51-6 |
| 51.21 | Revision History | 51-62 |

51.1 INTRODUCTION

The PIC24F 12-bit A/D Converter has the following key features:

- · Successive Approximation Register (SAR) Conversion
- · Conversion Speeds of up to 200 ksps
- Up to 32 Analog Input Channels (Internal and External)
- · Multiple Internal Reference Input Channels
- · External Voltage Reference Input Pins
- · Unipolar Differential Sample-and-Hold (S/H) Amplifier
- Automated Threshold Scan and Compare Operation to Pre-Evaluate Conversion Results
- · Selectable Conversion Trigger Source
- · Fixed-Length (one word per channel), Configurable Conversion Result Buffer
- · Four Options for Results Alignment
- · Configurable Interrupt Generation
- · DMA Operation with Indirect Address Generation
- · Operation During CPU Sleep and Idle modes

The 12-bit A/D Converter module is an enhanced version of the 10-bit module offered in some PIC24 devices. Both modules are Successive Approximation Register (SAR) Converters at their cores, surrounded by a range of hardware features for flexible configuration. This version of the module extends functionality by providing 12-bit resolution, a wider range of automatic sampling options, tighter integration with other analog modules, such as the CTMU, and a configurable results buffer. This module also includes a unique Threshold Detect feature that allows the module itself to make simple decisions based on the conversion results.

As before, an internal Sample-and-Hold (S/H) amplifier acquires a sample of an input signal, then holds that value constant during the conversion process. A combination of input multiplexers selects the signal to be converted from up to 32 analog inputs, both external (analog input pins) and internal (e.g., on-chip voltage references and other analog modules). The whole multiplexer path includes provisions for differential analog input, although, with a limited number of negative input pins. The sampled voltage is held and converted to a digital value, which strictly speaking, represents the ratio of that input voltage to a reference voltage. Configuration choices allow connection of an external reference or use of the device power and ground (AVDD and AVSS). Reference and input signal pins are assigned differently depending on the particular device.


An array of timing and control selections allow the user to create flexible scanning sequences. Conversions can be started individually by program control, continuously free-running or triggered by selected hardware events. A single channel may be repeatedly converted. Alternate conversions may be performed on two channels, or any or all of the channels may be sequentially scanned and converted according to a user-defined bit map. The resulting conversion output is a 12-bit digital number, which can be signed or unsigned, left or right justified. (In some devices, a user-selectable resolution of 10 bits is available; in other devices, 12-bit resolution is the only option available.)

Conversions are automatically stored in a dedicated buffer, allowing for multiple successive readings to be taken before software service is needed. The buffer can be configured to function as a FIFO buffer or as a channel indexed buffer. In FIFO mode, the buffer can be split into two equal sections for simultaneous conversion and read operations. In Indexed mode, the buffer can use the Threshold Scan feature to determine if a conversion meets specific, user-defined criteria, storing or discarding the converted value as appropriate, and then set semaphore flags to indicate the event. This allows conversions to occur in low-power modes when the CPU is inactive, waking the device only when specific conditions have occurred.

The module sets its interrupt flag after a selectable number of conversions, when the buffer can be read, or after a successful Threshold Detect comparison. After the interrupt, the sequence restarts at the beginning of the buffer. When the interrupt flag is set, according to the earlier selection, scan selections and the Output Buffer Pointer return to their starting positions.

A simplified block diagram for the module is shown in Figure 51-1.

Figure 51-1: 12-Bit A/D Converter Block Diagram



- Note 1: Up to 32 analog channels may be implemented, depending on the particular device family and individual device pin count. Some or all of these may be external channels, depending on the device. Refer to the specific device data sheet for details.
 - 2: Internal analog channels are implemented with different options in different device families. Refer to the specific device data sheet for details.
 - 3: The conversion buffer will always be at least the same size (in words) as the number of external channels, rounded up to the next greater even number. Refer to the specific device data sheet for the exact number.


51.2 A/D TERMINOLOGY AND CONVERSION SEQUENCE

Sample time is the time that the A/D module's S/H amplifier is connected to the analog input pin. The sample time may be started and ended automatically by the A/D Converter's hardware or under direct program control. There is a minimum sample time to ensure that the S/H amplifier will give sufficient accuracy for the A/D conversion.

The conversion trigger ends the sampling time and begins an A/D conversion or a repeating sequence. The conversion trigger sources can be taken from a variety of hardware sources or can be controlled directly in software. One of the conversion trigger options is an auto-conversion, which uses a counter and the A/D clock to set the time between auto-conversions. The Auto-Sample mode and auto-conversion trigger can be used together to provide continuous, automatic conversions without software intervention. When automatic sampling is used, an extended sampling interval is extended between the time the sampling ends and the conversion starts.

Conversion time is the time required for the A/D Converter to convert the voltage held by the S/H amplifier. An A/D conversion requires one A/D clock cycle (TAD) to convert each bit of the result, plus two additional clock cycles, or a total of 14 TAD cycles for a 12-bit conversion. When the conversion is complete, the result is loaded into one of the A/D result buffers. The S/H can be reconnected to the input pin and a CPU interrupt may be generated. The sum of the sample time(s) and the A/D conversion time provides the total A/D sequence time. Figure 51-2 shows the basic conversion sequence and the relationship between intervals.





Note 1: In Automatic Sampling modes, Extended Sampling Time is added to the sequence when the value for the Auto-Sampling Time is greater than 0. Otherwise, sampling ends and conversion starts whenever the SAMP bit is cleared.


51.2.1 Operation as a State Machine

The A/D conversion process can be thought of in terms of a finite state machine (Figure 51-3). The sample state represents the time that the input channel is connected to the S/H amplifier and the signal is passed to the converter input. The convert state is transitory. The module enters this state as soon as it exits the sample state and transitions to a different state when that is done. The inactive state is the default state prior to module initialization and following a software-controlled conversion; it can be avoided in operation by using Auto-Sample mode. Machine states are identified by the state of several control and status bits in AD1CON1 (Register 51-1).

If the module is configured for Auto-Sample mode, the operation "ping-pongs" continuously between the sample and convert states. The module automatically selects the input channels to be sampled (if channel scanning is enabled), while the selected conversion trigger source paces the entire operation. Any time that Auto-Sample mode is not used for conversion, it is available for the sample state. The user needs to make certain that acquisition time is sufficient, in addition to accounting for the normal concerns about system throughput.

Whenever the issue of sampling time is important, the significant event is the transition from sample to convert state. This is the point where the Sample-and-Hold aperture closes, and it is essentially the signal value at this instant, which is applied to the A/D for conversion to digital.

Figure 51-3: A/D Module State Machine Model



51.3 REGISTERS

The 12-bit A/D Converter module uses up to 43 registers for its operation. All registers are mapped in the data memory space.

51.3.1 Control Registers

Depending on the specific device, the module has up to twelve control and status registers:

- AD1CON1: A/D Control Register 1
- · AD1CON2: A/D Control Register 2
- · AD1CON3: A/D Control Register 3
- AD1CON4: A/D Control Register 4
- AD1CON5: A/D Control Register 5
- · AD1CHS: A/D Input Channel Select Register
- · AD1CHITH and AD1CHITL: A/D Scan Compare Hit Registers
- · AD1CSSL and AD1CSSH: A/D Input Scan Select Registers
- AD1CTMENH and AD1CTMENL: CTMU Enable Register

The AD1CON1, AD1CON2 and AD1CON3 registers (Register 51-1, Register 51-2 and Register 51-3) control the overall operation of the A/D module. This includes enabling the module, configuring the conversion clock and voltage reference sources, selecting the sampling and conversion triggers, and manually controlling the sample/convert sequences. The AD1CON4 register (Register 51-4) sets the DMA buffer size in Scatter/Gather mode. The AD1CON5 register (Register 51-5) specifically controls features of Threshold Detect operation, including its functioning in power-saving modes.

The AD1CHS register (Register 51-6) selects the input channels to be connected to the S/H amplifier. It also allows the choice of input multiplexers and the selection of a reference source for differential sampling.

The AD1CHITH and AD1CHITL registers (Register 51-7 and Register 51-8) are semaphore registers used with Threshold Detect operations. The status of individual bits, or bit pairs in some cases, indicate if a match condition has occurred. Their use is described in more detail in **Section 51.10 "Threshold Detect Operation"**. AD1CHITL is always implemented, whereas AD1CHITH may not be implemented in devices with 16 channels or less.

The AD1CSSH/L registers (Register 51-9 and Register 51-10) select the channels to be included for sequential scanning.

The AD1CTMENH/L registers (Register 51-11 and Register 51-12) select the channel(s) to be used by the CTMU during conversions. Selecting a particular channel allows the A/D Converter to control the CTMU (particularly, its current source) and read its data through that channel. AD1CTMENL is always implemented, whereas AD1CTMENH may not be implemented in devices with 16 channels or less.

51.3.2 A/D Result Buffers

The module incorporates a multi-word, dual port RAM, called ADC1BUF. The buffer is composed of at least the same number of word locations as there are external analog channels for a particular device, with a maximum number of 32. The number of buffer addresses is always even. Each of the locations is mapped into the data memory space and is separately addressable. The buffer locations are referred to as ADC1BUF0 through ADC1BUFn (up to 31).

The A/D result buffers are both readable and writable. When the module is active (AD1CON1<15> = 1), the buffers are read-only, and store the results of A/D conversions. When the module is inactive (AD1CON1<15> = 0), the buffers are both readable and writable. In this state, writing to a buffer location programs a conversion threshold for Threshold Detect operations, as described in Section 51.10.2 "Setting Comparison Thresholds".

When Extended DMA operation is enabled (AD1CON1<11> = 1), conversion results are written to AD1DMBUF, a 16-bit conversion buffer. Buffer contents are not cleared when the module is deactivated with the ADON bit (AD1CON1<15>). Conversion results and any programmed threshold values in the ADC1BUFn registers are maintained when ADON is set or cleared.

Section 51, 12-Bit A/D Converter with Threshold Detect

Register 51-1: AD1CON1: A/D Control Register 1

| R/W-0 | U-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0/U | R/W-0 | R/W-0 |
|--------|-----|--------|------------------------|----------------------|-----------------------|-------|-------|
| ADON | _ | ADSIDL | DMABM ^(3,4) | DMAEN ⁽³⁾ | MODE12 ⁽¹⁾ | FORM1 | FORM0 |
| bit 15 | | | | | | | bit 8 |

| R/W-0 | R/W-0 | R/W-0 | R/W-0 | U-0 | R/W-0 | R/W-0 HSC | R/C-0 HSC |
|----------------------|----------------------|----------------------|----------------------|-----|-------|-----------|-----------|
| SSRC3 ⁽²⁾ | SSRC2 ⁽²⁾ | SSRC1 ⁽²⁾ | SSRC0 ⁽²⁾ | _ | ASAM | SAMP | DONE |
| bit 7 | | | | | | | bit 0 |

| Legend: | C = Clearable bit | U = Unimplemented bit, read as '0' | |
|-------------------|-------------------|------------------------------------|--------------------|
| R = Readable bit | W = Writable bit | HSC = Hardware Settable/ | Clearable bit |
| -n = Value at POR | '1' = Bit is set | '0' = Bit is cleared | x = Bit is unknown |

- bit 15 ADON: A/D Operating Mode bit
 - 1 = A/D Converter module is operating
 - 0 = A/D Converter is off
- bit 14 **Unimplemented:** Read as '0'
- bit 13 ADSIDL: Stop in Idle Mode bit
 - 1 = Discontinue module operation when the device enters Idle mode
 - 0 = Continue module operation in Idle mode
- bit 12 **DMABM:** Extended DMA Buffer Mode Select bit (3,4)
 - 1 = Extended Buffer mode: Conversion values are stored in the order in which they were converted.
 - 0 = Scatter/Gather mode: Conversion values are stored according to the channel from which they were converted.
- bit 11 **DMAEN:** Extended DMA/Buffer Enable bit⁽³⁾
 - 1 = Extended DMA and buffer features are enabled
 - 0 = Extended features are disabled
- bit 10 **MODE12:** 12-Bit Operation Mode bit⁽¹⁾
 - 1 = 12-bit A/D operation
 - 0 = 10-bit A/D operation
- bit 9-8 **FORM<1:0>:** Data Output Format bits (see the following formats)
 - 11 = Fractional result, signed, left-justified
 - 10 = Absolute fractional result, unsigned, left-justified
 - 01 = Decimal result, signed, right-justified
 - 00 = Absolute decimal result, unsigned, right-justified
- Note 1: This bit is implemented only in modules with user-selectable resolution. For A/D modules with fixed, 10-bit or 12-bit resolution, this bit is unimplemented and should be maintained as '1' or '0'. Refer to the device data sheet for the specific setting of this bit.
 - 2: Sample clock trigger sources are defined differently for each device family; not all trigger sources may be defined. Refer to the specific device data sheet for details.
 - **3:** DMAEN and DMABM are implemented only in devices with DMA. For devices without DMA, the bits are unimplemented and read as '0'. For more information, refer to the specific device data sheet.
 - 4: This bit is only available when Extended DMA/Buffer features are available (DMAEN = 1).

PIC24F Family Reference Manual

Register 51-1: AD1CON1: A/D Control Register 1 (Continued)

bit 7-4 SSRC<3:0>: Sample Clock Source Select bits⁽²⁾

1111 = The SAMP bit is cleared by a rising edge of Trigger Input 15

1110 = The SAMP bit is cleared by a rising edge of Trigger Input 14

• • •

1001 = The SAMP bit is cleared by a rising edge of Trigger Input 9

1000 = The SAMP bit is cleared by a rising edge of Trigger Input 8

0111 = The SAMP bit is cleared after SAMC<4:0> number of TAD clocks, following the SAMP bit being set (Auto-Convert mode); no Extended Sample Time is present

0110 = The SAMP bit is cleared by a rising edge of Trigger Input 6

• • •

0001 = The SAMP bit is cleared by a rising edge of Trigger Input 1

0000 = The SAMP bit must be cleared by software

bit 3 **Unimplemented:** Read as '0'

bit 2 ASAM: A/D Sample Auto-Start bit

1 = Sampling begins immediately after the last conversion; SAMP bit is auto-set

0 = Sampling begins when the SAMP bit is manually set

bit 1 SAMP: A/D Sample Enable bit

1 = A/D Sample-and-Hold amplifiers are sampling

0 = A/D Sample-and-Hold amplifiers are holding

bit 0 **DONE:** A/D Conversion Status bit

1 = A/D conversion cycle is completed

0 = A/D conversion has not started or is in progress

- Note 1: This bit is implemented only in modules with user-selectable resolution. For A/D modules with fixed, 10-bit or 12-bit resolution, this bit is unimplemented and should be maintained as '1' or '0'. Refer to the device data sheet for the specific setting of this bit.
 - 2: Sample clock trigger sources are defined differently for each device family; not all trigger sources may be defined. Refer to the specific device data sheet for details.
 - **3:** DMAEN and DMABM are implemented only in devices with DMA. For devices without DMA, the bits are unimplemented and read as '0'. For more information, refer to the specific device data sheet.
 - 4: This bit is only available when Extended DMA/Buffer features are available (DMAEN = 1).

Section 51, 12-Bit A/D Converter with Threshold Detect

Register 51-2: AD1CON2: A/D Control Register 2

| R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | U-0 | U-0 |
|--------|--------|--------|--------|----------|-------|-----|-------|
| PVCFG1 | PVCFG0 | NVCFG0 | OFFCAL | BUFREGEN | CSCNA | _ | _ |
| bit 15 | | | | | | | bit 8 |

| R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 |
|---------------------|----------------------|----------------------|----------------------|----------------------|----------------------|---------------------|-------|
| BUFS ⁽¹⁾ | SMPI4 ⁽²⁾ | SMPI3 ⁽²⁾ | SMPI2 ⁽²⁾ | SMPI1 ⁽²⁾ | SMPI0 ⁽²⁾ | BUFM ⁽¹⁾ | ALTS |
| bit 7 | | | | | | | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-14 **PVCFG<1:0>:** Converter Positive Voltage Reference Configuration bits

11 = Internal VRH2

10 = Internal VRH1

01 = External VREF+

00 = AVDD

bit 13 NVCFG0: Converter Negative Voltage Reference Configuration bits

1 = External VREF-

0 = AVss

bit 12 OFFCAL: Offset Calibration Mode Select bit

1 = Inverting and non-inverting inputs of channel Sample-and-Hold are connected to AVss

0 = Inverting and non-inverting inputs of channel Sample-and-Hold are connected to normal inputs

bit 11 **BUFREGEN:** A/D Buffer Register Enable bit

1 = Conversion result is loaded into buffer location determined by the converted channel

0 = A/D result buffer is treated as a FIFO

bit 10 CSCNA: MUX A Channel Scan Enable bit

1 = Scan inputs are selected by the AD1CSSH/AD1CSSL registers as the MUX A input(s)

0 = Do not scan inputs

bit 9-8 **Unimplemented:** Read as '0'

bit 7 **BUFS**: Buffer Fill Status bit⁽¹⁾

1 = A/D is filling the upper half of the buffer; user should access data in the lower half

0 = A/D is filling the lower half of the buffer; user should access data in the upper half

bit 6-2 SMPI<4:0>: Interrupt Sample/DMA Increment Rate Select bits(2)

When DMAEN = 1:

11111 = Increment the DMA address after completion of the 32nd sample/conversion operation

11110 = Increment the DMA address after completion of the 31st sample/conversion operation

• • •

00001 = Increment the DMA address after completion of the 2nd sample/conversion operation

00000 = Increment the DMA address after completion of each sample/conversion operation

When DMAEN = 0:

11111 = Interrupts at the completion of conversion for each 32nd sample

11110 = Interrupts at the completion of conversion for each 31st sample

• • •

00001 = Interrupts at the completion of conversion for every other sample

00000 = Interrupts at the completion of conversion for each sample

Note 1: Applicable only when the buffer is used in FIFO mode (BUFREGEN = 0). In addition, BUFS is only used when BUFM = 1 and DMAEN = 0 (AD1CON1<11>), if implemented in the specific device family.

2: In devices where DMAEN (AD1CON1<11>) is unimplemented, the SMPIx bits always select the number of sample/conversions per each interrupt.

PIC24F Family Reference Manual

Register 51-2: AD1CON2: A/D Control Register 2 (Continued)

bit 1 **BUFM:** Buffer Fill Mode Select bit⁽¹⁾

- 1 = Starts buffer filling at AD1BUF0 on first interrupt and AD1BUF(n/2) on next interrupt (Split Buffer mode)
- 0 = Starts filling buffer at address, ADCBUF0, and each sequential address on successive interrupts (FIFO mode)
- bit 0 ALTS: Alternate Input Sample Mode Select bit
 - 1 = Uses channel input selects for Sample A on first sample and Sample B on the next sample
 - 0 = Always uses channel input selects for Sample A
- **Note 1:** Applicable only when the buffer is used in FIFO mode (BUFREGEN = 0). In addition, BUFS is only used when BUFM = 1 and DMAEN = 0 (AD1CON1<11>), if implemented in the specific device family.
 - 2: In devices where DMAEN (AD1CON1<11>) is unimplemented, the SMPIx bits always select the number of sample/conversions per each interrupt.

Register 51-3: AD1CON3: A/D Control Register 3

| R/W-0 | R-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 |
|--------|--------|-----------------------|-------|-------|-------|-------|-------|
| ADRC | EXTSAM | PUMPEN ⁽¹⁾ | SAMC4 | SAMC3 | SAMC2 | SAMC1 | SAMC0 |
| bit 15 | | | | | | | bit 8 |

| R/W-0 |
|-------|-------|-------|-------|-------|-------|-------|-------|
| ADCS7 | ADCS6 | ADCS5 | ADCS4 | ADCS3 | ADCS2 | ADCS1 | ADCS0 |
| bit 7 | | | | | | | bit 0 |

| Legend: | | | |
|-------------------|------------------|-----------------------------|--------------------|
| R = Readable bit | W = Writable bit | U = Unimplemented bit, read | d as '0' |
| -n = Value at POR | '1' = Bit is set | '0' = Bit is cleared | x = Bit is unknown |

bit 15 ADRC: A/D Conversion Clock Source bit 1 = RC clock 0 = Clock derived from system clock bit 14 **EXTSAM:** Extended Sampling Time bit 1 = A/D is still sampling after SAMP = 0 0 = A/D is finished sampling bit 13 **PUMPEN:** Charge Pump Enable bit⁽¹⁾ 1 = Charge pump for switches is enabled 0 = Charge pump for switches is disabled **SAMC<4:0>:** Auto-Sample Time Select bits bit 12-8 11111 = 31 TAD 00001 **= 1 T**AD 00000 = 0 TAD bit 7-0 ADCS<7:0>: A/D Conversion Clock Select bits 11111111 = Reserved 01000000 $001111111 = 64 \cdot \text{TCY} = \text{TAD}$ 00000001 = 2 · TCY = TAD 00000000 = Tcy = Tad

Note 1: This feature is available on select devices only.

PIC24F Family Reference Manual

Register 51-4: AD1CON4: A/D Control Register 4⁽¹⁾

| U-0 | U-0 | U-0 | U-0 | U-0 | U-0 | U-0 | U-0 |
|--------|-----|-----|-----|-----|-----|-----|-------|
| _ | _ | _ | _ | _ | _ | _ | _ |
| bit 15 | | | | | | | bit 8 |

| U-0 | U-0 | U-0 | U-0 | U-0 | R/W-0 | R/W-0 | R/W-0 |
|-------|-----|-----|-----|-----|-----------------------|-----------------------|-----------------------|
| _ | _ | _ | _ | _ | DMABL2 ⁽²⁾ | DMABL1 ⁽²⁾ | DMABL0 ⁽²⁾ |
| bit 7 | | | | | | | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-3 Unimplemented: Read as '0'

bit 2-0 DMABL<2:0>: DMA Buffer Size Select bits⁽²⁾

111 = Allocates 128 words of buffer to each analog input

110 = Allocates 64 words of buffer to each analog input

101 = Allocates 32 words of buffer to each analog input

100 = Allocates 16 words of buffer to each analog input

011 = Allocates 8 words of buffer to each analog input

010 = Allocates 4 words of buffer to each analog input

001 = Allocates 2 words of buffer to each analog input

000 = Allocates 1 word of buffer to each analog input

Note 1: AD1CON4 is not implemented on all devices. For more information, refer to the specific device data sheet.

2: The DMABL<2:0> bits are only used when AD1CON1<11> = 1; otherwise, their value is ignored.

Register 51-5: AD1CON5: A/D Control Register 5

| R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | U-0 | R/W-0 | R/W-0 |
|--------|-------|--------|----------------------|-----------------------|-----|-----------------------|-----------------------|
| ASEN | LPEN | CTMREQ | BGREQ ⁽¹⁾ | VRSREQ ⁽¹⁾ | _ | ASINT1 ⁽²⁾ | ASINTO ⁽²⁾ |
| bit 15 | | | | | | | bit 8 |

| U-0 | U-0 | U-0 | U-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 |
|-------|-----|-----|-----|-------|-------|-------|-------|
| _ | _ | _ | _ | WM1 | WM0 | CM1 | CM0 |
| bit 7 | | | | | | | bit 0 |

| Legend: | | | |
|-------------------|------------------|----------------------------|--------------------|
| R = Readable bit | W = Writable bit | U = Unimplemented bit, rea | d as '0' |
| -n = Value at POR | '1' = Bit is set | '0' = Bit is cleared | x = Bit is unknown |

bit 15 ASEN: Auto-Scan Enable bit

1 = Auto-Scan is enabled

0 = Auto-Scan is disabld

bit 14 LPEN: Low-Power Enable bit

1 = Low power is enabled after scan0 = Full power is enabled after scan

bit 13 CTMREQ: CTMU Request bit

1 = CTMU is enabled when the A/D is enabled and active

0 = CTMU is not enabled by the A/D

bit 12 **BGREQ:** Band Gap Request bit⁽¹⁾

1 = Band gap is enabled when the A/D is enabled and active

0 = Band gap is not enabled by the A/D

bit 11 **VRSREQ:** VREG Scan Request bit⁽¹⁾

1 = On-chip regulator is enabled when the A/D is enabled and active

0 = On-chip regulator is not enabled by the A/D

bit 10 Unimplemented: Read as '0'

bit 9-8 ASINT<1:0>: Auto-Scan (Threshold Detect) Interrupt Mode bits(2)

11 = Interrupt after Threshold Detect sequence is completed and a valid compare has occurred

10 = Interrupt after valid compare has occurred

01 = Interrupt after Threshold Detect sequence is completed

00 = No interrupt

bit 7-4 Unimplemented: Read as '0'

bit 3-2 WM<1:0>: Write Mode bits

11 = Reserved

10 = Auto-compare only (conversion results are not saved, but interrupts are generated when a valid match occurs, as defined by the CMx and ASINTx bits)

01 = Convert and save (conversion results saved to locations as determined by register bits when a match occurs, as defined by the CMx bits)

00 = Legacy operation (conversion data saved to location determined by buffer register bits)

Note 1: These bits are not implemented in all devices.

2: The ASINTx bits setting only takes effect when ASEN = 1 (AD1CON5<15>) and DMAEN = 0 (AD1CON1<11>). When DMAEN = 1, an interrupt is generated on every successful write to the ADCRESDMA register (where implemented); otherwise, interrupt generation is governed by the SMPI<4:0> field.

PIC24F Family Reference Manual

Register 51-5: AD1CON5: A/D Control Register 5 (Continued)

- bit 1-0 CM<1:0>: Compare Mode bits
 - 11 = Outside Window mode (valid match occurs if the conversion result is outside of the window defined by the corresponding buffer pair)
 - 10 = Inside Window mode (valid match occurs if the conversion result is inside the window defined by the corresponding buffer pair)
 - 01 = Greater Than mode (valid match occurs if the result is greater than value in the corresponding buffer register)
 - 00 = Less Than mode (valid match occurs if the result is less than value in the corresponding buffer register)
- Note 1: These bits are not implemented in all devices.
 - 2: The ASINTx bits setting only takes effect when ASEN = 1 (AD1CON5<15>) and DMAEN = 0 (AD1CON1<11>). When DMAEN = 1, an interrupt is generated on every successful write to the ADCRESDMA register (where implemented); otherwise, interrupt generation is governed by the SMPI<4:0> field.

Register 51-6: AD1CHS: A/D Sample Select Register

| R/W-0 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| CH0NB2 | CH0NB1 | CH0NB0 | CH0SB4 | CH0SB3 | CH0SB2 | CH0SB1 | CH0SB0 |
| bit 15 | | | | | | | bit 8 |

| R/W-0 |
|--------|--------|--------|--------|--------|--------|--------|--------|
| CH0NA2 | CH0NA1 | CH0NA0 | CH0SA4 | CH0SA3 | CH0SA2 | CH0SA1 | CH0SA0 |
| bit 7 | | | | | | | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-13 CH0NB<2:0>: Sample B Channel 0 Negative Input Select bits

The number of implemented inputs, and the bit combinations assigned to them, vary between device families. In general, device analog ground and/or the negative external voltage reference (VREF-) is assigned to '000'. Inputs from other external analog channels or internal references may be assigned to the other combinations. Refer to the specific device data sheet for a complete listing of implemented inputs for a particular device.

Any bit combinations not explicitly listed in the device data sheet are unimplemented. Using an unimplemented channel for a conversion will produce unpredictable results.

bit 12-8 CH0SB<4:0>: S/H Amplifier Positive Input Select for MUX B Multiplexer Setting bits

The number of implemented inputs, and the bit combinations assigned to them, vary significantly between device families. In general, external analog inputs are sequentially assigned from '00000', starting with AN0, potentially up to AN31 ('11111').

If 32 external inputs are not implemented, inputs for internal band gap references, external voltage references, and other analog modules, such as the CTMU, are implemented following the external analog channels. Refer to the specific device data sheet for a complete listing of implemented inputs for a particular device.

If a sequential input is unimplemented, its corresponding bit value is also unimplemented. Also, any bit combinations not explicitly listed in the device data sheet are unimplemented. Using an unimplemented channel for a conversion will produce unpredictable results.

bit 7-5 **CH0NA<2:0>:** Sample A Channel 0 Negative Input Select bits

Same definitions as for CH0NB<2:0>.

bit 4-0 CH0SA<4:0>: Sample A Channel 0 Positive Input Select bits

Same definitions as for CH0SB<4:0>.

Register 51-7: AD1CHITH: A/D Scan Compare Hit Register (High Word)

| R/W-0 |
|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|
| CHH31 ⁽¹⁾ | CHH30 ⁽¹⁾ | CHH29 ⁽¹⁾ | CHH28 ⁽¹⁾ | CHH27 ⁽¹⁾ | CHH26 ⁽¹⁾ | CHH25 ⁽¹⁾ | CHH24 ⁽¹⁾ |
| bit 15 | | | | | | | bit 8 |

| R/W-0 |
|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|
| CHH23 ⁽¹⁾ | CHH22 ⁽¹⁾ | CHH21 ⁽¹⁾ | CHH20 ⁽¹⁾ | CHH19 ⁽¹⁾ | CHH18 ⁽¹⁾ | CHH17 ⁽¹⁾ | CHH16 ⁽¹⁾ |
| bit 7 | | | | | | | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 CHH<31:16>: A/D Compare Hit bits⁽¹⁾

If CM<1:0> = 11:

1 = A/D Result Buffer n has been written with data or a match has occurred

0 = A/D Result Buffer n has not been written with data

For All Other Values of CM<1:0>:

1 = A match has occurred on A/D Result Channel n

0 = No match has occurred on A/D Result Channel n

Note 1: The actual number of channels available depends on which channels are implemented on a specific device. Refer to the device data sheet for details. Unimplemented channels are read as '0'.

Register 51-8: AD1CHITL: A/D Scan Compare Hit Register (Low Word)

| R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 |
|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|---------------------|---------------------|
| CHH15 ⁽¹⁾ | CHH14 ⁽¹⁾ | CHH13 ⁽¹⁾ | CHH12 ⁽¹⁾ | CHH11 ⁽¹⁾ | CHH10 ⁽¹⁾ | CHH9 ⁽¹⁾ | CHH8 ⁽¹⁾ |
| bit 15 | | | | | | | bit 8 |

| R/W-0 |
|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|
| CHH7 ⁽¹⁾ | CHH6 ⁽¹⁾ | CHH5 ⁽¹⁾ | CHH4 ⁽¹⁾ | CHH3 ⁽¹⁾ | CHH2 ⁽¹⁾ | CHH1 ⁽¹⁾ | CHH0 ⁽¹⁾ |
| bit 7 | | | | | | | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 CHH<15:0>: A/D Compare Hit bits⁽¹⁾

<u>If CM<1:0> = 11:</u>

1 = A/D Result Buffer n has been written with data or a match has occurred

0 = A/D Result Buffer n has not been written with data

For All Other Values of CM<1:0>:

1 = A match has occurred on A/D Result Channel n

0 = No match has occurred on A/D Result Channel n

Note 1: The actual number of channels available depends on which channels are implemented on a specific device; refer to the specific device data sheet for details. Unimplemented channels are read as '0'.

Register 51-9: AD1CSSH: A/D Input Scan Select Register (High Word)

| R/W-0 |
|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|
| CSS31 ⁽¹⁾ | CSS30 ⁽¹⁾ | CSS29 ⁽¹⁾ | CSS28 ⁽¹⁾ | CSS27 ⁽¹⁾ | CSS26 ⁽¹⁾ | CSS25 ⁽¹⁾ | CSS24 ⁽¹⁾ |
| bit 15 | | | | | | | bit 8 |

| R/W-0 |
|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|
| CSS23 ⁽¹⁾ | CSS22 ⁽¹⁾ | CSS21 ⁽¹⁾ | CSS20 ⁽¹⁾ | CSS19 ⁽¹⁾ | CSS18 ⁽¹⁾ | CSS17 ⁽¹⁾ | CSS16 ⁽¹⁾ |
| bit 7 | | | | | | | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 CSS<31:16>: A/D Input Scan Selection bits⁽¹⁾

1 = Include corresponding channel for input scan

0 = Skip channel for input scan

Note 1: The actual number of channels available depends on which channels are implemented on a specific device; refer to the specific device data sheet for details. Unimplemented channels are read as '0'. Do not select unimplemented channels for sampling, as indeterminate results may be produced.

Register 51-10: AD1CSSL: A/D Input Scan Select Register (Low Word)

| R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 |
|----------------------|----------------------|----------------------|----------------------|----------------------|----------------------|---------------------|---------------------|
| CSS15 ⁽¹⁾ | CSS14 ⁽¹⁾ | CSS13 ⁽¹⁾ | CSS12 ⁽¹⁾ | CSS11 ⁽¹⁾ | CSS10 ⁽¹⁾ | CSS9 ⁽¹⁾ | CSS8 ⁽¹⁾ |
| bit 15 | | | | | | | bit 8 |

| R/W-0 |
|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|---------------------|
| CSS7 ⁽¹⁾ | CSS6 ⁽¹⁾ | CSS5 ⁽¹⁾ | CSS4 ⁽¹⁾ | CSS3 ⁽¹⁾ | CSS2 ⁽¹⁾ | CSS1 ⁽¹⁾ | CSS0 ⁽¹⁾ |
| bit 7 | | | | | | | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 CSS<15:0>: A/D Input Scan Selection bits⁽¹⁾

1 = Include corresponding channel for input scan

0 = Skip channel for input scan

Note 1: The actual number of channels available depends on which channels are implemented on a specific device; refer to the specific device data sheet for details. Unimplemented channels are read as '0'. Do not select unimplemented channels for sampling, as indeterminate results may be produced.

PIC24F Family Reference Manual

Register 51-11: AD1CTMENH: CTMU Enable Register (High Word)

| R/W-0 |
|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|
| CTMEN31 ⁽¹⁾ | CTMEN30 ⁽¹⁾ | CTMEN29 ⁽¹⁾ | CTMEN28 ⁽¹⁾ | CTMEN27 ⁽¹⁾ | CTMEN26 ⁽¹⁾ | CTMEN25 ⁽¹⁾ | CTMEN24 ⁽¹⁾ |
| bit 15 | | | | | | | bit 8 |

| R/W-0 |
|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|------------------------|
| CTMEN23 ⁽¹⁾ | CTMEN22 ⁽¹⁾ | CTMEN21 ⁽¹⁾ | CTMEN20 ⁽¹⁾ | CTMEN19 ⁽¹⁾ | CTMEN18 ⁽¹⁾ | CTMEN17 ⁽¹⁾ | CTMEN16 ⁽¹⁾ |
| bit 7 | | | | | | | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 CTMUEN<31:16>: CTMU Enabled During Conversion bits (1)

1 = CTMU is enabled and connected to the selected channel during conversion

0 = CTMU is not connected to this channel

Note 1: The actual number of channels available depends on which channels are implemented on a specific device; refer to the specific device data sheet for details. Unimplemented channels are read as '0'.

Register 51-12: AD1CTMENL: CTMU Enable Register (Low Word)

| R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 | R/W-0 |
|------------------------|------------------------|------------------------|------------------------|-------------------------|------------------------|-----------------------|-----------------------|
| CTMEN15 ⁽¹⁾ | CTMEN14 ⁽¹⁾ | CTMEN13 ⁽¹⁾ | CTMEN12 ⁽¹⁾ | CTMUEN11 ⁽¹⁾ | CTMEN10 ⁽¹⁾ | CTMEN9 ⁽¹⁾ | CTMEN8 ⁽¹⁾ |
| bit 15 | | | | | | | bit 8 |

| R/W-0 |
|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|
| CTMEN7 ⁽¹⁾ | CTMEN6 ⁽¹⁾ | CTMEN5 ⁽¹⁾ | CTMEN4 ⁽¹⁾ | CTMEN3 ⁽¹⁾ | CTMEN2 ⁽¹⁾ | CTMEN1 ⁽¹⁾ | CTMEN0 ⁽¹⁾ |
| bit 7 | | | | | | | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 CTMUEN<15:0>: CTMU Enabled During Conversion bits (1)

1 = CTMU is enabled and connected to the selected channel during conversion

0 = CTMU is not connected to this channel

Note 1: The actual number of channels available depends on which channels are implemented on a specific device; refer to the specific device data sheet for details. Unimplemented channels are read as '0'.

51.4 A/D MODULE CONFIGURATION

All of the registers described in the previous section must be configured for module operation to be fully defined. An effective approach is first, to describe the signals and sequences for the particular application. Typically, it is an iterative process to assign signals to port pins, to establish timing methods and to organize a scanning scheme, as well as to integrate the whole process with the software design.

The various configuration and control functions of the module are distributed throughout the module's six control registers. Control functions can be broadly sorted into four groups: input, timing, conversion and output. Table 51-1 shows the register location of control or status bits by register.

Table 51-1: A/D Module Functions by Registers and Bits

| A/D Function | Register(s) | Specific Bits |
|--------------|-------------|--|
| Input | AD1CON2 | PVCFG<1:0>, NVCFG, OFFCAL, CSCNA, ALTS |
| | AD1CON5 | CTMREQ, BGREQ, VRSREQ |
| | AD1CHS | CH0NB<2:0>, CH0SB<4:0>, CH0NA<2:0>, CH0SA<4:0> |
| | AD1CSSH/L | CSS<31:16>, CSS<15:0> ⁽¹⁾ |
| | AD1CTMENH/L | CTMEN<31:16>, CTMEN<15:0>(1) |
| Conversion | AD1CON1 | ADON, ADSIDL, SSRC<3:0>, ASAM, SAMP, DONE |
| | AD1CON2 | SMPI<4:0> |
| | AD1CON3 | EXTSAM |
| | AD1CON5 | ASEN, LPEN, ASINT<1:0> |
| Timing | AD1CON3 | ADRC, SAMC<4:0>, ADCS<7:0> |
| Output | AD1CON1 | FORM<1:0>, DMAEN, DMABM |
| | AD1CON2 | BUFS, BUFM, BUFREGEN |
| | AD1CON4 | DMABL<2:0> |
| | AD1CON5 | WM<1:0>, CM<1:0> |

Note 1: The number and location of implemented bits is device-specific. For more information, refer to the specific device data sheet.

Note: Do not write to the SSRCx, BUFS, SMPIx, BUFM and ALTS bits, or the AD1CON3 and AD1CSSL registers, while ADON = 1; otherwise, indeterminate conversion data may result.

The following steps should be followed for performing an A/D conversion.

- 1. Configure the A/D module:
 - Select the output resolution (if configurable)
 - · Select the voltage reference source to match the expected range on analog inputs
 - · Select the analog conversion clock to match the desired data rate with a processor clock
 - · Determine how sampling will occur
 - · Set the multiplexer input assignments
 - Select the desired sample/conversion sequence
 - · Select the output data format
 - · Select the output value destination
 - Select the number of readings per interrupt
- 2. Configure the A/D interrupt (if required):
 - Clear the AD1IF bit
 - · Select the A/D interrupt priority
- 3. Turn on the A/D module.

The options for each configuration step are described in the subsequent sections.

51.4.1 Selecting the Resolution

Most versions of the A/D module will have a fixed conversion resolution of either 12 bits (the majority) or 10 bits. Where configuration is permitted, the MODE12 bit (AD1CON1<10>) controls output resolution. Setting this bit selects 12-bit resolution.

51.4.2 Selecting the Voltage Reference Source

The voltage references for A/D conversions are selected using the PVCFG<1:0> and NVCFG control bits (AD1CON2<15:13>). The upper voltage reference (VR+) may be AVDD, the external VREF+ or an internal band gap reference voltage. The lower voltage reference (VR-) may be AVSS or the VREF- input pin. The available options vary between device families.

The external voltage reference pins may be shared with the AN0 and AN1 inputs on low pin count devices. The A/D Converter can still perform conversions on these pins when they are shared with the VREF+ and VREF- input pins.

The voltages applied to the external reference pins must meet certain specifications. Refer to the device data sheet for further details.

51.4.3 Selecting the A/D Conversion Clock

The A/D Converter has a maximum rate at which conversions may be completed. An analog module clock, TAD, controls the conversion timing. The A/D conversion requires 14 clock periods (14 TAD) for a 12-bit conversion and 12 clock periods (12 TAD) for a 10-bit conversion. The A/D clock is derived from the device instruction clock.

The period of the A/D conversion clock is software selected using a 6-bit counter. There are 64 possible options for TAD, specified by the ADCSx bits in the AD1CON3 register. Equation 51-1 gives the TAD value as a function of the ADCSx control bits and the device instruction cycle clock period, Tcy. For correct A/D conversions, the A/D conversion clock (TAD) must be selected to ensure a minimum TAD time, as specified by the device family data sheet.

Equation 51-1: A/D Conversion Clock Period

$$TAD = TCY (ADCSx + 1)$$

$$ADCSX = \frac{TAD}{TCY} - 1$$

Note: Based on Tcy = 2/Fosc; Doze mode and PLL are disabled.

The A/D Converter also has its own dedicated RC clock source that can be used to perform conversions. The A/D RC clock source should be used when conversions are performed while the device is in Sleep mode. The RC oscillator is selected by setting the ADRC bit (AD1CON3<15>). When the ADRC bit is set, the ADCSx bits have no effect on A/D operation.

51.4.4 Configuring Analog Port Pins

The A/D module does not have an internal provision to configure port pins for analog operation. Instead, input pins are configured as analog inputs through the Analog Select registers (ANSn, where 'n' is the port name). A pin is configured as an analog input when the corresponding ANSn bit is set. By default, pins with multiplexed analog and digital functions are configured as analog pins on device Reset.

For external analog inputs, both the ANSn register and the corresponding TRIS register bits control the operation of the A/D port pins. The port pins that will function as analog inputs must also have their corresponding TRIS bits set, specifying the pins as inputs. After a device Reset, all TRIS bits are set. If the I/O pin associated with an A/D channel is configured as a digital output (TRIS bit is cleared), while the pin is configured for Analog mode, the port digital output level (VOH or VOL) will be converted.

Note 1: When reading a PORT register, any pin configured as an analog input reads as '0'.

2: Analog levels on any pin that is defined as a digital input may cause the input buffer to consume current that is out of the device's specification.

51.4.5 Input Channel Selection

The A/D Converter incorporates two independent sets of input multiplexers (MUX A and MUX B) that allow users to choose which analog channels are to be sampled. The inputs specified by the CH0SAx and CH0NAx bits are collectively called the MUX A inputs. The inputs specified by the CH0SBx and CH0NBx bits are collectively called the MUX B inputs.

Functionally, MUX A and MUX B are very similar to each other. Both multiplexers allow any of the analog input channels to be selected for individual sampling and allow selection of a negative reference source for differential signals. In addition, MUX A can be configured for sequential analog channel scanning. This is discussed in more detail in Section 51.4.5.1 "Configuring MUX A and MUX B Inputs" and Section 51.4.5.3 "Scanning Through Several Inputs".

Note: Different PIC24F devices will have different numbers of analog inputs. Verify the analog input availability against the particular device's data sheet.

51.4.5.1 CONFIGURING MUX A AND MUX B INPUTS

The user may select any one of up to 32 inputs available to the A/D Converter as the positive input of the S/H amplifier. For MUX A, the CH0SA<4:0> bits (AD1CHS<4:0>) normally select the analog channel for the positive input. For MUX B, the positive channel is selected by the CH0SB<4:0> bits (AD1CHS<12:8>).

All of the external analog channels are available as positive inputs. In addition to the external inputs, these may also include device supply voltage (AVDD), the logic core supply voltage (VDDCORE), the internal band gap voltage (VBG) and/or multiples or fractions of VBG. One or more additional input channels are used for the CTMU. These selections leave the A/D disconnected from all other inputs. The options vary by device family; refer to the specific device data sheet for details

The CTMU input is selected by the AD1CTMENH/L registers. Setting a particular bit in one of these registers effectively assigns the analog output from the CTMU to the corresponding A/D input channel, automatically enabling the CTMU. Many devices will already have a CH0SAx bit combination designated for use of the CTMU. This setting disconnects the converter from any other load. This channel should be the one selected by the appropriate AD1CTMEN bit. If another channel is selected, verify that any other analog sources are disconnected from that channel; otherwise, erroneous readings may result.

For the negative (inverting) input of the amplifier, the user has up to eight options, selected by the CH0NA<2:0> and CH0NB<2:0> bits (AD1CHS<7:5> and AD1CHS<15:13>, respectively). Options typically include the device ground (AVss), the current VR- source designated by the NVCFG bit (AD1CON2<13>), and one or more of the external analog input channels. As with the non-inverting inputs, the options vary by device family.

51.4.5.2 ALTERNATING MUX A AND MUX B INPUT SELECTIONS

By default, the A/D Converter only samples and converts the inputs selected by MUX A. The ALTS bit (AD1CON2<0>) enables the module to alternate between two sets of inputs selected by MUX A and MUX B during successive samples.

If the ALTS bit is '0', only the inputs specified by the CH0SAx and CH0NAx bits are selected for sampling. When the ALTS bit is '1', the module will alternate between the MUX A inputs on one sample and the MUX B inputs on the subsequent sample.

If the ALTS bit is '1' on the first sample/convert sequence, the inputs specified by the CH0SAx and CH0NAx bits are selected for sampling. On the next sample/convert sequence, the inputs specified by the CH0SBx and CH0NBx bits are selected for sampling. This pattern repeats for subsequent sample conversion sequences.

51.4.5.3 SCANNING THROUGH SEVERAL INPUTS

When using MUX A to select analog inputs, the A/D module has the ability to scan multiple analog channels. When the CSCNA bit (AD1CON2<10>) is set, the CH0SA bits are ignored and the channels specified by the AD1CSSL register are sequentially sampled.

Each bit in the AD1CSSL register and AD1CSSH register (when implemented) corresponds to one of the analog channels. If a bit in the AD1CSSL or AD1CSSH register is set, the corresponding analog channel is included in the scan sequence. Inputs are always scanned from lower to higher numbered inputs, starting at the first selected channel after each interrupt occurs.

- **Note 1:** If the number of scanned inputs selected is greater than the number of samples taken per interrupt, the higher numbered inputs will not be sampled.
 - 2: If the CTMU channel is to be included in a scan operation, verify that the proper analog input channel is selected and that the AD1CTMEN register(s) are correctly configured. For more information, see Section 51.4.5.1 "Configuring MUX A and MUX B Inputs".

The AD1CSSH/L registers' bits specify the positive input of the channel. The CH0NAx bits still select the negative input of the channel during scanning.

Scanning is only available on the MUX A input selection. The MUX B input selection, as specified by the CH0SBx bits, will still select the alternating input. When alternated sampling between MUX A and MUX B is selected (ALTS = 1), the input will alternate between a set of scanning inputs specified by the AD1CSSH/L registers, and a fixed input specified by the CH0SBx bits.

Automatic scanning can be used in conjunction with the Threshold Detect feature to determine if one or more analog channels meet a predetermined set of conditions while the CPU is inactive. This is described in detail in **Section 51.10** "Threshold Detect Operation".

51.4.5.4 INTERNAL CHANNELS IN LOW-POWER MODES

While the A/D module can scan and convert analog inputs in low-power modes, some internal analog inputs may be unavailable in Sleep mode. The main examples are the CTMU module, the internal band gap voltage source and the on-chip voltage regulator (for those devices that include one). The A/D module provides a method to make these resources available automatically through the CTMREQ, BGREQ and VRSREQ bits (AD1CON5<13:11>, respectively). Setting one or more of these bits causes the corresponding internal analog source(s) to become active during a channel scan.

The CTMREQ bit is available on all devices. The BGREQ bit is available on those devices that make the internal band gap reference available to the A/D module as an input channel and/or as VREF+. The VRSREQ bit is only available in device families that use an on-chip voltage regulator.

51.4.6 Enabling the Module

When the ADON bit (AD1CON1<15>) is set, the module is fully powered and functional. When ADON is '0', the module is disabled. Although the digital and analog portions of the circuit are turned off for maximum current savings, the contents of all registers are maintained.

Conversion data stored in the ADC1BUF registers will also be maintained, including any threshold values stored by the user. It may be necessary to re-initialize these registers to their proper values before re-enabling the module.

When enabling the module by setting the ADON bit, the user must wait for the analog stages to stabilize. For the stabilization time, refer to **Section 51.18** "**Electrical Specifications**".

51.5 INITIALIZATION

Example 51-1 shows a simple initialization code example for the A/D module. Operation in Idle mode is disabled, output data is in unsigned fractional format, and AVDD and AVSS are used for VR+ and VR-. The start of sampling, as well as the start of conversion (conversion trigger), are performed directly in software. Scanning of inputs is disabled and an interrupt occurs after every sample/convert sequence (one conversion result) with only one channel (AN0) being converted. The A/D conversion clock is Tcy/2.

In this particular configuration, all 16 analog input pins are set up as analog inputs. It is important to note that with this A/D module, I/O pins are configured for analog or digital operation at the I/O port with the ANSn Analog Select registers. The use of these registers is described in detail in the I/O Port chapter of the specific device data sheet.

This example shows one method of controlling a sample/convert sequence by manually setting and clearing the SAMP bit (AD1CON1<1>). This method, among others, is more fully discussed in Section 51.6 "Controlling the Sampling Process" and Section 51.7 "Controlling the Conversion Process".

Example 51-1: A/D Initialization Code Example

```
AD1CON1 = 0x2200;
                      // Configure sample clock source
                      // and conversion trigger mode.
                      // Unsigned Fraction format (FORM<1:0>=10),
                      // Manual conversion trigger (SSRC<3:0>=0000),
                      // Manual start of sampling (ASAM=0),
                      // No operation in Idle mode (ADSIDL=1),
                      // S/H in Sample (SAMP = 1)
AD1CON2 = 0;
                      // Configure A/D voltage reference
                      // and buffer fill modes.
                      // Vr+ and Vr- from AVdd and AVss(PVCFG<1:0>=00, NVCFG=0),
                      // Inputs are not scanned,
                      // Interrupt after every sample
AD1CON3 = 0;
                      // Configure sample time = 1Tad,
                      // A/D conversion clock as Tcy
AD1CHS = 0;
                      // Configure input channels,
                      // S/H+ input is ANO,
                      // S/H- input is Vr- (AVss).
AD1CSSL = 0;
                     // No inputs are scanned.
IFSObits.AD1IF = 0;
                    // Clear A/D conversion interrupt.
// Configure A/D interrupt priority bits (AD1IP<2:0>) here, if
// required. Default priority level is 4.
IECObits.AD1IE = 1; // Enable A/D conversion interrupt
AD1CON1bits.ADON = 1; // Turn on A/D
AD1CON1bits.SAMP = 1; // Start sampling the input
Delay();
                     // Ensure the correct sampling time has elapsed
                      // before starting conversion.
AD1CON1bits.SAMP = 0; // End A/D sampling and start conversion
// Example code for A/D ISR:
void __attribute__ ((__interrupt__)) _ADC1Interrupt(void)
   IFSObits.AD1IF = 0;
```

51.6 CONTROLLING THE SAMPLING PROCESS

51.6.1 Manual Sampling

Setting the SAMP bit (AD1CON1<1>) while the ASAM bit (AD1CON1<2>) is clear causes the A/D to begin sampling. Clearing the SAMP bit ends sampling and automatically begins the conversion; however, there must be a sufficient delay between setting and clearing SAMP for the sampling process to start (tPss, Parameter AD61). Sampling will not resume until the SAMP bit is once again set. For an example, see Figure 51-4.

51.6.2 Automatic Sampling

Setting the ASAM bit causes the A/D to automatically begin sampling after a conversion has been completed. One of several options can be used as an event to end sampling and complete the conversions. Sampling will continue on the next selected channel after the conversion in progress has completed. For an example, see Figure 51-5.

51.6.3 Monitoring Sample Status

The SAMP bit indicates the sampling state of the A/D. Generally, when the SAMP bit clears, indicating the end of sampling, the DONE bit is automatically cleared to indicate the start of conversion. If SAMP is '0' while DONE is '1', the A/D is in an inactive state.

51.6.4 Aborting a Sample

While in Manual Sampling mode, clearing the SAMP bit will terminate sampling. If SSRC<3:0> = 0000, it may also start a conversion automatically.

Clearing the ASAM bit while in Automatic Sampling mode will not terminate an ongoing sample/convert sequence; however, sampling will not automatically resume after a subsequent conversion.

51.7 CONTROLLING THE CONVERSION PROCESS

The conversion trigger source will terminate sampling and start a selected sequence of conversions. The SSRC<3:0> bits (AD1CON1<7:4>) select the source of the conversion trigger.

- **Note 1:** The available conversion trigger sources may vary depending on the PIC24F device variant. Refer to the specific device data sheet for the available conversion trigger sources.
 - 2: The SSRCx selection bits should not be changed when the A/D module is enabled. If the user wishes to change the conversion trigger source, disable the A/D module first by clearing the ADON bit (AD1CON1<15>).


51.7.1 Manual Control

When SSRC<3:0> = 0000, the conversion trigger is under software control. Clearing the SAMP bit (AD1CON1<1>) starts the conversion sequence.

Figure 51-4 is an example where setting the SAMP bit initiates sampling, and clearing the SAMP bit terminates sampling and starts conversion. The user software must time the setting and clearing of the SAMP bit to ensure adequate sampling time of the input signal.

Figure 51-5 is an example where setting the ASAM bit initiates automatic sampling, and clearing the SAMP bit terminates sampling and starts conversion. After the conversion completes, the module sets the SAMP bit and returns to the sample state. The user software must time the clearing of the SAMP bit to ensure adequate sampling time of the input signal, understanding that the time since previously clearing the SAMP bit includes the conversion time, which immediately follows, as well as the next sampling time.






Example 51-2: Converting One Channel, Manual Sample Start, Manual Conversion Start Code

```
int ADCValue;
     = 0x0001;
                                // AN2 as analog, all other pins are digital
ANSB
AD1CON1 = 0x0000;
                                // SAMP bit = 0 ends sampling and starts converting
AD1CHS = 0 \times 0002;
                                // Connect AN2 as S/H+ input
                                // in this example AN2 is the input
AD1CSSL = 0;
AD1CON3 = 0 \times 0002;
                                // Manual Sample, Tad = 3Tcy
AD1CON2 = 0;
AD1CON1bits.ADON = 1;
                                 // turn ADC ON
while (1)
                                 // repeat continuously
   AD1CON1bits.SAMP = 1;
                                // start sampling...
   Delay();
                                // Ensure the correct sampling time has elapsed
                               // before starting conversion.
   AD1CON1bits.SAMP = 0; // start converting
   while (!AD1CON1bits.DONE){}; // conversion done?
   ADCValue = ADC1BUF0;
                         // yes then get ADC value
```

Figure 51-5: Converting One Channel, Automatic Sample Start, Manual Conversion Start



51.7.2 Clocked Conversion Trigger


When ADRC = 1, the conversion trigger is under A/D clock control. The SAMCx bits (AD1CON3<12:8>) select the number of TAD clock cycles between the start of sampling and the start of conversion. After the start of sampling, the module will count a number of TAD clocks specified by the SAMCx bits. The SAMCx bits must always be programmed for at least 1 clock cycle to ensure sampling requirements are met.

Equation 51-2: Clocked Conversion Trigger Time

```
TSMP = SAMC < 4:0> * TAD
```

Figure 51-6 shows how to use the clocked conversion trigger with the sampling started by the user software.

Figure 51-6: Converting One Channel, Manual Sample Start, TAD-Based Conversion Start



Example 51-3: Converting One Channel, Manual Sample Start, TAD-Based Conversion Start Code


```
int ADCValue;
ANSB
       = 0x1000;
                                     // all PORTB = Digital; RB12 = analog
AD1CON1 = 0x00E0;
                                      // SSRC<2:0> = 111 implies internal counter ends sampling
                                     // and starts converting.
AD1CHS = 0x000C;
                                     // Connect AN12 as S/H input.
                                      // in this example AN12 is the input
AD1CSSL = 0;
AD1CON3 = 0x1F02;
                                     // Sample time = 31Tad, Tad = 3Tcy
AD1CON2 = 0;
AD1CON1bits.ADON = 1;
                                     // turn ADC ON
while (1)
                                     // repeat continuously
   AD1CON1bits.SAMP = 1;
                                     // start sampling, then after 31Tad go to conversion
   while (!AD1CON1bits.DONE){};
                                     // conversion done?
   ADCValue = ADC1BUF0;
                                     // yes then get ADC value
                                     // repeat
```

51.7.2.1 FREE-RUNNING SAMPLE CONVERSION SEQUENCE

Using the Auto-Convert Conversion Trigger mode (SSRC<3:0> = 0111), in combination with the Auto-Sample Start mode (ASAM = 1), allows the A/D module to schedule sample/conversion sequences with no intervention by the user or other device resources. This "Clocked" mode, shown in Figure 51-7, allows continuous data collection after module initialization.

Note that all timing in this mode scales with TAD, either from the A/D internal RC clock or from TCY (as prescaled by the ADCS<7:0> bits). In both cases, the SAMC<4:0> bits set the number of TAD clocks in TSAMP. TCONV is fixed at 12 TAD.

Figure 51-7: Converting One Channel, Auto-Sample Start, TAD-Based Conversion Start



Example 51-4: Converting One Channel, Auto-Sample Start, TAD-Based Conversion Start Code

```
int ADCValue, count;
int *ADC16Ptr;
       = 0x0001;
                                               // AN2 as analog, all other pins are digital
AD1CON1 = 0x00E0;
                                               // SSRC bit = 111 implies internal counter
                                               // ends sampling and starts converting.
AD1CHS = 0 \times 0002;
                                               // Connect RB2/AN2 as CH0 input..
                                               // in this example RB2/AN2 is the input
AD1CSSL = 0;
AD1CON3 = 0 \times 0 = 0;
                                               // Sample time = 15Tad, Tad = Tcy
                                               // Set AD1IF after every 2 samples
AD1CON2 = 0 \times 0004;
AD1CON1bits.ADON = 1;
                                               // turn ADC ON
while (1)
                                               // repeat continuously
   ADCValue = 0;
                                               // clear variable
    ADC16Ptr = &ADC1BUF0;
                                               // initialize ADC1BUF pointer
    IFSObits.AD1IF = 0;
                                               // clear ADC interrupt flag
    AD1CON1bits.ASAM = 1;
                                               // auto start sampling for 31Tad
                                               // then go to conversion
    while (!IFSObits.AD1IF){};
                                               // conversion done?
    AD1CON1bits.ASAM = 0;
                                               // yes then stop sample/convert
    for(count = 0; count < 2; count++)</pre>
                                               // average the 2 ADC value
       ADCValue = ADCValue + *ADC16Ptr++;
    ADCValue = ADCValue >> 1;
                                               // repeat
```

51.7.2.2 SAMPLE TIME CONSIDERATIONS USING CLOCKED CONVERSION TRIGGER AND AUTOMATIC SAMPLING

The user must ensure the sampling time satisfies the sampling requirements, as outlined in **Section 51.12 "A/D Sampling Requirements"**. Assuming that the module is set for automatic sampling and using a clocked conversion trigger, the sampling interval is specified by the SAMCx bits.

51.7.3 Event Trigger Conversion Start

It is often desirable to synchronize the end of sampling and the start of conversion with some other time event. Depending on the device family, the A/D module has up to 16 sources available to use as a conversion trigger event. The event trigger is selected by the SSRC<3:0> bits (AD1CON1<7:4>).

As noted, the available event triggers vary between device families. Refer to the specific device data sheet for specific information. The examples that follow represent trigger sources that are implemented in most devices. Note that the SSRCx bit assignments may vary in some devices.

51.7.3.1 EXTERNAL INTO PIN TRIGGER

When SSRC<3:0> = 0001, the A/D conversion is triggered by an active transition on the INT0 pin. The pin may be programmed for either a rising edge input or a falling edge input.

51.7.3.2 GENERAL PURPOSE TIMER COMPARE TRIGGER

When SSRC<3:0> = 0010, the A/D is triggered by a match between the 32-bit timer pair, TMR3/TMR2, and the 32-bit combined Period register, PR3/PR2. The match causes the timer to generate a special A/D trigger event signal.

In some devices, this feature is also implemented for the TMR5/TMR4 timer pair. Refer to the specific device data sheet for details.

51.7.3.3 SYNCHRONIZING A/D OPERATIONS TO INTERNAL OR EXTERNAL EVENTS

The modes where an external event trigger pulse ends sampling and starts conversion may be used in combination with auto-sampling (ASAM = 1) to cause the A/D to synchronize the sample conversion events to the trigger pulse source. For example, in Figure 51-9, where SSRC<3:0> = 0010 and ASAM = 1, the A/D will always end sampling and start conversions synchronously with the timer compare trigger event. The A/D will have a sample conversion rate that corresponds to the timer comparison event rate.

51.7.3.4 SAMPLE TIME CONSIDERATIONS FOR AUTOMATIC SAMPLING/CONVERSION SEQUENCES

Different sample/conversion sequences provide different available sampling times for the S/H channel to acquire the analog signal. The user must ensure the sampling time satisfies the sampling requirements, as outlined in **Section 51.12 "A/D Sampling Requirements"**.

Assuming that the module is set for automatic sampling, and an external trigger pulse is used as the conversion trigger, the sampling interval is a portion of the trigger pulse interval. The sampling time is the trigger pulse period, less the time required to complete the conversion.

Equation 51-3: Calculating Available Sampling Time for Sequential Sampling

TSMP = Trigger Pulse Interval (TSEQ) – Conversion Time (TCONV) = TSEQ – TCONV







Figure 51-9: Auto-Sample Start, Conversion Trigger-Based Conversion Start



Example 51-5: Converting One Channel, Auto-Sample Start, Conversion Trigger-Based Conversion Start Code

```
int ADCValue;
ANSB = 0 \times 0001;
                                   // AN2 as analog, all other pins are digital
                                   // SSRC bit = 010 implies GP TMR3
AD1CON1 = 0 \times 0040;
                                   // compare ends sampling and starts converting.
AD1CHS = 0 \times 0002;
                                   // Connect AN2 as CH0 input...
                                   // in this example AN2 is the input
AD1CSSL = 0;
AD1CON3 = 0 \times 0000;
                                   // Sample time is TMR3, Tad = Tcy
AD1CON2 = 0 \times 0004;
                                   // Set AD1IF after 2 conversions
TMR3 = 0 \times 0000;
                                   // set TMR3 to time out every 125 ms
       = 0x3FFF;
T3CON = 0x8010;
AD1CON1bits.ADON = 1;
                                  // turn ADC ON
AD1CON1bits.ASAM = 1;
                                   // start auto sampling every 125 ms
while (1)
                                   // repeat continuously
   while (!IFSObits.AD1IF){};  // conversion done?
   ADCValue = ADC1BUF0;
                                   // yes then get first ADC value
   IFSObits.AD1IF = 0;
                                   // clear AD1IF
}
```

51.7.4 Monitoring Sample/Conversion Status

The DONE bit (AD1CON1<0>) indicates the conversion state of the A/D. Generally, when the SAMP bit clears, indicating the end of sampling, the DONE bit is automatically cleared to indicate the start of conversion. If SAMP is '0' while DONE is '1', the A/D is in an inactive state.

In some operational modes, the SAMP bit may also invoke and terminate sampling. In these modes, the DONE bit cannot be used to terminate conversions in progress.

51.7.5 Generating A/D Interrupts

The SMPI<4:0> bits (AD1CON2<6:2>) control the generation of the A/D Interrupt Flag, AD1IF. The A/D Interrupt Flag is set after the number of sample/conversion sequences is specified by the SMPIx bits, after the start of sampling, and continues to recur after that number of samples. The value specified by the SMPIx bits also corresponds to the number of data samples in the buffer, up to the maximum of 16. To enable the interrupt, it is necessary to set the A/D Interrupt Enable bit, AD1IE.

If DMAEN (AD1CON1<11>) is set, the interrupt is generated on every successful write to the AD1DMBUF register. For more information, refer to **Section 51.9 "Extended DMA Operations"**.

If auto-scan is enabled (AD1CON5<15> = 1), interrupt generation is controlled by the ASINTx bits (AD1CON5<9:8>). For more information, refer to **Section 51.10.4** "**Threshold Detect Interrupts**".

51.7.6 Aborting a Conversion

Clearing the ADON bit during a conversion will abort the current conversion. The A/D results buffer will not be updated with the partially completed A/D conversion sample; that is, the corresponding ADC1BUF buffer location will continue to contain the value of the last completed conversion (or the last value written to the buffer).

51.7.7 Offset Calibration

The module provides a simple calibration method to offset the effects of internal device noise. While not always necessary, this may be helpful in situations where weak analog signals are being converted. Calibration is performed by using the OFFCAL bit (AD1CON2<12>). This disconnects the S/H amplifier entirely from any inputs. With the OFFCAL bit set, a single reference conversion is performed. The results of this conversion are value added by internal device noise. This result can be stored by the application, then used as an offset value for future conversions.

51.8 A/D RESULTS BUFFER

As conversions are completed, the module writes the results of the conversions into the A/D result buffer. This buffer is a RAM array of fixed word size, accessed through the SFR space. The size of the buffer is determined by the number of external analog input channels on the device, allowing one word for each channel. Depending on the device, additional buffer space may be provided for one or more internal analog channels (e.g., band gap sources). The number of buffer addresses is always even and always at least equal to the number of external channels.

User software may attempt to read each A/D conversion result as it is generated; however, this might consume too much CPU time. Generally, to minimize software overhead, the module will fill the buffer with results and then generate an interrupt when the buffer is filled.

Note: This section describes buffer operation in Legacy mode (AD1CON5<3:2> = 00). Buffer operation is different when the Compare Only or Compare and Save modes are used with the Threshold Detect feature. For more information, see **Section 51.10** "Threshold Detect Operation".

51.8.1 Number of Conversions Per Interrupt

The SMPI<4:0> bits select how many A/D conversions will take place before the CPU is interrupted. This can vary from 1 to 16 samples per interrupt. The A/D Converter module always starts writing its conversion results at the beginning of the buffer, after each interrupt. For example, if SMPI<4:0> = 00000, the conversion results will always be written to the ADC1BUF0. In this example, no other buffer locations would be used, since only one sequence per interrupt is specified.

51.8.2 Buffer Fill Modes

The results buffer can be configured to operate in either of two modes: a standard FIFO mode, compatible with the earlier 10-bit A/D module (default), or a Channel Indexed mode. The Fill mode is selected by the BUFREGEN bit (AD1CON2<11>).

51.8.2.1 FIFO MODES

When BUFREGEN = 0, the results buffer operates in FIFO mode. The first conversion results, after initiating conversions, is written to the first available buffer address. Subsequent conversions are written to the next sequential buffer location, continuing until the process is interrupted. If allowed to continue without interrupts, the module would fill each location and then wrap around to the first address, continuing the process.

The BUFM bit (AD1CON2<1>) controls how the buffer is filled. When BUFM is '1', the buffer is split into two equal halves: a lower half (ADC1BUF0 through ADC1BUF[(n/2) – 1]) and an upper half (ADC1BUF[n/2] through ADC1BUFn), where n is the number of available analog channels (both internal and external). The buffers will alternately receive the conversion results after each interrupt event. The initial buffer used after BUFM is set is the lower group.

When BUFM is '0', the entire buffer is used for all conversion sequences.

Note: When the BUFM bit is set, the user should not program the SMPIx bits to a value that specifies more than (n/2) conversions per interrupt.

The decision to use the split buffer feature will depend upon how much time is available to move the buffer contents after the interrupt, as determined by the application. If the application can quickly unload a full buffer within the time it takes to sample and convert one channel, the BUFM bit can be '0', and up to 16 conversions may be done per interrupt. The application will have one sample/convert time before the first buffer location is overwritten.

If the processor cannot unload the buffer within the sample and conversion time, the BUFM bit should be '1'. For example, if SMPI<4:0> = 00111, then eight conversions will be loaded into the lower half of the buffer, following which, an interrupt may occur. The next eight conversions will be loaded into the upper half of the buffer. The processor will, therefore, have the entire time between interrupts to move the eight conversions out of the buffer.

51.8.2.1.1 Buffer Fill Status

When the conversion result buffer is split (BUFM = 1), the BUFS status bit (AD1CON2<7>) indicates which half of the buffer that the A/D Converter is currently writing. If BUFS = 0, the A/D Converter is filling the lower group and the user application should read conversion values from the upper group. If BUFS = 1, the situation is reversed, and the user application should read conversion values from the lower group.

51.8.2.2 CHANNEL INDEXED MODE

When BUFREGEN = 1, FIFO operation is disabled. In this Fill mode, the conversion result for each channel is written only to the buffer location that corresponds to that channel. For example, any conversions performed on AN0 are stored only in ADC1BUF0. The same holds true for AN1 and ADC1BUF1, and so on. Subsequent conversions on a particular channel that occur, prior to an interrupt, will result in any previous data in that location being overwritten.

Channel Indexed mode is particularly useful when used with the Threshold Detect feature, as this allows the user to easily test for a particular condition on a specific analog channel without creating an excess of CPU overhead. This is covered in more detail in **Section 51.10 "Threshold Detect Operation"**.

51.8.3 Buffer Data Formats

The results of each A/D conversion are 12 bits wide (optionally, 10 bits wide in some devices). To maintain data format compatibility, the result of each conversion is automatically converted to one of four selectable, 16-bit formats. The FORM<1:0> bits (AD1CON1<9:8>) select the format. Figure 51-10 and Figure 51-11 show the data output formats that can be selected. Tables 51-2 through 51-5 show the numerical equivalents for the various conversion result codes.

Figure 51-10: A/D Output Data Formats (12-Bit)

| RAM Contents: | | d11 | d10 | d09 | d08 | d07 | d06 | d05 | d04 | d03 | d02 | d01 | d00 |
|--------------------------|--|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Read to Bus: | | | | l | l | l | | | | l | | | |
| Integer | 0 0 0 0 | d11 | d10 | d09 | d08 | d07 | d06 | d05 | d04 | d03 | d02 | d01 | d00 |
| | | | | ı | ı | ı | | | | ı | | | |
| Signed Integer | $ \overline{d11} \overline{d11} \overline{d11} \overline{d11} $ | d11 | d10 | d09 | d08 | d07 | d06 | d05 | d04 | d03 | d02 | d01 | d00 |
| | | 1 | | 1 | 1 | 1 | | | | 1 | | | |
| Fractional (1.15) | d11 d10 d09 d08 | d07 | d06 | d05 | d04 | d03 | d02 | d01 | d00 | 0 | 0 | 0 | 0 |
| | | • | | | | | | | | | | | |
| Signed Fractional (1.15) | d11 d10 d09 d08 | d07 | d06 | d05 | d04 | d03 | d02 | d01 | d00 | 0 | 0 | 0 | 0 |
| | | • | • | • | • | • | | • | • | • | • | • | |

Table 51-2: Numerical Equivalents of Various Result Codes: 12-Bit Integer Formats

| VIN/VREF | 12-Bit Output Code | 16-Bit Integer Format/ Equivalent Decimal Value | 16-Bit Signed Integer Format/ Equivalent Decimal Value | | | |
|-----------|-----------------------|--|---|---------------------|-------|--|
| 4095/4096 | 1111 1111 1111 | 0000 1111 1111 1111 | 4095 | 0000 0111 1111 1111 | 2047 | |
| 4094/4096 | 1111 1111 1110 | 0000 1111 1111 1110 | 4094 | 0000 0111 1111 1110 | 2046 | |
| | | ••• | | | | |
| 2049/4096 | 1000 0000 0001 | 0000 1000 0000 0001 | 2049 | 0000 0000 0000 0001 | 1 | |
| 2048/4096 | 1000 0000 0000 | 0000 1000 0000 0000 | 2048 | 0000 0000 0000 0000 | 0 | |
| 2047/4096 | 0111 1111 1111 | 0000 0111 1111 1111 | 2047 | 1111 1111 1111 1111 | -1 | |
| | | ••• | | | | |
| 1/4096 | 0000 0000 0001 | 0000 0000 0000 0001 | 1 | 1111 1000 0000 0001 | -2047 | |
| 0/4096 | 0000 0000 0000 | 0000 0000 0000 0000 | 0 | 1111 1000 0000 0000 | -2048 | |

Table 51-3: Numerical Equivalents of Various Result Codes: 12-Bit Fractional Formats

| VIN/VREF | 12-Bit Output Code | 16-Bit Fractional Format Equivalent Decimal Valu | - | 16-Bit Signed Fractional Format/ Equivalent Decimal Value | | | |
|-----------|-----------------------|---|-------|--|--------|--|--|
| 4095/4096 | 1111 1111 1111 | 1111 1111 1111 0000 | 0.999 | 0111 1111 1111 0000 | 0.499 | | |
| 4094/4096 | 1111 1111 1110 | 1111 1111 1110 0000 | 0.998 | 0111 1111 1110 0000 | 0.498 | | |
| | | ••• | | | | | |
| 2049/4096 | 1000 0000 0001 | 1000 0000 0001 0000 | 0.501 | 0000 0000 0001 0000 | 0.001 | | |
| 2048/4096 | 1000 0000 0000 | 1000 0000 0000 0000 | 0.500 | 0000 0000 0000 0000 | 0.000 | | |
| 2047/4096 | 0111 1111 1111 | 0111 1111 1111 0000 | 0.499 | 1111 1111 1111 0000 | -0.001 | | |
| | | ••• | | | | | |
| 1/4096 | 0000 0000 0001 | 0000 0000 0001 0000 | 0.001 | 1000 0000 0001 0000 | -0.499 | | |
| 0/4096 | 0000 0000 0000 | 0000 0000 0000 0000 | 0.000 | 1000 0000 0000 0000 | -0.500 | | |

Figure 51-11: A/D Output Data Formats (10-Bit)

| RAM Contents: Read to Bus: | | | | | | | d09 | d08 | d07 | d06 | d05 | d04 | d03 | d02 | d01 | d00 |
|----------------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|
| Integer | 0 | 0 | 0 | 0 | 0 | 0 | d09 | d08 | d07 | d06 | d05 | d04 | d03 | d02 | d01 | d00 |
| Signed Integer | d09 | d08 | d07 | d06 | d05 | d04 | d03 | d02 | d01 | d00 |
| Fractional (1.15) | d09 | d08 | d07 | d06 | d05 | d04 | d03 | d02 | d01 | d00 | 0 | 0 | 0 | 0 | 0 | 0 |
| Signed Fractional (1.15) | d09 | d08 | d07 | d06 | d05 | d04 | d03 | d02 | d01 | d00 | 0 | 0 | 0 | 0 | 0 | 0 |

Table 51-4: Numerical Equivalents of Various Result Codes: 10-Bit Integer Formats

| | mamorioa: =qairai | onic or various resourt ocusor | – | ogo. i omiato | |
|-----------|-----------------------|--|--|---------------------|------|
| Vin/Vref | 10-Bit Output Code | 16-Bit Integer Format/ Equivalent Decimal Value | 16-Bit Signed Integer For Equivalent Decimal Valu | | |
| 1023/1024 | 11 1111 1111 | 0000 0011 1111 1111 | 1023 | 0000 0001 1111 1111 | 511 |
| 1022/1024 | 11 1111 1110 | 0000 0011 1111 1110 | 1022 | 0000 0001 1111 1110 | 510 |
| | | ••• | | | |
| 513/1024 | 10 0000 0001 | 0000 0010 0000 0001 | 513 | 0000 0000 0000 0001 | 1 |
| 512/1024 | 10 0000 0000 | 0000 0010 0000 0000 | 512 | 0000 0000 0000 0000 | 0 |
| 511/1024 | 01 1111 1111 | 0000 0001 1111 1111 | 511 | 1111 1111 1111 1111 | -1 |
| | | ••• | | | |
| 1/1024 | 00 0000 0001 | 0000 0000 0000 0001 | 1 | 1111 1110 0000 0001 | -511 |
| 0/1024 | 00 0000 0000 | 0000 0000 0000 0000 | 0 | 1111 1110 0000 0000 | -512 |

Table 51-5: Numerical Equivalents of Various Result Codes: 10-Bit Fractional Formats

| VIN/VREF | 10-Bit Output Code | 16-Bit Fractional Format Equivalent Decimal Valu | • | 16-Bit Signed Fractional Format/ Equivalent Decimal Value | | | |
|-----------|-----------------------|---|-------|--|--------|--|--|
| 1023/1024 | 11 1111 1111 | 1111 1111 1100 0000 | 0.999 | 0111 1111 1100 0000 | 0.499 | | |
| 1022/1024 | 11 1111 1110 | 1111 1111 1000 0000 | 0.998 | 0111 1111 1000 0000 | 0.498 | | |
| | | ••• | | | | | |
| 513/1024 | 10 0000 0001 | 1000 0000 0100 0000 | 0.501 | 0000 0000 0100 0000 | 0.001 | | |
| 512/1024 | 10 0000 0000 | 1000 0000 0000 0000 | 0.500 | 0000 0000 0000 0000 | 0.000 | | |
| 511/1024 | 01 1111 1111 | 0111 1111 1100 0000 | 0.499 | 1111 1111 1100 0000 | -0.001 | | |
| | | ••• | | | | | |
| 1/1024 | 00 0000 0001 | 0000 0000 0100 0000 | 0.001 | 1000 0000 0100 0000 | -0.499 | | |
| 0/1024 | 00 0000 0000 | 0000 0000 0000 0000 | 0.000 | 1000 0000 0000 0000 | -0.500 | | |

51.9 EXTENDED DMA OPERATIONS

For DMA enabled modules, when DMAEN (AD1CON1<11>) = 1, the A/D conversion values are able to be written to user-defined regions of data memory, expanding the conversion storage beyond the ADC1BUFn buffer. This allows the ADC1BUFn buffer to maintain threshold values while still storing conversion values. DMA operations also allocate dedicated memory to the results of conversions on the upper channels, which do not have their own memory mapped buffers inside the A/D module.

In Extended DMA operation, A/D conversion results are written to the AD1DMBUF register. An interrupt is generated after a successful write to the AD1DMBUF register. This interrupt can be used to trigger a DMA operation, writing the conversion value to the desired memory location. Extended DMA operates in two modes: Extended Buffer mode and Scatter/Gather mode.

For more information on configuring a DMA channel for a memory operation, refer to **Section 54.** "**Direct Memory Access Controller (DMA)**" (DS39742) in the "*PIC24F Family Reference Manual*".

51.9.1 Extended Buffer Mode

Extended Buffer mode is enabled when DMABM (AD1CON1<12>) = 1. In this Buffer mode, the DMA will assemble a buffer in memory in the order of conversions completed. It is useful for storing the results of conversions on the upper channels, which do not have their own memory mapped buffers inside the A/D module. It can also be used to store the conversion results on any A/D channel in any implemented address in data RAM. In Extended Buffer mode, in order to scan multiple channels, the DMA must be configured for Peripheral Indirect mode. The DMADST register points to the beginning of the buffer. The A/D module provides the inter-block address, pointing to locations within the block of DMA data. The address to the buffer is formed from two parts, ORed together. The DMA count and SMPIx bits (AD1CON2<6:2>) must be set to generate an interrupt after the proper number of conversions. Conversion data is written to a destination specified by the DMA Controller.

This allows users to implement dedicated storage for conversions of higher numbered channels, which do not have their own memory mapped A/D buffer locations. When using Extended Buffer mode, always set the BUFREGEN bit to disable FIFO operation. In addition, disable the Split Buffer mode by clearing the BUFM bit.

51.9.2 Scatter/Gather Mode

When DMABM = 0, the A/D module is configured to function with the DMA Controller for Scatter/Gather mode operations. The buffers are written in the order of the channels scanned. The A/D module generates an 11-bit Indirect Address (IA). The IA is ORed with the destination address in the DMA Controller to define where the A/D conversion data will be stored.

In Scatter/Gather mode, each analog channel is allocated a buffer for conversion data. Each buffer is contiguous, and the size of each channel's buffer is selected by the DMABLx bits (AD1CON4<2:0>). The size options range from a single word per buffer to 128 words. The buffers are allocated to each channel, regardless of whether or not the channel will actually have conversion data. The exception to this rule is when the buffer size per channel is large enough that not all of the channels can be addressed (DMABL<2:0>= 110 or 111).

If Peripheral Indirect Addressing (PIA) is used, the Indirect Address (IA) is created by combining the base address within a channel buffer with three to five bits (depending on the buffer size) to identify the channel. The base address ranges from zero to seven bits wide, depending on the buffer size. The address is right-padded with a '0' in order to maintain address alignment in the data space. The concatenated channel and base address bits are then left-padded with zeroes, as necessary, to complete the 11-bit IA.

The write address inside a channel buffer is controlled by the A/D module. The buffer location counter is a simple counter. It is initialized to '0' when the A/D module is initialized. Its maximum value is defined by the DMABLx bits. Upon reaching this maximum value, it rolls over back to '0'. It is incremented based on the SMPIx bits (AD1CON2<6:2>). Essentially, it is incremented when the non-DMA version of the module would generate an A/D interrupt (for more information, refer to Section 51.8.1 "Number of Conversions Per Interrupt").

The IA is configured to auto-increment during write operations according to the SMPI<4:0> bits (AD1CON2<6:2>). There are three useful cases of the SMPIx bits for use with the DMA. When the A/D is set up to store one conversion per channel, the SMPIx bits should be set to '00000'. This indicates that the address will increment every sample. If ALTS = 1, indicating alternating analog input selections, then set SMPI<4:0> = 00001 to allow two samples per address increment. When scanning is used, then the SMPIx bits should be set to the number of inputs being scanned. So, for example, if AD1CSSL = 0xFFFF, indicating AN0-AN15 are being scanned, then set SMPI<4:0> = 01111 to increment the address after 16 sample/conversion sequences.

As with PIA operations for any DMA-enabled module, the base destination address in the DMADST register must be masked properly to accommodate the IA. Table 51-6 shows how complete addresses are formed. Note that the address masking varies for each buffer size option. Because of masking requirements, some address ranges may not be available for certain buffer sizes. Users should verify that the DMA base address is compatible with the buffer size selected.

Figure 51-12 shows how the parts of the address define the buffer locations in data memory. In this case, the module "allocates" 256 bytes of data RAM (1000h to 1100h) for 32 buffers of four words each. However, this is not a hard allocation and nothing prevents these locations from being used for other purposes. For example, in the current case, if Analog Channels 2, 7 and 29 are being sampled and converted, conversion data will only be written to the channel buffers, starting at 1008h, 1038h and 10F0h. The empty locations in PIA buffer space can be used for any other purpose.

Note that the generated buffer address is not checked for out of bounds conditions. It is the user's responsibility to keep track of buffer locations and preventing data overwrites. Also, the number of potential analog inputs, multiplied by the buffer size specified in the DMABLx bits, cannot exceed the total DMA buffer area.

Table 51-6: Indirect Address Generation in PIA Mode

| DMABL<2:0> | Buffer Size Per Channel (words) | Generated Offset Address (lower 11 bits) | Available Input Channels | Allowable DMADST Addresses |
|------------|------------------------------------|---|--------------------------------|-------------------------------|
| 000 | 1 | 000 00cc ccc0 | 32 | xxxx xxxx xx00 0000 |
| 001 | 2 | 000 0ccc ccn0 | 32 | xxxx xxxx x000 0000 |
| 010 | 4 | 000 cccc cnn0 | 32 | xxxx xxxx 0000 0000 |
| 011 | 8 | 00c cccc nnn0 | 32 | xxxx xxx0 0000 0000 |
| 100 | 16 | Occ cccn nnnO | 32 | xxxx xx00 0000 0000 |
| 101 | 32 | ccc ccnn nnn0 | 32 | xxxx x000 0000 0000 |
| 110 | 64 | ccc cnnn nnn0 | 16 | xxxx x000 0000 0000 |
| 111 | 128 | ccc nnnn nnn0 | 8 | xxxx x000 0000 0000 |

Legend: ccc = Channel number (three to five bits); n = Base buffer address (zero to seven bits);

x = User-definable range of DMADST for base address; 0 = Masked bits of DMADST for IA.




Figure 51-12: Example of Buffer Address Generation in PIA Mode (4-Word Buffers Per Channel)

51.9.3 Extended DMA Operation with Threshold Detect

When using the Threshold Detect operation with the Extended DMA, it is important to note that the Write mode must be configured to convert and save (ASINT<1:0> = 01), or else the converted values will not be saved in the desired memory location. Also, if a channel fails to generate a valid comparison, the undesired value will not be written to memory, which will be interpreted by the DMA as an incomplete DMA session. As such, the user should poll the AD1CHITL and/or AD1CHITH register to determine if a given memory location contains valid data. For more information on DMA operation, refer to **Section 54. "Direct Memory Access Controller (DMA)"**. To learn more about Threshold Detect operation, refer to **Section 51.10** "Threshold Detect Operation".

51.10 THRESHOLD DETECT OPERATION

Threshold Detect is a significant extension of the Auto-Scan feature offered in previous 10-bit A/D modules. In addition to being able to repeatedly sample a predefined sequence of analog channels, Threshold Detect allows the user to define match conditions based on the conversion results and generate an interrupt based on these conditions. During normal operation, this can potentially reduce the amount of CPU time spent on processing A/D interrupts. For low-power applications, this can allow the CPU to remain inactive for longer periods, waking only when specific analog conditions are met.

When selected by the user, Threshold Detect changes the operation of the A/D results buffer by making it a read/write array for both conversion results and comparison (threshold) values. It also brings into play the AD1CHIT registers, which are used to indicate match conditions. Independently selectable comparison and buffer storage settings make a wide range of operating combinations possible.

51.10.1 Operating Modes

The operation of Threshold Detect is mostly controlled by the AD1CON5 register (Figure 51-5). The ASEN bit (AD1CON5<15>) controls overall operation of Threshold Detect; setting this bit enables the functionality.

As with Legacy Auto-Scan operation, the channels to be included are selected using the AD1CSSH/L registers. Setting a particular bit in either register includes the corresponding channel in an automatic sequential scan. One or more channels may be selected. After the channels have been selected, setting both the CSCNA and ASEN bits to enable a single scan of the designated channels. The scan itself is triggered by the trigger source programmed by the SSRC<3:0> bits.

Note:

Legacy Auto-Scan (i.e., sequential scanning of analog channels on MUX A, without any comparison) is controlled by the CSCNA bit (AD1CON2<10>) and does not depend on the ASEN bit to function

The LPEN bit (AD1CON5<14>) allows Threshold Detect to function with a low-power feature. By design, Threshold Detect can perform comparison operations when the device is in Sleep or Idle modes, waking the CPU when it generates an interrupt. Setting LPEN configures the device to return to low-power operation after the interrupt has been serviced.

The Compare Mode bits, CM<1:0> (AD1CON5<1:0>), select the type of comparison to be performed. Four types are available:

- · The result of the current conversion is greater than a reference threshold
- · The result of the current conversion is less than a reference threshold
- The result of the current conversion is between two predefined thresholds ("Inside Window")
- The result of the current conversion is outside of the predefined thresholds ("Outside Window")

The Write Mode bits, WM<1:0> (AD1CON5<3:2>), determine the disposition of the conversion. Three options are available:

- Discard the conversion after the comparison has been performed
- · Store the conversion after the comparison has been performed
- Store the conversion without comparison (Legacy mode)

51.10.1.1 BUFFER OPERATION AND COMPARISONS

For Buffer Write modes that involve storing conversions (WM<1:0> = 0x), the BUFM and BUFREGEN bits control how the buffer functions (as a channel indexed, single FIFO or split FIFO buffer). However, when the compare and store option is selected (WM<1:0> = 01), using a FIFO mode may overwrite the buffers of other channels and cause unpredictable comparison results. For that reason, always use Channel Indexed Buffer mode (BUFREGEN = 1) when using the compare and store option.

51.10.1.2 BUFFER OPERATION IN WINDOWED COMPARISONS (CHANNEL MIRRORING)

The use of windowed comparisons changes the available options for the results buffer. To accommodate the storage of two threshold values, the buffer is automatically split into halves, similar to Split FIFO mode. Buffer addresses in each half are paired, with the lowest address in one buffer, matched to the buffer address in the upper half. (For example, in a 16-word buffer, ADC1BUF0 is paired with ADC1BUF9, ADC1BUF1 is paired with ADC1BUF10, and so on.) This pairing is referred to as "channel mirroring".

Mirroring can obviously be applied only to the lower A/D channels; for most devices, this corresponds to the lower half of the external analog channels. This does not mean that those buffer locations cannot be used for other purposes. However, storing any other data in a particular buffer location, where channel mirroring is being used, may result in misleading comparison evaluations.

51.10.2 Setting Comparison Thresholds

The comparison thresholds for Threshold Detect are set by writing the desired values to an appropriate location in the A/D results buffer. This can only be done when the module is deactivated (AD1CON1<15> = 0).

The location of the threshold is determined by the comparison type. For simple greater than, and less than, comparisons, the value is written to the buffer location corresponding to the input channel to be monitored. For example, if AN0 is to be monitored for a voltage over a certain level, the ceiling threshold is stored in ADC1BUF0.

The location of the thresholds for windowed comparisons are written to two addresses. The lower value is written to the address corresponding to the monitored channel. The upper value is stored in the corresponding mirrored address in the upper half of the buffer. To expand on the previous example, if the conversion on AN0 is to be a windowed comparison, the floor threshold is stored in ADC1BUF0, while the ceiling threshold is stored in ADC1BUF9.

51.10.3 Compare Hit Registers

To determine if a particular event has occurred, the A/D module uses two registers to record match events. These registers are referred to as the Compare Hit registers and are designated, AD1CHITL and AD1CHITH. The registers map their individual bits sequentially to each of the (up to) 32 analog channels. If a particular channel in a device is not implemented, the corresponding Compare Hit bit (CHHn) is not implemented.

Each bit serves as an event semaphore for its corresponding channel. When the programmed event occurs on that channel, the bit becomes set and stays set until it is cleared by the application. It is the user's responsibility to clear the bits after the application has evaluated them.

Depending on the event, more than one Compare Hit bit may be set. The significance of a set bit must be interpreted by the application in the context of the Compare mode selected. Particular examples are covered in **Section 51.10.5** "Comparison Mode Examples".

51.10.4 Threshold Detect Interrupts

The A/D module can generate an interrupt and set the AD1IF flag based on Threshold Detect operation. This is based on completion of a Threshold Detect sequence and/or the occurrence of a valid comparison. When Threshold Detect is enabled (ASEN = 1), A/D module interrupt generation is governed by the ASINTx bits (AD1CON5<9:8>), superseding any configuration implemented by the SMPIx bits (AD1CON2<6:2>). For information on alternative interrupt settings, refer to Section 51.8.1 "Number of Conversions Per Interrupt".

The Threshold Detect interrupt is configured by the ASINT<1:0> bits (AD1CON5<9:8>). Options include interrupt after a scan sequence, interrupt after a scan sequence with a valid match, interrupt after a valid match (without waiting for the sequence to end) or no interrupt.

51.10.5 Comparison Mode Examples

The following examples show the effect of valid comparisons on the results buffer and the Compare Hit registers. In each figure, changes within the registers are indicated in bold.

For the sake of simplicity, the examples assume a device with only 16 analog inputs. Devices with a greater number of channels, and thus, larger results buffers and two Compare Hit registers, will function in a similar fashion.

Note: When using any comparison mode, always use channel indexed buffer storage (BUFREGEN = 1). Otherwise, the threshold values for other channels may be overwritten, resulting in unpredictable comparisons.

51.10.5.1 SIMPLE COMPARISONS (GREATER AND LESS THAN RESULTS)

When the Compare Mode bits, CM<1:0> (AD1CON5<1:0>), are programmed as '0x', the converter compares the sampled value to see if it is greater than (CM<1:0> = 01), or less than (CM<1:0> = 00), the threshold value in the buffer location. If the condition is met, both of the following occur:

- The Compare Hit bit (CHHn) for the corresponding channel is set.
- If the Write Mode bits, WM<1:0> (AD1CON5<3:2>), are programmed to '01', the converted value is written to the buffer, replacing the threshold value. If WM<1:0> = 10, the converted value is discarded.

The changes to the result buffer and the Compare Hit register are shown in Figure 51-13. Note that they are the same for both types of simple comparison.

Figure 51-13: Simple Comparison Operations (Greater Than and Less Than)

| _ |
|-----------------|
| _ |
| _ |
| _ |
| _ |
| _ |
| _ |
| _ |
| _ |
| _ |
| _ |
| _ |
| _ |
| Threshold Value |
| _ |
| _ |
| |

Before Conversion and Comparison

| | AD1CHITL | | | | | | | |
|----|----------|----|----|----|----|---|---|--|
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |

After Conversion and Comparison

| | Compare Only | Compare and |
|-----------|-----------------|------------------|
| | ('10') | Store ('01') |
| ADC1BUF15 | | _ |
| ADC1BUF14 | | _ |
| ADC1BUF13 | | _ |
| ADC1BUF12 | | _ |
| ADC1BUF11 | | _ |
| ADC1BUF10 | | _ |
| ADC1BUF9 | | _ |
| ADC1BUF8 | | _ |
| ADC1BUF7 | | _ |
| ADC1BUF6 | | _ |
| ADC1BUF5 | | _ |
| ADC1BUF4 | | _ |
| ADC1BUF3 | - | _ |
| ADC1BUF2 | Threshold Value | Conversion Value |
| ADC1BUF1 | | _ |
| ADC1BUF0 | | _ |

| AD1CHITL | | | | | | | | |
|----------|----|----|----|----|----|---|---|--|
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | |

51.10.5.2 INSIDE WINDOW COMPARISON

When the Compare Mode bits, CM<1:0>, are programmed as '10', the converter compares the sampled value to see if it falls between the threshold values in the buffer and mirrored channel location. Since the value in the mirrored channel location is always the greater value of the two thresholds, the condition is met when:

Threshold 2 > Converted Value > Threshold 1

In this case, both of the following occur:

- The Compare Hit bit (CHHn) for the corresponding channel is set; the Compare Hit bit for the mirrored channel remains cleared.
- If the Write Mode bits, WM<1:0> (AD1CON5<3:2>), are programmed to '01', the converted value is written to the buffer, replacing the lower threshold value. If WM<1:0> = 10, the converted value is discarded.

The changes to the result buffer and the Compare Hit register are shown in Figure 51-14.

Figure 51-14: Inside Window Comparison Operation

Before Conversion and Comparison

| ADC1BUF15 | 1 |
|-----------|-------------|
| ADC1BUF14 | 1 |
| ADC1BUF13 | |
| ADC1BUF12 | |
| ADC1BUF11 | |
| ADC1BUF10 | Threshold 2 |
| ADC1BUF9 | |
| ADC1BUF8 | |
| ADC1BUF7 | |
| ADC1BUF6 | |
| ADC1BUF5 | |
| ADC1BUF4 | |
| ADC1BUF3 | |
| ADC1BUF2 | Threshold 1 |
| ADC1BUF1 | |
| ADC1BUF0 | _ |

| | AD1CHITL | | | | | | | |
|----|----------|----|----|----|----|---|---|--|
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | |

After Conversion and Comparison

| | Compare Only ('10') | Compare and Store ('01') |
|-----------|------------------------|-----------------------------|
| ADC1BUF15 | | _ |
| ADC1BUF14 | | _ |
| ADC1BUF13 | | _ |
| ADC1BUF12 | | _ |
| ADC1BUF11 | | _ |
| ADC1BUF10 | Threshold 2 | Threshold 2 |
| ADC1BUF9 | | _ |
| ADC1BUF8 | | _ |
| ADC1BUF7 | | _ |
| ADC1BUF6 | | _ |
| ADC1BUF5 | | _ |
| ADC1BUF4 | | _ |
| ADC1BUF3 | | _ |
| ADC1BUF2 | Threshold 1 | Conversion Value |
| ADC1BUF1 | | _ |
| ADC1BUF0 | _ | _ |

| | AD1CHITL | | | | | | | | |
|----|----------|----|----|----|----|---|---|--|--|
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | | |

Section 51, 12-Bit A/D Converter with Threshold Detect

51.10.5.3 OUTSIDE WINDOW COMPARISON

When the Compare Mode bits CM<1:0> are programmed as '11', the converter compares the sampled value to see if it falls outside of the threshold values in the buffer and mirrored channel location. Again, since the value in the mirrored channel location is always the greater value of the two thresholds, the condition is met when either:

Converted Value > Threshold 2

or

Threshold 1 > Converted Value

In these cases, the following occurs:

- · The Compare Hit bit (CHHn) for the corresponding channel is set.
- If the converted value is greater than Threshold 2, the CHHn bit for the mirrored channel is also set. If it is less than Threshold 1, the mirrored channel bit remains '0'.
- If the Write Mode bits, WM<1:0> (AD1CON5<3:2>), are programmed to '01':
 - If the converted value is above Threshold 2, the converted value is written to the mirrored channel address, replacing the upper threshold value.
 - If the converted value is below Threshold 1, the converted value is written to the channel address, replacing the lower threshold value.
- If WM<1:0> = 10, the converted value is discarded.

The changes to the result buffer and the Compare Hit register are shown in Figure 51-15 (over the upper threshold) and Figure 51-16 (under the lower threshold).

Note that when a Windowed Comparison mode is selected and channel mirroring is enabled, nothing prevents a conversion from another operation from being stored in the mirrored channel location. In the previous examples of windowed operation, if AN10 is included in a Threshold Detect operation, a conversion on AN10 might be tested against the upper threshold for AN2, stored in that location. This could result in the threshold value being overwritten and/or the CHH10 bit being set.

For this reason, users must always carefully consider the allocation and use of the upper analog channels (both external and internal) when using Windowed Compare modes. Wherever possible, exclude the upper analog channels for Threshold Detect operations, and convert and test those channels in a separate routine.

Figure 51-15: Outside Window Comparison Operation (Over Threshold 2)

Before Conversion and Comparison

| ADC1BUF15 | 1 |
|-----------|-------------|
| ADC1BUF14 | |
| ADC1BUF13 | 1 |
| ADC1BUF12 | 1 |
| ADC1BUF11 | 1 |
| ADC1BUF10 | Threshold 2 |
| ADC1BUF9 | 1 |
| ADC1BUF8 | 1 |
| ADC1BUF7 | 1 |
| ADC1BUF6 | |
| ADC1BUF5 | |
| ADC1BUF4 | |
| ADC1BUF3 | |
| ADC1BUF2 | Threshold 1 |
| ADC1BUF1 | _ |
| ADC1BUF0 | _ |

0

| AD1CHITL | | | | | | | |
|----------|----|----|----|----|----|---|---|
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |

0

After Conversion and Comparison

| | Compare Only | Compare and |
|-----------|--------------|------------------|
| | ('10') | Store ('01') |
| ADC1BUF15 | | _ |
| ADC1BUF14 | | _ |
| ADC1BUF13 | | _ |
| ADC1BUF12 | - | _ |
| ADC1BUF11 | | _ |
| ADC1BUF10 | Threshold 2 | Conversion Value |
| ADC1BUF9 | | _ |
| ADC1BUF8 | | _ |
| ADC1BUF7 | | _ |
| ADC1BUF6 | | _ |
| ADC1BUF5 | | _ |
| ADC1BUF4 | | _ |
| ADC1BUF3 | - | _ |
| ADC1BUF2 | Threshold 1 | Threshold 1 |
| ADC1BUF1 | | _ |
| ADC1BUF0 | | _ |

| AD1CHITL | | | | | | | | |
|----------|----|----|----|----|----|---|---|--|
| 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | |

Figure 51-16: Outside Window Comparison Operation (Under Threshold 1)

Before Conversion and Comparison

| ADC1BUF15 | |
|-----------|-------------|
| ADC1BUF14 | |
| ADC1BUF13 | |
| ADC1BUF12 | |
| ADC1BUF11 | |
| ADC1BUF10 | Threshold 2 |
| ADC1BUF9 | _ |
| ADC1BUF8 | _ |
| ADC1BUF7 | _ |
| ADC1BUF6 | _ |
| ADC1BUF5 | _ |
| ADC1BUF4 | _ |
| ADC1BUF3 | |
| ADC1BUF2 | Threshold 1 |
| ADC1BUF1 | _ |
| ADC1BUF0 | _ |

| | AD1CHITL | | | | | | | | | |
|----|-----------------------|---|---|---|---|---|---|--|--|--|
| 15 | 15 14 13 12 11 10 9 8 | | | | | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | | | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | | | |

After Conversion and Comparison

| | Compare Only ('10') | Compare and Store ('01') |
|-----------|------------------------|-----------------------------|
| ADC1BUF15 | | _ |
| ADC1BUF14 | | _ |
| ADC1BUF13 | | _ |
| ADC1BUF12 | | _ |
| ADC1BUF11 | | _ |
| ADC1BUF10 | Threshold 2 | Threshold 2 |
| ADC1BUF9 | | _ |
| ADC1BUF8 | | _ |
| ADC1BUF7 | | _ |
| ADC1BUF6 | | _ |
| ADC1BUF5 | | _ |
| ADC1BUF4 | | _ |
| ADC1BUF3 | | _ |
| ADC1BUF2 | Threshold 1 | Conversion Value |
| ADC1BUF1 | | _ |
| ADC1BUF0 | _ | _ |

| | AD1CHITL | | | | | | | | | |
|----|--------------------|---|---|---|---|---|---|--|--|--|
| 15 | 5 14 13 12 11 10 9 | | | | | | | | | |
| 0 | 0 | 0 | 0 | 0 | 0 | 0 | 0 | | | |
| 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 | | | |
| 0 | 0 | 0 | 0 | 0 | 1 | 0 | 0 | | | |


51.11 CONVERSION SEQUENCE EXAMPLES

The following configuration examples show the A/D operation in different sampling and buffering configurations. In each example, setting the ASAM bit starts automatic sampling. A conversion trigger ends sampling and starts conversion.

51.11.1 Sampling and Converting a Single Channel Multiple Times

Figure 51-17 and Example 51-6 illustrate a basic configuration of the A/D. In this case, one A/D input, ANO, will be sampled and converted. The results are stored in the ADC1BUFn buffer. This process repeats 16 times until the buffer is full and then the module generates an interrupt. The entire process will then repeat.

With the ALTS bit clear, only the MUX A inputs are active. The CH0SAx and CH0NAx bits are specified (AN0 - VR-) as the inputs to the Sample-and-Hold channel. All other input selection bits are unused.



Example 51-6: Sampling and Converting a Single Channel Multiple Times

```
int ADCValue, count;
int *ADC16Ptr;
ANSB = 0 \times 0001;
                                           // Only ANO as analog input
AD1CON1 = 0 \times 00 = 0;
                                           // Internal counter triggers conversion
AD1CHS = 0 \times 0000;
                                           // Connect ANO as positive input
AD1CSSL = 0;
AD1CON3 = 0 \times 0 = 0;
                                          // Sample time = 15Tad, Tad = Tcy
                                          // Set AD1IF after every 16 samples
AD1CON2 = 0 \times 003C;
AD1CON1bits.ADON = 1;
                                          // turn ADC ON
while(1)
                                          // repeat continuously
   ADCValue = 0;
                                          // clear value
   ADC16Ptr = &ADC1BUF0;
                                          // initialize ADC1BUF pointer
   IFSObits.AD1IF = 0;
                                          // clear ADC interrupt flag
   AD1CON1bits.ASAM = 1;
                                          // auto start sampling for 31Tad
                                          // then go to conversion
   while (!IFSObits.AD1IF){};
                                          // conversion done?
                                          // yes then stop sample/convert
    AD1CON1bits.ASAM = 0;
    for (count = 0; count < 16; count++) // average the 16 ADC value
       ADCValue = ADCValue + *ADC16Ptr++;
    ADCValue = ADCValue >> 4;
                                           // repeat
```

Example 51-7: Converting a Single Channel 16 Times Per Interrupt

A/D Configuration:

- Select AN0 for S/H+ Input (CH0SA<4:0> = 00000)
- Select VR- for S/H- Input (CH0NA<2:0> = 000)
- Configure for No Input Scan (CSCNA = 0)
- Use Only MUX A for Sampling (ALTS = 0)
- Set AD1IF on Every 16th Sample (SMPI<4:0> = 01111)
- Configure Buffers for Single, 16-Word Results (BUFM = 0)

Operational Sequence:

- 1. Sample MUX A Input ANO; Convert and Write to Buffer 0h.
- 2. Sample MUX A Input AN0; Convert and Write to Buffer 1h.
- 3. Sample MUX A Input AN0; Convert and Write to Buffer 2h.
- 4. Sample MUX A Input AN0; Convert and Write to Buffer 3h.
- 5. Sample MUX A Input AN0; Convert and Write to Buffer 4h.
- 6. Sample MUX A Input AN0; Convert and Write to Buffer 5h.
- 7. Sample MUX A Input AN0; Convert and Write to Buffer 6h.
- 8. Sample MUX A Input AN0; Convert and Write to Buffer 7h.
- 9. Sample MUX A Input AN0; Convert and Write to Buffer 8h.
- 10. Sample MUX A Input AN0; Convert and Write to Buffer 9h.
- 11. Sample MUX A Input ANO; Convert and Write to Buffer Ah.
- 12. Sample MUX A Input AN0; Convert and Write to Buffer Bh.
- 13. Sample MUX A Input AN0; Convert and Write to Buffer Ch.
- 14. Sample MUX A Input ANO; Convert and Write to Buffer Dh.15. Sample MUX A Input ANO; Convert and Write to Buffer Eh.
- 40. O ... I MIDY A I ... (AND O ... (I INV'S C BUILD EI
- 16. Sample MUX A Input AN0; Convert and Write to Buffer Fh.
- 17. Set AD1IF Flag (and generate interrupt, if enabled).
- 18. Repeat (1-16) After Return from Interrupt.

Results Stored in Buffer (after 2 cycles):

| Buffer | Buffer Contents |
|----------|--------------------|
| Address | at 1st AD1IF Event |
| ADC1BUF0 | AN0, Sample 1 |
| ADC1BUF1 | AN0, Sample 2 |
| ADC1BUF2 | AN0, Sample 3 |
| ADC1BUF3 | AN0, Sample 4 |
| ADC1BUF4 | AN0, Sample 5 |
| ADC1BUF5 | AN0, Sample 6 |
| ADC1BUF6 | AN0, Sample 7 |
| ADC1BUF7 | AN0, Sample 8 |
| ADC1BUF8 | AN0, Sample 9 |
| ADC1BUF9 | AN0, Sample 10 |
| ADC1BUFA | AN0, Sample 11 |
| ADC1BUFB | AN0, Sample 12 |
| ADC1BUFC | AN0, Sample 13 |
| ADC1BUFD | AN0, Sample 14 |
| ADC1BUFE | AN0, Sample 15 |
| ADC1BUFF | AN0, Sample 16 |
| | |

| AN0, Sample 17 |
|----------------|
| AN0, Sample 18 |
| AN0, Sample 19 |
| AN0, Sample 20 |
| AN0, Sample 21 |
| AN0, Sample 22 |
| AN0, Sample 23 |
| AN0, Sample 24 |
| AN0, Sample 25 |
| AN0, Sample 26 |
| AN0, Sample 27 |
| AN0, Sample 28 |
| AN0, Sample 29 |
| AN0, Sample 30 |
| AN0, Sample 31 |

AN0, Sample 32


Buffer Contents at 2nd AD1IF Event

51.11.2 A/D Conversions While Scanning Through All Analog Inputs

Figure 51-18 and Example 51-9 illustrate a typical setup, where all available analog input channels are sampled and converted. In this instance, 16 analog inputs are assumed. The set CSCNA bit specifies scanning of the A/D inputs to the S/H positive input. Other conditions are similar to those located in Section 51.11.1 "Sampling and Converting a Single Channel Multiple Times".

Initially, the AN0 input is sampled and converted. The result is stored in the ADC1BUFn buffer. Then, the AN1 input is sampled and converted. This process of scanning the inputs repeats 16 times, until the buffer is full, and then the module generates an interrupt. The entire process will then repeat.





Example 51-8: Sampling and Converting All Channels

```
int ADCValue, count;
int *ADC16Ptr;
ANSA
      = 0xFFFF;
                                          // Configure all pins as analog inputs
                                          // (small-pincount device w/16 channels shown here)
       = 0xFFFF;
ANSB
ANSC
       = 0xFFFF;
                                          //
                                          // Include all channels in scan
AD1CSSL = 0xFFFF;
AD1CON1 = 0x00E0;
                                          // Internal counter triggers conversion
AD1CON3 = 0 \times 0 = 0;
                                          // Sample time = 15Tad, Tad = Tcy
AD1CON2 = 0x043C;
                                          // Set AD1IF after every 16 samples, enable scanning
AD1CON1bits.ADON = 1;
                                          // turn ADC ON
while (1)
                                          // repeat continuously
   ADCValue = 0;
                                          // clear value
                                          // initialize ADC1BUF pointer
   ADC16Ptr = &ADC1BUF0;
    IFSObits.AD1IF = 0;
                                          // clear ADC interrupt flag
   AD1CON1bits.ASAM = 1;
                                          // auto start sampling for 31Tad
                                          // then go to conversion
   while (!IFSObits.AD1IF){};
                                          // conversion done?
   AD1CON1bits.ASAM = 0;
                                          // yes then stop sample/convert
    for (count = 0; count < 16; count++) // average the 16 ADC value
       ADCValue = ADCValue + *ADC16Ptr++;
    ADCValue = ADCValue >> 4;
                                          // repeat
```

Example 51-9: Scanning and Converting All 16 Channels Per Single Interrupt

A/D Configuration:

- Select Any Channel for S/H+ Input (CH0SA<4:0> = xxxxx)
- Select VR- for S/H- Input (CH0NA<2:0> = 000)
- Use Only MUX A for Sampling (ALTS = 0)
- Configure MUX A for Input Scan (CSCNA = 1)
- Include All Analog Channels in Scanning (AD1CSSL = 1111 1111 1111 1111)
- Set AD1IF on Every 16th Sample (SMPI<4:0> = 01111)
- Configure Buffers for Single, 16-Word Results (BUFM = 0)

Operational Sequence:

- 1. Sample MUX A Input ANO; Convert and Write to Buffer 0h.
- 2. Sample MUX A Input AN1; Convert and Write to Buffer 1h.
- 3. Sample MUX A Input AN2; Convert and Write to Buffer 2h.
- 4. Sample MUX A Input AN3; Convert and Write to Buffer 3h.
- 5. Sample MUX A Input AN4; Convert and Write to Buffer 4h.
- 6. Sample MUX A Input AN5; Convert and Write to Buffer 5h.
- 7. Sample MUX A Input AN6; Convert and Write to Buffer 6h.
- 8. Sample MUX A Input AN7; Convert and Write to Buffer 7h.
- 9. Sample MUX A Input AN8; Convert and Write to Buffer 8h.
- 10. Sample MUX A Input AN9; Convert and Write to Buffer 9h.
- 11. Sample MUX A Input AN10; Convert and Write to Buffer Ah.
- 12. Sample MUX A Input AN11; Convert and Write to Buffer Bh.
- 13. Sample MUX A Input AN12; Convert and Write to Buffer Ch.
- 14. Sample MUX A Input AN13; Convert and Write to Buffer Dh.
- 15. Sample MUX A Input AN14; Convert and Write to Buffer Eh.
- 16. Sample MUX A Input AN15; Convert and Write to Buffer Fh.
- 17. Set AD1IF Flag (and generate interrupt, if enabled).
- 18. Repeat (1-16) after Return from Interrupt.


Results Stored in Buffer (after 2 cycles):

| Buffer Address | Buffer Contents at 1st AD1IF Event | Buffer Contents at 2nd AD1IF Event |
|-------------------|------------------------------------|------------------------------------|
| ADC1BUF0 | Sample 1 (AN0, Sample 1) | Sample 17 (AN0, Sample 2) |
| ADC1BUF1 | Sample 2 (AN1, Sample 1) | Sample 18 (AN1, Sample 2) |
| ADC1BUF2 | Sample 3 (AN2, Sample 1) | Sample 19 (AN2, Sample 2) |
| ADC1BUF3 | Sample 4 (AN3, Sample 1) | Sample 20 (AN3, Sample 2) |
| ADC1BUF4 | Sample 5 (AN4, Sample 1) | Sample 21 (AN4, Sample 2) |
| ADC1BUF5 | Sample 6 (AN5, Sample 1) | Sample 22 (AN5, Sample 2) |
| ADC1BUF6 | Sample 7 (AN6, Sample 1) | Sample 23 (AN6, Sample 2) |
| ADC1BUF7 | Sample 8 (AN7, Sample 1) | Sample 24 (AN7, Sample 2) |
| ADC1BUF8 | Sample 9 (AN8, Sample 1) | Sample 25 (AN8, Sample 2) |
| ADC1BUF9 | Sample 10 (AN9, Sample 1) | Sample 26 (AN9, Sample 2) |
| ADC1BUF10 | Sample 11 (AN10, Sample 1) | Sample 27 (AN10, Sample 2) |
| ADC1BUF11 | Sample 12 (AN11, Sample 1) | Sample 28 (AN11, Sample 2) |
| ADC1BUF12 | Sample 13 (AN12, Sample 1) | Sample 29 (AN12, Sample 2) |
| ADC1BUF13 | Sample 14 (AN13, Sample 1) | Sample 30 (AN13, Sample 2) |
| ADC1BUF14 | Sample 15 (AN14, Sample 1) | Sample 31 (AN14, Sample 2) |
| ADC1BUF15 | Sample 16 (AN15, Sample 1) | Sample 32 (AN15, Sample 2) |
| | | · |

51.11.3 Using Dual Buffers

Figure 51-19 and Example 51-10 demonstrate using dual buffers and alternating the buffer fill. Setting the BUFM bit enables dual buffers. In this example, an interrupt is generated after each sample. The BUFM setting does not affect other operational parameters. First, the conversion sequence starts filling the buffer at ADC1BUF0. After the first interrupt occurs, the buffer begins to fill at ADC1BUF8. The BUFS status bit is toggled after each interrupt.





Example 51-10: Converting a Single Channel, Once Per Interrupt, Dual Buffer Mode

A/D Configuration:

- Select AN3 for S/H+ Input (CH0SA<4:0> = 00011)
- Select VR- for S/H- Input (CH0NA<2:0> = 000)
- Configure for No Input Scan (CSCNA = 0)
- Use Only MUX A for Sampling (ALTS = 0)
- Set AD1IF on Every Sample (SMPI<4:0> = 00000)
- Configure Buffer as Dual, 8-Word Segments (BUFM = 1)

Operational Sequence:

- 1. Sample MUX A Input, AN3; Convert and Write to Buffer 0h.
- Set AD1IF Flag (and generate interrupt, if enabled); Write Access Automatically Switches to Alternate Buffer.
- 3. Sample MUX A Input, AN3; Convert and Write to Buffer 8h.
- Set AD1IF Flag (and generate interrupt, if enabled); Write Access Automatically Switches to Alternate Buffer.
- 5. Repeat (1-4).

Results Stored in Buffer (after 2 cycles):


| Buffer Address | Buffer Contents at 1st AD1IF Event |
|-------------------|---------------------------------------|
| ADC1BUF0 | Sample 1 (AN3, Sample 1) |
| ADC1BUF1 | (undefined) |
| ADC1BUF2 | (undefined) |
| ADC1BUF3 | (undefined) |
| ADC1BUF4 | (undefined) |
| ADC1BUF5 | (undefined) |
| ADC1BUF6 | (undefined) |
| ADC1BUF7 | (undefined) |
| ADC1BUF8 | (undefined) |
| ADC1BUF9 | (undefined) |
| ADC1BUFA | (undefined) |
| ADC1BUFB | (undefined) |
| ADC1BUFC | (undefined) |
| ADC1BUFD | (undefined) |
| ADC1BUFE | (undefined) |
| ADC1BUFF | (undefined) |

| Buffer Contents at 2nd AD1IF Event |
|---------------------------------------|
| (undefined) |
| Sample 2 (AN3, Sample 2) |
| (undefined) |

51.11.4 Using Alternating MUX A and MUX B Input Selections

Figure 51-20 and Example 51-11 demonstrate alternate sampling of the inputs assigned to MUX A and MUX B. Setting the ALTS bit enables alternating input selections. The first sample uses the MUX A inputs specified by the CH0SAx and CH0NAx bits. The next sample uses the MUX B inputs, specified by the CH0SBx and CH0NBx bits.

This example also demonstrates use of the dual, 8-word buffers. An interrupt occurs after every 8th sample, resulting in filling 8 words into the buffer on each interrupt.



Example 51-11: Converting Two Inputs by Alternating MUX A and MUX B

A/D Configuration:

- Select AN1 for MUX A S/H+ Input (CH0SA<4:0> = 00001)
- Select VR- for MUX A S/H- Input (CH0NA<2:0> = 000)
- Configure for No Input Scan (CSCNA = 0)
- Select AN15 for MUX B S/H+ Input (CH0SB<4:0> = 11111)
- Select VR- for MUX B S/H- Input (CH0NB<2:0> = 000)
- Alternate MUX A and MUX B for Sampling (ALTS = 1)
- Set AD1IF on Every 8th Sample (SMPI<4:0> = 00111)
- Configure Buffer as Two, 8-Word Segments (BUFM = 1)

Operational Sequence:

- 1. Sample MUX A Input AN1; Convert and Write to Buffer 0h.
- 2. Sample MUX B Input AN15; Convert and Write to Buffer 1h.
- 3. Sample MUX A Input AN1; Convert and Write to Buffer 2h.
- 4. Sample MUX B Input AN15; Convert and Write to Buffer 3h.
- 5. Sample MUX A Input AN1; Convert and Write to Buffer 4h.
- 6. Sample MUX B Input AN15; Convert and Write to Buffer 5h.
- 7. Sample MUX A Input AN1; Convert and Write to Buffer 6h.
- 8. Sample MUX B Input AN15; Convert and Write to Buffer 7h.
- Set AD1IF Flag (and generate interrupt, if enabled); Write Access Automatically Switches to Alternate Buffer.
- 10. Repeat (1-9); Resume Writing to Buffer with Buffer 8h (first address of alternate buffer).

Results Stored in Buffer (after 2 cycles):

| | (| |
|-------------------|---------------------------------------|------------------------------------|
| Buffer Address | Buffer Contents at 1st AD1IF Event | Buffer Contents at 2nd AD1IF Event |
| ADC1BUF0 | Sample 1 (AN1, Sample 1) | (undefined) |
| ADC1BUF1 | Sample 2 (AN15, Sample 1) | (undefined) |
| ADC1BUF2 | Sample 3 (AN1, Sample 2) | (undefined) |
| ADC1BUF3 | Sample 4 (AN15, Sample 2) | (undefined) |
| ADC1BUF4 | Sample 5 (AN1, Sample 3) | (undefined) |
| ADC1BUF5 | Sample 6 (AN15, Sample 3) | (undefined) |
| ADC1BUF6 | Sample 7 (AN1, Sample 4) | (undefined) |
| ADC1BUF7 | Sample 8 (AN15, Sample 4) | (undefined) |
| ADC1BUF8 | (undefined) | Sample 9 (AN1, Sample 5) |
| ADC1BUF9 | (undefined) | Sample 10 (AN15, Sample 5) |
| ADC1BUFA | (undefined) | Sample 11 (AN1, Sample 6) |
| ADC1BUFB | (undefined) | Sample 12 (AN15, Sample 6) |
| ADC1BUFC | (undefined) | Sample 13 (AN1, Sample 7) |
| ADC1BUFD | (undefined) | Sample 14 (AN15, Sample 7) |
| ADC1BUFE | (undefined) | Sample 15 (AN1, Sample 8) |
| ADC1BUFF | (undefined) | Sample 16 (AN15, Sample 8) |
| | | |


51.12 A/D SAMPLING REQUIREMENTS

The Analog Input model of the 12-bit A/D Converter is shown in Figure 51-21. The total sampling time for the A/D is a function of the holding capacitor charge time.

For the A/D Converter to meet its specified accuracy, the charge holding capacitor (Chold) must be allowed to fully charge to the voltage level on the analog input pin. The source impedance (Rs), the interconnect impedance (RIC) and the internal sampling switch (Rss) impedance combine to directly affect the time required to charge Chold. The combined impedance of the analog sources must, therefore, be small enough to fully charge the holding capacitor within the chosen sample time. To minimize the effects of pin leakage currents on the accuracy of the A/D Converter, the maximum recommended source impedance, Rs, is 2.5 k Ω . After the analog input channel is selected (changed), this sampling function must be completed prior to starting the conversion. The internal holding capacitor will be in a discharged state prior to each sample operation.

At least 1 TAD time period should be allowed between conversions for the sample time. For more details, see **Section 51.18** "Electrical Specifications".

Figure 51-21: 12-Bit A/D Converter Analog Input Model




51.13 TRANSFER FUNCTIONS

The transfer functions of the A/D Converter, in 12-bit and 10-bit resolution, are shown in Figure 51-22 and Figure 51-23, respectively. In both cases, the difference of the input voltages, (VINH - VINL), is compared to the reference, ((VR+) - (VR-)).

For the 12-bit transfer function:

- The first code transition occurs when the input voltage is ((VR+) (VR-))/4096 or 1.0 LSb.
- The '0000 0000 0001' code is centered at VR- + (1.5 * ((VR+) (VR-))/4096).
- The '0010 0000 0000' code is centered at VREFL + (2048.5 * ((VR+) (VR-))/4096).
- An input voltage less than VR- + (((VR-) (VR-))/4096) converts as '0000 0000 0000'.
- An input voltage greater than (VR-) + (4096((VR+) (VR-))/4096) converts as '1111 1111 1111'.


Figure 51-22: 12-Bit A/D Transfer Function



For the 10-bit transfer function (when 10-bit resolution is available):

- The first code transition occurs when the input voltage is ((VR+) (VR-))/1024 or 1.0 LSb.
- The '00 0000 0001' code is centered at VR- + (1.5 * (((VR+) (VR-))/1024).
- The '10 0000 0000' code is centered at VREFL + (512.5 * (((VR+) (VR-))/1024).
- An input voltage less than VR- + (((VR-) (VR-))/1024) converts as '00 0000 0000'.
- An input voltage greater than (VR-) + ((1023 (VR+)) (VR-))/1024) converts as '11 1111 1111'.

Figure 51-23: 10-Bit A/D Transfer Function



51.14 A/D ACCURACY/ERROR

Refer to **Section 51.20 "Related Application Notes"** for a list of documents that discuss A/D accuracy.

51.15 OPERATION DURING SLEEP AND IDLE MODES

Sleep and Idle modes are useful for minimizing conversion noise because the digital activity of the CPU, buses and other peripherals is minimized.

51.15.1 CPU Sleep Mode Without RC A/D Clock

When the device enters Sleep mode, all clock sources to the module are shut down and stay at logic '0'.

If Sleep occurs in the middle of a conversion, the conversion is aborted unless the A/D is clocked from its internal RC clock generator. The converter will not resume a partially completed conversion on exiting from Sleep mode.

Register contents are not affected by the device entering or leaving Sleep mode.

51.15.2 CPU Sleep Mode With RC A/D Clock

The A/D module can operate during Sleep mode if the A/D clock source is set to the internal A/D RC oscillator (ADRC = 1). This eliminates digital switching noise from the conversion. When the conversion is completed, the DONE bit will be set and the result is loaded into the A/D Result Buffer n, ADC1BUFn.

If the A/D interrupt is enabled (AD1IE = 1), the device will wake-up from Sleep when the A/D interrupt occurs. Program execution will resume at the A/D Interrupt Service Routine (ISR) if the A/D interrupt is greater than the current CPU priority. Otherwise, execution will continue from the instruction after the PWRSAV instruction that placed the device in Sleep mode.

If the A/D interrupt is not enabled, the A/D module will then be turned off, although the ADON bit will remain set.

To minimize the effects of digital noise on the A/D module operation, the user should select a conversion trigger source that ensures the A/D conversion will take place in Sleep mode. The automatic conversion trigger option can be used for sampling and conversion in Sleep (SSRC<3:0> = 0111). To use the automatic conversion option, the ADON bit should be set in the instruction prior to the PWRSAV instruction.

Note: For the A/D module to operate in Sleep, the A/D clock source must be set to RC (ADRC = 1).

51.15.3 A/D Operation During CPU Idle Mode

The ADSIDL bit (AD1CON1<13>) determines whether the module stops or continues operation on Idle. If ADSIDL = 0, the module will continue normal operation when the device enters Idle mode. If the A/D interrupt is enabled (AD1IE = 1), the device will wake-up from Idle mode when the A/D interrupt occurs. Program execution will resume at the A/D Interrupt Service Routine (ISR) if the A/D interrupt is greater than the current CPU priority. Otherwise, execution will continue from the instruction after the PWRSAV instruction that placed the device in Idle mode.

If ADSIDL = 1, the module will stop in Idle. If the device enters Idle mode in the middle of a conversion, the conversion is aborted. The converter will not resume a partially completed conversion on exiting from Idle mode.

51.15.4 Peripheral Module Disable (PMD) Register

The Peripheral Module Disable (PMD) registers provide a method to disable the A/D module by stopping all clock sources supplied to that module. When a peripheral is disabled via the appropriate PMDx control bit, the peripheral is in a minimum power consumption state. The control and status registers associated with the peripheral will also be disabled, so writes to those registers will have no effect and read values will be invalid. The A/D module is enabled only when the ADC1MD bit in the PMDx register is cleared.

51.16 EFFECTS OF A RESET

A device Reset forces all registers to their Reset state. This forces the A/D module to be turned off and any conversion in progress to be aborted. All pins that are multiplexed with analog inputs will be configured as analog inputs. The corresponding TRIS bits will be set.

The values in the ADC1BUFn registers are not initialized during a Power-on Reset; they will contain unknown data.

51.17 REGISTER MAPS

A summary of the registers associated with the PIC24F 10-Bit A/D Converter with Threshold Detect is provided in Table 51-7.

Table 51-7: A/D Register Map

| File Name | Bit 15 | Bit 14 | Bit 13 | Bit 12 | Bit 11 | Bit 10 | Bit 9 | Bit 8 | Bit 7 | Bit 6 | Bit 5 | Bit 4 | Bit 3 | Bit 2 | Bit 1 | Bit 0 | All Resets |
|--------------------------------|--|--|-----------------------|-------------------------------|-----------------------|-----------------------|-----------------|-----------------|-----------------------|-----------------|-----------------|---------|-----------------|-------------------------------|--------------------------------|--------------------------------|---------------|
| ADC1BUF0 | A/D Data Buffer 0/Threshold Detect Value for AN0 | | | | | | | | | | | | xxxx | | | | |
| ADC1BUF1 | A/D Data Buffer 1/Threshold Detect Value for AN1 | | | | | | | | | | | | xxxx | | | | |
| ADC1BUF2 | | A/D Data Buffer 2/Threshold Detect Value for AN2 | | | | | | | | | | | | xxxx | | | |
| ADC1BUF3 | A/D Data Buffer 3/Threshold Detect Value for AN3 | | | | | | | | | | | | xxxx | | | | |
| ADC1BUF4 | A/D Data Buffer 4/Threshold Detect Value for AN4 | | | | | | | | | | | | xxxx | | | | |
| ADC1BUF5 | A/D Data Buffer/Threshold Detect Value for AN5 | | | | | | | | | | | xxxx | | | | | |
| ADC1BUF6 | | | | | | | A/D Data E | Buffer/Thres | hold Detect \ | /alue for AN6 | 6 | | | | | | xxxx |
| ADC1BUF7 | | | | | | | A/D Data B | uffer 7/Thres | shold Detect | Value for AN | 17 | | | | | | xxxx |
| ADC1BUF8 | | | | | | | A/D Data B | uffer 8/Thres | shold Detect | Value for AN | 18 | | | | | | xxxx |
| ADC1BUF9 | | | | | | | A/D Data B | uffer 9/Thres | shold Detect | Value for AN | 19 | | | | | | xxxx |
| • | | | | | | | | | • | | | | | | | | • |
| • | | | | | | | | | • | | | | | | | | • |
| ADC1BUFn ⁽¹⁾ | | | | | | | A/D D-4- D | | · | \ /=l | l | | | | | | • |
| | ADON | | ADSIDL | DMABM ⁽²⁾ | DMA EN(2) | MODE12 ⁽²⁾ | FORM1 | FORM0 | shold Detect SSRC3 | SSRC2 | ssrc1 | SSRC0 | | 40414 | CAMP | DONE | XXXX |
| AD1CON1 | ADON | — — | | OFFCAL | DMAEN ⁽²⁾ | | | | | | | | - CMPI4 | ASAM | SAMP | | 0000 |
| AD1CON2 | PVCFG1 | PVCFG0 | NVCFG | | BUFREGEN | CSCNA | - | - | BUFS | SMPI4 | SMPI3 | SMPI2 | SMPI1 | SMPI0 | BUFM | ALTS | 0000 |
| AD1CON3 AD1CON4 ⁽⁴⁾ | ADRC | EXTSAM | PUMPEN ⁽²⁾ | SAMC4 | SAMC3 | SAMC2 | SAMC1 | SAMC0 | ADCS7 | ADCS6 | ADCS5 | ADCS4 | ADCS3 | ADCS2 DMABL2 ^(2,5) | ADCS1 DMABL1 ^(2,5) | ADCS0 DMABL0 ^(2,5) | 0000 |
| AD1CON407 | — — — — — — — — — — — — — — — — — — — | - CLIONIDA | CH0NB0 | — CLIOCD4 | — — | — CLI00D0 | — CLIOCD4 | — CLIOCDO | - | - | - | CH0SA4 | - | CH0SA2 | | CH0SA0 | + |
| AD1CHS AD1CSSH(3) | CH0NB2 CSS31 | CH0NB1 CSS30 | CSS29 | CH0SB4 CSS28 | CH0SB3 CSS27 | CH0SB2 CSS26 | CH0SB1 CSS25 | CH0SB0 CSS24 | CH0NA2 CSS23 | CH0NA1 CSS22 | CH0NA0 CSS21 | CSS20 | CH0SA3 CSS19 | CSS18 | CH0SA1 CSS17 | CSS16 | 0000 |
| | | | | | | | | | | | | | | | | | XXXX |
| AD1CSSL | CSS15 | CSS14 | CSS13 | CSS12 BGREQ ⁽²⁾ | CSS11 | CSS10 | CSS9 | CSS8 | CSS7 | CSS6 | CSS5 | CSS4 | CSS3 | CSS2 | CSS1 | CSS0 | 0000 |
| AD1CON5 | ASEN | LPEN | CTMREQ | | VRSREQ ⁽²⁾ | | ASINT1 | ASINT0 | - | - | - | - | WM1 | WM0 | CM1 | CM0 | 0000 |
| AD1CHITH(3) | CHH31 | CHH30 | CHH29 | CHH28 | CHH27 | CHH26 | CHH25 | CHH24 | CHH23 | CHH22 | CHH21 | CHH20 | CHH19 | CHH18 | CHH17 | CHH16 | 0000 |
| ADCCHITL | CHH15 | CHH14 | CHH13 | CHH12 | CHH11 | CHH10 | CHH9 | CHH8 | CHH7 | CHH6 | CHH5 | CHH4 | CHH3 | CHH2 | CHH1 | CHH0 | 0000 |
| AD1CTMENH ⁽³⁾ | CTMEN31 | CTMEN30 | CTMEN29 | CTMEN28 | CTMEN27 | CTMEN26 | CTMEN25 | CTMEN24 | CTMEN23 | CTMEN22 | CTMEN21 | CTMEN20 | CTMEN19 | CTMEN18 | CTMEN17 | CTMEN16 | 0000 |
| AD1CTMENL | CTMEN15 | CTMEN14 | CTMEN13 | CTMEN12 | CTMEN11 | CTMEN10 | CTMEN9 | CTMEN8 | CTMEN7 | CTMEN6 | CTMEN5 | CTMEN4 | CTMEN3 | CTMEN2 | CTMEN1 | CTMEN0 | 0000 |

Legend: x = unknown value on Reset, --- = unimplemented, read as '0'. Reset values are shown in hexadecimal.


- Note 1: The number of AD1BUF registers is equal to at least the number of external analog channels, rounded up the nearest even number. Refer to the specific device data sheet for the exact number.
 - 2: These bits are not implemented in all devices. Refer to the specific device data sheet.
 - 3: These registers and bits are implemented in devices with more than 16 analog channels only. Not all bits may be implemented in 'H' registers. Refer to the specific device data sheet.
 - 4: AD1CON4 is not implemented on all devices. For more information, refer to the specific device data sheet.
 - 5: The DMABL<2:0> bits are only used when AD1CON1<11> = 1; otherwise, their value is ignored.



Section 51. 12-Bit A/D Converter with Threshold Detect

51.18 ELECTRICAL SPECIFICATIONS

Figure 51-24: A/D Conversion Timing



- Note 1: If the A/D clock source is selected as RC, a time of Tcy is added before the A/D clock starts. This allows the SLEEP instruction to be executed.
 - 2: This is a minimal RC delay (typically 100 ns) which also disconnects the holding capacitor from the analog input.

Table 51-8: A/D Conversion Requirements⁽⁴⁾

| Param No. | Symbol | Characteristic | Min | Тур | Max | Units | Conditions |
|--------------|--------|--|-----|----------|----------|-------|---|
| AD61 | tpss | Sample Start Delay from Setting SAMP | 2 | _ | 3 | TAD | |
| AD130 | TAD | A/D Clock Period | 300 | _ | _ | ns | Tosc-based |
| | | | _ | 250 | _ | ns | A/D RC mode |
| AD131 | TCNV | Conversion Time (not including acquisition time) | _ | 12 14 | _ | TAD | 10-bit result 12-bit result (Note 1) |
| AD132 | TACQ | Acquisition Time | _ | | 750 | ns | (Note 2) |
| AD135 | Tswc | Switching Time from Convert to Sample | _ | _ | (Note 3) | | |
| AD137 | TDIS | Discharge Time | 1 | _ | _ | TAD | |
| | | A/D Stabilization Time (from setting ADON to setting SAMP) | _ | 300 | _ | ns | |

- Note 1: The ADC1BUFn register may be read on the following TcY cycle.
 - 2: The time for the holding capacitor to acquire the "New" input voltage when the voltage changes full scale after the conversion (AVDD to AVSS or AVSS to AVDD).
 - 3: On the following cycle of the device clock.
 - **4:** Specifications may change between devices. Refer to the family data sheet for information specific to a given device.

51.19 DESIGN TIPS

Question 1: How can I optimize the system performance of the A/D Converter?

Answer: There are three main things to consider in optimizing A/D performance:

- 1. Make sure you are meeting all of the timing specifications. If you are turning the module off and on, there is a minimum delay you must wait before taking a sample. If you are changing input channels, there is a minimum delay you must wait for this as well, and finally, there is TAD, which is the time selected for each bit conversion. This is selected in AD1CON3 and should be within a certain range, as specified in Section 51.18 "Electrical Specifications". If TAD is too short, the result may not be fully converted before the conversion is terminated, and if TAD is made too long, the voltage on the sampling capacitor can decay before the conversion is complete. These timing specifications are provided in the "Electrical Characteristics" section of the device data sheets.
- 2. Often, the source impedance of the analog signal is high (greater than $2.5 \text{ k}\Omega$), so the current drawn from the source by leakage, and to charge the sample capacitor, can affect accuracy. If the input signal does not change too quickly, try putting a $0.1 \mu F$ capacitor on the analog input. This capacitor will charge to the analog voltage being sampled and supply the instantaneous current needed to charge the internal holding capacitor.
- 3. Put the device into Sleep mode before the start of the A/D conversion. The RC clock source selection is required for conversions in Sleep mode. This technique increases accuracy, because digital noise from the CPU and other peripherals is minimized.

Question 2: Do you know of a good reference on A/D Converters?

Answer: A good reference for understanding A/D conversions is the "Analog-Digital Conversion Handbook" third edition, published by Prentice Hall (ISBN 0-13-03-2848-0).

Question 3: My combination of channels/samples and samples/interrupt is greater than the size of the buffer. What will happen to the buffer?

Answer: This configuration is not recommended. The buffer will contain unknown results.

51.20 RELATED APPLICATION NOTES

Note:

This section lists application notes that are related to this section of the manual. These application notes may not be written specifically for the PIC24F device family, but the concepts are pertinent and could be used with modification and possible limitations. The current application notes related to the 12-Bit A/D Converter with Threshold Detect module are:

Title Application Note #

Using the Analog-to-Digital (A/D) Converter Four-Channel Digital Voltmeter with Display and Keyboard Understanding A/D Converter Performance Specifications AN546 AN557 AN693

Please visit the Microchip web site (www.microchip.com) for additional application notes and code examples for the PIC24F family of devices.

51.21 REVISION HISTORY

Revision A (March 2011)

This is the initial released revision of this document.

Revision B (December 2011)

This revision includes the following updates:

- Updated 12-Bit A/D Converter Block Diagram (see Figure 51-1)
- Added AD1CON4 in Section 51.3.1 "Control Registers"
- The following updates were made to the AD1CON1 register (see Register 51-1):
 - Updated the definitions for DMAEN and DMABM bits
 - Added Note 3 and Note 4
- The following updates were made to the AD1CON2 register (see Register 51-2):
 - Updated the definitions for bits 6-2 (SMPI<4:0>)
 - Updated Note 1
 - Added Note 2
- Added new AD1CON4 register (see Register 51-4)
- Added note in AD1CON5 register (see Register 51-5)
- Added a new paragraph on the DMAEN bit in Section 51.7.5 "Generating A/D Interrupts"
- Added Section 51.9 "Extended DMA Operations"
- Updated content in Section 51.10.4 "Threshold Detect Interrupts"
- Updated code in Example 51-6
- Updated code in Example 51-8

Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

Trademarks

The Microchip name and logo, the Microchip logo, dsPIC, KEELOQ, KEELOQ logo, MPLAB, PIC, PICmicro, PICSTART, PIC³² logo, rfPIC and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, HI-TECH C, Linear Active Thermistor, MXDEV, MXLAB, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, HI-TIDE, In-Circuit Serial Programming, ICSP, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, mTouch, Omniscient Code Generation, PICC, PICC-18, PICDEM, PICDEM.net, PICkit, PICtail, REAL ICE, rfLAB, Select Mode, Total Endurance, TSHARC, UniWinDriver, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2011, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

Printed on recycled paper.

ISBN: 978-1-61341-869-7

QUALITY MANAGEMENT SYSTEM

CERTIFIED BY DNV

ISO/TS 16949:2009

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



Worldwide Sales and Service

AMERICAS

Corporate Office 2355 West Chandler Blvd.

Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277

Technical Support: http://www.microchip.com/

support

Web Address: www.microchip.com

Atlanta

Duluth, GA Tel: 678-957-9614 Fax: 678-957-1455

Boston

Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago Itasca, IL

Tel: 630-285-0071 Fax: 630-285-0075

Cleveland

Independence, OH Tel: 216-447-0464 Fax: 216-447-0643

Dallas

Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

Detroit

Farmington Hills, MI Tel: 248-538-2250 Fax: 248-538-2260

Indianapolis Noblesville, IN Tel: 317-773-8323

Fax: 317-773-5453

Los Angeles

Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608

Santa Clara

Santa Clara, CA Tel: 408-961-6444 Fax: 408-961-6445

Toronto

Mississauga, Ontario,

Canada

Tel: 905-673-0699 Fax: 905-673-6509

ASIA/PACIFIC

Asia Pacific Office

Suites 3707-14, 37th Floor Tower 6, The Gateway Harbour City, Kowloon Hong Kong

Tel: 852-2401-1200 Fax: 852-2401-3431

Australia - Sydney Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

China - Beijing Tel: 86-10-8569-7000 Fax: 86-10-8528-2104

China - Chengdu Tel: 86-28-8665-5511 Fax: 86-28-8665-7889

China - Chongqing Tel: 86-23-8980-9588 Fax: 86-23-8980-9500

China - Hangzhou Tel: 86-571-2819-3187 Fax: 86-571-2819-3189

China - Hong Kong SAR Tel: 852-2401-1200 Fax: 852-2401-3431

China - Nanjing Tel: 86-25-8473-2460 Fax: 86-25-8473-2470

China - Qingdao Tel: 86-532-8502-7355 Fax: 86-532-8502-7205

China - Shanghai Tel: 86-21-5407-5533 Fax: 86-21-5407-5066

China - Shenyang Tel: 86-24-2334-2829 Fax: 86-24-2334-2393

China - Shenzhen Tel: 86-755-8203-2660 Fax: 86-755-8203-1760

China - Wuhan Tel: 86-27-5980-5300 Fax: 86-27-5980-5118

China - Xian
Tel: 86-29-8833-7252

Fax: 86-29-8833-7256

China - Xiamen

Tel: 86-592-2388138

Fax: 86-592-2388130

China - Zhuhai Tel: 86-756-3210040 Fax: 86-756-3210049

ASIA/PACIFIC

India - Bangalore

Tel: 91-80-3090-4444 Fax: 91-80-3090-4123

India - New Delhi Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune Tel: 91-20-2566-1512 Fax: 91-20-2566-1513

Japan - Osaka Tel: 81-66-152-7160 Fax: 81-66-152-9310

Japan - Yokohama Tel: 81-45-471- 6166 Fax: 81-45-471-6122

Korea - Daegu Tel: 82-53-744-4301 Fax: 82-53-744-4302

Korea - Seoul Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Kuala Lumpur Tel: 60-3-6201-9857

Fax: 60-3-6201-9859 **Malaysia - Penang** Tel: 60-4-227-8870 Fax: 60-4-227-4068

Philippines - Manila Tel: 63-2-634-9065 Fax: 63-2-634-9069

Singapore

Tel: 65-6334-8870 Fax: 65-6334-8850

Taiwan - Hsin Chu Tel: 886-3-5778-366 Fax: 886-3-5770-955

Taiwan - Kaohsiung Tel: 886-7-536-4818 Fax: 886-7-330-9305

Taiwan - Taipei Tel: 886-2-2500-6610 Fax: 886-2-2508-0102

Thailand - Bangkok Tel: 66-2-694-1351 Fax: 66-2-694-1350

EUROPE

Austria - Wels

Tel: 43-7242-2244-39 Fax: 43-7242-2244-393

Denmark - Copenhagen Tel: 45-4450-2828

Fax: 45-4485-2829
France - Paris

Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

Germany - Munich Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

Italy - Milan

Tel: 39-0331-742611 Fax: 39-0331-466781

Netherlands - Drunen Tel: 31-416-690399 Fax: 31-416-690340

Spain - Madrid Tel: 34-91-708-08-90 Fax: 34-91-708-08-91

UK - Wokingham Tel: 44-118-921-5869 Fax: 44-118-921-5820

11/29/11