

# Section 52. Flash Memory with Support for Live Update

### **HIGHLIGHTS**

This section of the manual contains the following topics:

52.1	Introduction	52-2
52.2	Control Registers	52-4
52.3	Memory Configuration	52-14
52.4	Boot Flash Memory (BFM) Partitions	52-16
52.5	Program Flash Memory (PFM) Partitions	52-17
52.6	Error Correcting Code (ECC) and Flash Programming	52-18
52.7	Interrupts	52-19
52.8	Error Detection	52-20
52.9	NVMKEY Register Unlocking Sequence	52-21
52.10	Word Programming	52-23
52.11	Quad Word Programming	52-24
52.12	Row Programming	52-25
52.13	Page Erase	52-26
52.14	Program Flash Memory Erase	52-27
52.15	Operation in Power-Saving Modes	52-28
52.16	Operation in Debug Mode	52-28
52.17	Effects of Various Resets	52-28
52.18	Related Application Notes	52-29
52.19	Revision History	52-30

Note:

This family reference manual section is meant to serve as a complement to device data sheets. Depending on the device variant, this manual section may not apply to all PIC32 devices.

Please consult the note at the beginning of the "Flash Program Memory" chapter in the current device data sheet to check whether this document supports the device you are using.

Device data sheets and family reference manual sections are available for download from the Microchip Worldwide Web site at: http://www.microchip.com

#### 52.1 INTRODUCTION

This document describes techniques for programming the Flash memory on PIC32 devices with dual flash memory banks. These devices contain two banks of flash memory each with their own Boot Flash Memory (BFM) partition and Program Flash Memory (PFM) partition for storing user code or non-volatile data. The dual memory bank feature allows Flash to be programmed in one bank while executing from another for live updates of program memory. There are three methods by which the user can program this memory:

- Run-Time Self-Programming (RTSP) performed by the user's software
- In-Circuit Serial Programming<sup>™</sup> (ICSP<sup>™</sup>) performed using a serial data connection to the device, which allows much faster programming than RTSP
- Enhanced Joint Test Action Group Programming (EJTAG) performed by an EJTAG-capable programmer, using the EJTAG port of the device

RTSP techniques are described in this chapter. The ICSP and EJTAG methods are described in the "PIC32 Flash Programming Specification" (DS61145), which is available for download from the Microchip Web site (www.microchip.com).

#### 52.1.1 Run-Time Self-Programming (RTSP)

RTSP is used for applications where field upgradable firmware or non-volatile data storage is needed. Software that implements field upgradable firmware capability is called a Bootloader. Non-volatile data storage in flash memory is often implemented using EEPROM simulation software which incorporates wear leveling that extends the usable life of the memory used for data storage. Complete example code for both of these techniques is available for download from the Microchip Web site (www.microchip.com).

#### 52.1.2 Dual Memory Bank

The dual memory bank features supplied on these PIC32 devices lend significant advantages for Bootloader and EEPROM simulation software. Dual flash memory banks allow code to be executing in one bank, while another bank is being erased or programmed, thereby avoiding CPU stalling during programming operations. Flash banks can be aliased or mapped into memory and selected for execution at start-up, either automatically or manually, allowing for high reliability field updates to application and Bootloader software. Error-Correcting Code (ECC) memory has also been incorporated, which extends the usable life of the Flash memory.

#### 52.1.2.1 FLASH PARTITIONS

Each bank of Flash memory is divided into two logical Flash partitions: the PFM and the BFM. The two BFM partitions are aliased into two regions at start-up. The order of the aliasing is determined by the Flash Sequence Codes (FSEQs) stored in special Configuration words in each bank at start-up. This ordering determines which partition of BFM memory is selected to be used as the start-up code upon a device Reset. The PFM partitions of each bank are mapped into upper and lower regions of the memory map. Start-up code, executing from BFM, can select the mapping of the two PFM partitions into the two PFM regions. Refer to the "Memory Organization" chapter in the specific device data sheet for detailed information on devices memory maps and the available options for Flash memory.

## **52**

#### 52.1.3 Addressing

PIC32 devices implement two address schemes: virtual and physical. Virtual addresses are exclusively used by the CPU to fetch and execute instructions as well as access peripherals. When programming or erasing Flash memory, the physical addresses is always the address used for the target operation.

Code protection on BFM is implemented by page, is enabled at reset and must be disabled prior to programming any BFM. Code protection of PFM is implemented using a watermark register, is disabled at reset and must be configured in the startup code at initialization to avoid inadvertent program or erasure of PFM.

#### 52.2 CONTROL REGISTERS

Flash program, erase, and write protection operations are controlled using the following Non-Volatile Memory (NVM) control registers:

#### • NVMCON: Programming Control Register

The NVMCON register is the control register for Flash program/erase operations. This register is used to select the operation to be performed, initiate the operation, and provide status of the result when the operation is complete.

#### NVMKEY: Programming Unlock Register

NVMKEY is a write-only register that is used to implement an unlock sequence to help prevent accidental writes/erasures of Flash or EEPROM memory or accidental changing the NVMSWAP and write permission settings.

#### NVMADDR: Flash Address Register

This register is used to store the physical target address for row, quad word and word programming as well as page erasing.

#### NVMDATAx: Flash Data Register ('x' = 0-3)

These registers hold the data to be programmed during Flash Word program operations. NVMDATA3 through NVMDATA1 are used for Quad Word (128-bit) programming while only NVMDATA0 is used for Word (32-bit) Programming.

#### NVMSRCADDR: Source Data Address Register

This register is used to point to the physical address of the data to be programmed when executing a row program operation.

#### • NVMPWP: Program Flash Write-Protect Register

This register is used to set the boundary of the last write protected page in the Program Flash partition.

#### • NVMBWP: Flash Boot (Page) Write-Protect Register

This register is used to configure which Boot Flash partition pages are write-protected.

Table 52-1 provides a brief summary of all of the Flash-programming-related registers. Corresponding registers appear after the summary, followed by a detailed description.

Table 52-1: Flash Controller SFR Summary

Name	Bit Range	Bit 31/15	Bit 30/14	Bit 29/13	Bit 28/12	Bit 27/11	Bit 26/10	Bit 25/9	Bit 24/8	Bit 23/7	Bit 22/6	Bit 21/5	Bit 20/4	Bit 19/3	Bit 118/2	Bit 17/1	Bit 16/0
NVMCON <sup>(1)</sup>	31:24	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_
	23:16	WR	WREN	WRERR	LVDERR	_	_	_	_	SWAP	_	_	_		NVMO	P<3:0>	
NVMKEY	31:24							N	VMKEY<	:31:16>	•						
	23:16							1	NVMKEY-	<15:0>							
NVMADDR <sup>(1)</sup>	31:24							N\	/MADDR	<31:16>							
	23:16							N	VMADDF	R<15:0>							
NVMDATA3	31:24							N'	VMDATA-	<31:16>							
	23:16							N	IVMDATA	<15:0>							
NVMDATA2	31:24							N'	VMDATA-	<31:16>							
	23:16							N	IVMDATA	<15:0>							
NVMDATA1	31:24							N'	VMDATA-	<31:16>							
	23:16							N	IVMDATA	<15:0>							
NVMDATA0	31:24							N'	VMDATA-	<31:16>							
	23:16							N	IVMDATA	<15:0>							
NVMSRCADDR	31:24							NVM	ISRCADE	DR<31:16>							
	23:16							NVN	/ISRCAD	DR<15:0>							
NVMPWP	31:24	PWPULOCK	_	_	_	_	_	_	_				PWP<23	3:16>			
	15:8		•					•	PWP<1	5:0>							
NVMBWP <sup>(1)</sup>	31:24	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_	_
	23:16	LBWPULOCK	_	_	LBWP4	LBWP3	LBWP2	LBWP1	LBWP0	UBWPULOCK	_	_	UBWP4	UBWP3	UBWP2	UBWP1	UBWP0

**Legend:** — = unimplemented, read as '0'.

Note 1: This register has an associated Clear, Set, and Invert register at an offset of 0x4, 0x8, and 0xC bytes, respectively. These registers have the same name with CLR, SET, or INV appended to the end of the register name (e.g., NVMCONCLR). Writing a '1' to any bit position in these registers will clear, set, or invert valid bits in the associated register. Reads from these registers should be ignored.

Section 52. Flash Memory with Support for Live Update

Register 52-1: NVMCON: Programming Control Register

Bit Range	Bit 31/23/15/7	Bit 30/22/14/6	Bit 29/21/13/5	Bit 28/20/12/4	Bit 27/19/11/3	Bit 26/18/10/2	Bit 25/17/9/1	Bit 24/16/8/0
24.24	U-0	U-0	U-0	U-0	U-0	U-0	U-0	U-0
31:24	_		-			-	_	_
22.40	U-0	U-0	U-0	U-0	U-0	U-0	U-0	U-0
23:16	_	_	_	_	-	_	_	_
45.0	R/W-0, HC	R/W-0	R-0, HS, HC	R-0, HS, HC	U-0	U-0	U-0	U-0
15:8	WR <sup>(2)</sup>	WREN <sup>(2)</sup>	WRERR <sup>(2)</sup>	LVDERR(2)		_	_	_
7.0	R/W-0	U-0	U-0	U-0	R/W-0	R/W-0	R/W-0	R/W-0
7:0	SWAP	_	_	_		NVMOP	<3:0>	·

Legend:HS = Set by HardwareHC = Cleared by HardwareR = Readable bitW = Writable bitU = Unimplemented bit, read as '0'-n = Value at POR'1' = Bit is set'0' = Bit is clearedx = Bit is unknown

bit 31-16 Unimplemented: Read as '0'

bit 15 WR: Write Control bit<sup>(2)</sup>

This bit cannot be cleared and can be set only when WREN = 1 and the unlock sequence has been performed.

- 1 = Initiate a Flash operation
- 0 = Flash operation is complete or inactive
- bit 14 WREN: Write Enable bit<sup>(2)</sup>
  - 1 = Enable writes to the WR bit and the SWAP bit and disables writes to the NVMOP<3:0> bits
  - 0 = Disable writes to WR bit and the SWAP bit and enables writes to the NVMOP<3:0> bits
- bit 13 **WRERR:** Write Error bit<sup>(2)</sup>

This bit can be cleared only by setting the NVMOP<3:0> bits = 0000 (NOP) and initiating a Flash operation.

- 1 = Program or erase sequence did not complete successfully
- 0 = Program or erase sequence completed normally
- bit 12 LVDERR: Low-Voltage Detect Error bit<sup>(2)</sup>

This bit can be cleared only by setting the NVMOP<3:0> bits = 0000 (NOP) and initiating a Flash operation.

- 1 = Low-voltage condition was detected during a program and erase operation (possible data corruption, if WRERR is set)
- 0 = No low-voltage condition occurred during a program or erase operation
- bit 11-8 Unimplemented: Read as '0'
- bit 7 SWAP: Program Flash Bank Swap Control bit
  - 1 = Program Flash Bank 2 is mapped to the lower mapped region and program Flash Bank 1 is mapped to the upper mapped region
  - 0 = Program Flash Bank 1 is mapped to the lower mapped region and program Flash Bank 2 is mapped to the upper mapped region
- bit 6-4 Unimplemented: Read as '0'
- Note 1: This operation results in a "no operation" (NOP) when the Dynamic Flash ECC Configuration bits = 00 (FECCCTRL<1:0> (DVCFG0<9:8>)), which enables ECC at all times. For all other FECCTRL<1:0> bit settings, this command will execute, but will not write the ECC bits for the word and can cause DED errors if dynamic Flash ECC is enabled (FECCTRL<1:0> = 01).
  - 2: This bit is only reset on a Power-on reset (POR) and are unaffected by other reset sources.

#### Register 52-1: NVMCON: Programming Control Register (Continued)

bit 3-0 **NVMOP<3:0>:** NVM Operation bits<sup>(2)</sup>

These bits are only writable when WREN = 0.

1111 = Reserved

•

- 1000 = Reserved
- 0111 = Program erase operation: erase all of program Flash memory (all pages must be unprotected, PWP<23:0> = 0x000000)
- 0110 = Upper program Flash memory erase operation: erases only the upper mapped region of program Flash (all pages in that region must be unprotected)
- 0101 = Lower program Flash memory erase operation: erases only the lower mapped region of program Flash (all pages in that region must be unprotected)
- 0100 = Page erase operation: erases page selected by NVMADDR, if it is not write-protected
- 0011 = Row program operation: programs row selected by NVMADDR, if it is not write-protected
- 0010 = Quad Word (128-bit) program operation: programs the 128-bit Flash word selected by NVMADDR, if it is not write-protected
- 0001 = Word program operation: programs word selected by NVMADDR, if it is not write-protected (1)
- 0000 = No operation
- Note 1: This operation results in a "no operation" (NOP) when the Dynamic Flash ECC Configuration bits = 00 (FECCTRL<1:0> (DVCFG0<9:8>)), which enables ECC at all times. For all other FECCTRL<1:0> bit settings, this command will execute, but will not write the ECC bits for the word and can cause DED errors if dynamic Flash ECC is enabled (FECCTRL<1:0> = 01).
  - 2: This bit is only reset on a Power-on reset (POR) and are unaffected by other reset sources.

## **PIC32 Family Reference Manual**

Register 52-2: NVMKEY: Programming Unlock Register

Bit Range	Bit 31/23/15/7	Bit 30/22/14/6	Bit 29/21/13/5	Bit 28/20/12/4	Bit 27/19/11/3	Bit 26/18/10/2	Bit 25/17/9/1	Bit 24/16/8/0			
24.24	W-0	W-0	W-0	W-0	W-0	W-0	W-0	W-0			
31:24	NVMKEY<31:24>										
00.40	W-0	W-0	W-0	W-0	W-0	W-0	W-0	W-0			
23:16	NVMKEY<23:16>										
45.0	W-0	W-0	W-0	W-0	W-0	W-0	W-0	W-0			
15:8				NVMKE	EY<15:8>						
7.0	W-0	W-0	W-0	W-0	W-0	W-0	W-0	W-0			
7:0				NVMK	EY<7:0>						

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

#### bit 31-0 NVMKEY<31:0>: Unlock Register bits

These bits are write-only, and read as '0' on any read.

**Note:** This register is used as part of the unlock sequence to prevent inadvertent writes to the PFM.

#### Register 52-3: NVMADDR: Flash Address Register

Bit Range	Bit 31/23/15/7	Bit 30/22/14/6	Bit 29/21/13/5	Bit 28/20/12/4	Bit 27/19/11/3	Bit 26/18/10/2	Bit 25/17/9/1	Bit 24/16/8/0		
24.24	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
31:24				NVMADI	DR<31:24>					
00.40	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
23:16	NVMADDR<23:16>									
15.0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
15:8	NVMADDR<15:8>									
7.0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
7:0				NVMAD	DR<7:0>					

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

#### bit 31-0 NVMADDR<31:0>: Flash Address bits

NVMOP<3:0> Selection (see Note 1)	Flash Address Bits
Page Erase	Address identifies the page to erase (lower address bits are ignored based on device page size)
Row Program	Address identifies the row to program (lower address bits are ignored based on device row size)
Word Program (32-bit)	Address identifies the word to program (NVMADDR<1:0> are ignored)
Quad Word Program (128-bit)	Address identifies the quad word (128-bit) to program (NVMADDR<3:0> bits are ignored).

**Note 1:** For all other NVMOP<3:0> bit settings, the Flash address is ignored.

**Note:** The bits in this register are only reset on a Power-on reset (POR) and are unaffected by other reset sources.

Register 52-4: NVMDATAx: Flash Data Register ('x' = 0-3)

Bit Range	Bit 31/23/15/7	Bit 30/22/14/6	Bit 29/21/13/5	Bit 28/20/12/4	Bit 27/19/11/3	Bit 26/18/10/2	Bit 25/17/9/1	Bit 24/16/8/0		
24.24	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
31:24				NVMDA <sup>-</sup>	TA<31:24>					
00.40	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
23:16	NVMDATA<23:16>									
45.0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
15:8				NVMDA	NTA<15:8>					
7.0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
7:0				NVMD	ATA<7:0>					

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

#### bit 31-0 NVMDATA<31:0>: Flash Data bits

Word Program: Writes NVMDATA0 to the target Flash address defined in NVMADDR Quad Word Program: Writes NVMDATA3:NVMDATA2:NVMDATA1:NVMDATA0 to the target Flash address defined in NVMADDR. NVMDATA0 is the least significant instruction word.

**Note:** The bits in this register are only reset by a Power-on Reset (POR). Other reset sources do not affect its contents.

Register 52-5: NVMSRCADDR: Source Data Address Register

					2					
Bit Range	Bit 31/23/15/7	Bit 30/22/14/6	Bit 29/21/13/5	Bit 28/20/12/4	Bit 27/19/11/3	Bit 26/18/10/2	Bit 25/17/9/1	Bit 24/16/8/0		
24.24	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
31:24				NVMSRCA	DDR<31:24	•				
00.40	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
23:16	NVMSRCADDR<23:16>									
45.0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
15:8				NVMSRC/	ADDR<15:8>					
7.0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
7:0				NVMSRC	ADDR<7:0>					

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

#### bit 31-0 NVMSRCADDR<31:0>: Source Data Address bits

The system physical address of the data to be programmed into the Flash when the NVMOP<3:0> bits (NVMCON<3:0>) are set to perform row programming.

**Note:** The bits in this register are only reset by a Power-on Reset (POR). Other reset sources do not affect its contents.

Register 52-6:	NVMPWP: Program Flash	Write-Protect Register
NEGISIEI JZ-U.	INVIVIENTE FIOGRAFII I IASII	AALITE-LIOTECT IZERIQUE

Bit Range	Bit 31/23/15/7	Bit 30/22/14/6	Bit 29/21/13/5	Bit 28/20/12/4	Bit 27/19/11/3	Bit 26/18/10/2	Bit 25/17/9/1	Bit 24/16/8/0			
24.04	R/W-1	U-0	U-0	U-0	U-0	U-0	U-0	U-0			
31:24	PWPULOCK	_	_	_	_	_	_	_			
00:40	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0			
23:16	PWP<23:16>										
45.0	R/W-0	R/W-0	R-0	R-0	R-0	R-0	R-0	R-0			
15:8				PWP<	15:8>						
7.0	R-0	R-0	R-0	R-0	R-0	R-0	R-0	R-0			
7:0				PWP<	:7:0>						

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 31 PWPULOCK: Program Flash Memory Page Write-protect Unlock bit

1 = Register is not locked and can be modified

0 = Register is locked and cannot be modified

This bit is only clearable and cannot be set except by any reset.

bit 30-24 Unimplemented: Read as '0'

bit 23-0 PWP<23:0>: Flash Program Write-protect (Page) Address bits

Physical program Flash memory from address 0x1D000000 to address 0x1Dxxxxxx is write protected, where 'xxxxxx' is specified by PWP<23:0>. When PWP<23:0> has a value of '0', write protection is disabled for the entire program Flash. If the specified address falls within the page, the entire page and all pages below the current page will be protected.

**Note:** This register is only writable when the NVMKEY unlock sequence has been followed and the PWPULOCK bit is set.

Register 52-7: NVMBWP: Flash Boot (Page) Write-Protect Register

			\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \					
Bit Range	Bit 31/23/15/7	Bit 30/22/14/6	Bit 29/21/13/5	Bit 28/20/12/4	Bit 27/19/11/3	Bit 26/18/10/2	Bit 25/17/9/1	Bit 24/16/8/0
24.24	U-0	U-0	U-0	U-0	U-0	U-0	U-0	U-0
31:24	_	_	_	_	_	_	_	_
00:40	U-0	U-0	U-0	U-0	U-0	U-0	U-0	U-0
23:16	_	_	_	_	_	_	_	_
45.0	R/W-1	U-0	U-0	R/W-1	R/W-1	R/W-1	R/W-1	R/W-1
15:8	LBWPULOCK	_	_	LBWP4 <sup>(1)</sup>	LBWP3 <sup>(1)</sup>	LBWP2 <sup>(1)</sup>	LBWP1 <sup>(1)</sup>	LBWP0 <sup>(1)</sup>
7.0	R/W-1	r-1	U-0	R/W-1	R/W-1	R/W-1	R/W-1	R/W-1
7:0	UBWPULOCK	_	1	UBWP4 <sup>(2)</sup>	UBWP3 <sup>(2)</sup>	UBWP2 <sup>(2)</sup>	UBWP1 <sup>(2)</sup>	UBWP0 <sup>(2)</sup>

**Legend:** r = Reserved

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 31-16 Unimplemented: Read as '0'

bit 15 **LBWPULOCK:** Lower Boot Alias Write-protect Unlock bit

1 = LBWPx bits are not locked and can be modified

0 = LBWPx bits are locked and cannot be modified

This bit is only clearable and cannot be set except by any reset.

bit 14-13 Unimplemented: Read as '0'

bit 12 **LBWP4:** Lower Boot Alias Page 4 Write-protect bit<sup>(1)</sup>

1 = Write protection enabled

0 = Write protection disabled

bit 11 **LBWP3:** Lower Boot Alias Page 3 Write-protect bit<sup>(1)</sup>

1 = Write protection enabled

0 = Write protection disabled

bit 10 **LBWP2:** Lower Boot Alias Page 2 Write-protect bit<sup>(1)</sup>

1 = Write protection enabled

0 = Write protection disabled

bit 9 LBWP1: Lower Boot Alias Page 1 Write-protect bit (1)

1 = Write protection enabled

0 = Write protection disabled

bit 8 **LBWP0:** Lower Boot Alias Page 0 Write-protect bit<sup>(1)</sup>

1 = Write protection enabled

0 = Write protection disabled

bit 7 **UBWPULOCK:** Upper Boot Alias Write-protect Unlock bit

1 = UBWPx bits are not locked and can be modified

0 = UBWPx bits are locked and cannot be modified

This bit is only user-clearable and cannot be set except by any reset.

bit 6 Reserved: This bit is reserved for use by development tools

bit 5 **Unimplemented:** Read as '0'

bit 4 UBWP4: Upper Boot Alias Page 4 Write-protect bit<sup>(2)</sup>

1 = Write protection enabled

0 = Write protection disabled

Note 1: These bits are only writable when the NVMKEY unlock sequence has been followed and the LBWPULOCK bit is set.

These bits are only writable when the NVMKEY unlock sequence has been followed and the UBWPULOCK bit is set.

#### Register 52-7: NVMBWP: Flash Boot (Page) Write-Protect Register (Continued)

- bit 3 **UBWP3:** Upper Boot Alias Page 3 Write-protect bit<sup>(2)</sup>
  - 1 = Write protection enabled0 = Write protection disabled
  - **UBWP2:** Upper Boot Alias Page 2 Write-protect bit<sup>(2)</sup>
    - 1 = Write protection enabled0 = Write protection disabled

bit 2

- bit 1 **UBWP1:** Upper Boot Alias Page 1 Write-protect bit<sup>(2)</sup>
  - 1 = Write protection enabled0 = Write protection disabled
- bit 0 **UBWP0:** Upper Boot Alias Page 0 Write-protect bit<sup>(2)</sup>
  - 1 = Write protection enabled0 = Write protection disabled
- Note 1: These bits are only writable when the NVMKEY unlock sequence has been followed and the LBWPULOCK bit is set.
  - 2: These bits are only writable when the NVMKEY unlock sequence has been followed and the UBWPULOCK bit is set.


#### 52.3 MEMORY CONFIGURATION

#### 52.3.1 Flash Bank Construction

Each bank of Flash memory is divided into pages. A page is the smallest unit of memory that can be erased at one time. Each page of memory is segmented into eight rows. A row is the largest unit of memory that can be programmed at one time. A row consists of 128 Quad (128-bit) words. Each Quad word consists of four instruction (32-bit) words. Flash memory can be programmed in rows, Quad word (128-bit) or Word (32-bit) units.

**Note:** Page size varies by device. Please refer to the "Flash Program Memory" chapter in the specific device data sheet to determine the Flash page size for your device.

Figure 52-1: Flash Construction



#### 52.3.2 Dual Flash Banks

Flash memory is divided into two equal banks, each with a BFM partition and a PFM partition. Both the BFM and PFM partitions can be erased in page increments. The PFM partitions can be erased in their entirety with a single command.

# 52.3.3 Programming or Erasing Flash in the Same Bank Where Code is Executing

Code cannot be fetched by the CPU from the same Flash bank that is the target of the programming operation, which is either BFM or PFM. When this operation is attempted, the CPU will cease to execute code (stall) while the programming operation is in progress. This includes Interrupt Service Routines (and their vectors) when they are located in the same bank as the target Flash operation. If the system software requires execution of code during Flash operations, the code must reside in system RAM or the Flash bank that is not the target of the programming operation.

**Note:** Instruction code that is already stored in the cache when the programming operation is initiated will continue to execute.

# 52.3.4 Programming or Erasing Flash in the Opposite Bank Where Code is Executing

To avoid CPU stalling during programming operations, insure that all target addresses for programming operations are location in a Flash bank where no executable code is being fetched. When this requirement is met, the CPU can fetch and execute code during any of the programming operations without stalling, including Interrupt Service Routines. To accomplish this, the application must place all executable code in the BFM and PFM partitions of one bank and execute programming operations on the BFM or PFM partitions of the other bank.

© 2013 Microchip Technology Inc. Preliminary DS61193A-page 52-15

#### 52.4 BOOT FLASH MEMORY (BFM) PARTITIONS

#### 52.4.1 BFM Bank Aliasing – Selecting the Start-up Bank

The BFM partitions of each Flash bank are mapped into fixed and aliased regions. The order of mapping to the aliased regions is determined by the device Configuration memory words BFxSEQ0 (BFxSEQ1-BFxSEQ3 are not used). The mapping occurs at reset prior to execution of any instruction code. Whichever BFM has the larger value in the associated sequence word register, that bank will be mapped into the lower aliased region. If the values are equal, Bank 1 is mapped into the lower aliased region, Bank 2 and the other BFM is mapped into the upper aliased region.

When programming the BFxSEQ0 value, the sequence number value is stored in the lower 16 bits and the compliment of this value is stored in the upper 16 bits. As an example, using a sequence number of three, the BFxSEQ0 value would be 0xFFFC0003.

Figure 52-2 illustrates the effect of the BFxSEQ0 comparison. In either case, Bank 1 and Bank 2 BFM are mapped identically in the fixed regions, with Bank 1 in the lower fixed region, and Bank 2 in the upper fixed region. The mapping to the aliased regions changes based on the BFxSEQ0 values. This example shows a device with 80 KB BFM banks. Refer to the "Memory Organization" chapter of the specific device data sheet to determine the size and address mapping for the BFM banks of your particular device.




Figure 52-2: Example of Aliased and Fixed BFM Regions Based on BFxSEQ0 Values

#### 52.4.2 BFM Write Protection

Pages in the upper and lower aliased regions can be protected individually using bits in the NVMBWP register. Since these bits correspond to pages referenced in the aliased region, they are affected by the mapping of the aliasing at start-up. At reset, all pages are in a write-protected state and must be disabled prior to performing any programming operations on the BFM regions. There are also Upper Region and Lower Region unlock bits, UBWPULOCK (NVMBWP<7>) and LBWPULOCK (NVMBWP<15>), which are set at reset and can be cleared by user software. When cleared, changes to write protection for that region can no longer be made. Once cleared, the UBWPULOCK and LBWPULOCK bits can only be set by a reset.


The NVMBWP write-protect register can only be changed when the unlock sequence is followed. See **52.9** "NVMKEY Register Unlocking Sequence" for more information.

#### 52.5 PROGRAM FLASH MEMORY (PFM) PARTITIONS

#### 52.5.1 PFM Mapping to Address Space

Each Flash bank has an equally sized PFM region. The mapping of the banks of PFM into address space is determined by the state of the SWAP control bit (NVMCON<7>), as shown in Figure 52-3. It is recommended that this bit is only changed by the code executing from the BFM region.





The SWAP bit setting can only be changed when the unlock sequence is first completed. See **52.9 "NVMKEY Register Unlocking Sequence"** for more information.

#### 52.5.2 PFM Write Protection

Write protection for the PFM region is implemented by pages using a watermark address, defined by the NVMPWP<23:0> bits (NVMPWP<23:0>). Write protection is always implemented on page boundaries; therefore, for a device with a 0x4000 (16 KB) page size, address bits 0 through 13 are ignored and will always read '0'. When the NVMPWP is equal to '0', no PFM pages are write-protected. When not equal to '0', the NVMPWP bit will always point to the first address of the last page that is write-protected. All pages with lesser addresses will be write-protected. At reset no PFM memory is write-protected.

There is also an unlock bit, PFMULOCK (NVMPWP<31>), which is set at reset and can be cleared by user software. When cleared, changes to write protection of the PFM can no longer be made, including the PFMULOCK bit. The NVMPWP write-protect register can only be changed when the unlock sequence is followed. See 52.9 "NVMKEY Register Unlocking Sequence" for more information.

© 2013 Microchip Technology Inc. Preliminary DS61193A-page 52-17

#### 52.6 ERROR CORRECTING CODE (ECC) AND FLASH PROGRAMMING

Some PIC32 devices incorporate Error Correcting Code (ECC) features, which detect and correct errors resulting in extended Flash memory life. This feature is explained in detail in Section 41. "Prefetch Module for Devices with L1 CPU Cache".

ECC is implemented in 128-bit wide Flash words or four 32-bit instruction word groups. As a result, when programming Flash memory on a device where ECC is employed, the programming operation must be at minimum four instructions words or in groups of four instruction words. This is the reason that the Quad Word programming command exists and why row programming always programs multiples of four words.

For a given software application, ECC can be enabled at all times, disabled at all times, or dynamically enabled using the FECCCON Configuration bits. When ECC is enabled at all times, the Single Word NVMOP programming command does not function, and the quad word is the smallest unit of memory that can be programmed. When ECC is disabled or enabled dynamically, both the Word and Quad word programming NVMOP commands are functional and the programming method used determines how ECC is handled.

In the case of dynamic ECC, if the memory was programmed with the Word command, ECC is turned off for that word, and when it is read, no error correction is performed. If the memory was programmed with the Quad Word or Row Programming commands, ECC data is written and tested for errors (and corrected if needed) when read. Table 52-2 describes the different ECC scenarios.

Table 52-2: ECC Programming Summary

FECCCON		Data Read			
Setting	Word Write	Quad Word Write	Row Write	Data Neau	
Disabled	Allowed	Allowed	Allowed	ECC is never applied on a Flash read	
Enabled	Not allowed	Allowed	Allowed	ECC is applied on every Flash word read.	
Dynamic	Allowed, but when used, the programmed word is flagged to NOT USE ECC	Writes ECC data and flags programmed words to USE ECC	Writes ECC data and flags programmed words to USE ECC	ECC is only applied on words that are flagged to USE ECC	

**Note:** When using dynamic ECC, all non-ECC locations must be programmed with the 32-bit Word programming command, while all ECC enabled locations must be programmed with a 128-bit Quad Word or Row programming command. Divisions between ECC and non-ECC memory must be on even quad word boundaries (address bits 0 through 3 are equal to '0').

#### 52.7 INTERRUPTS

An interrupt is generated when the WR bit is cleared by the Flash Controller upon completion of a Flash program or erase operation. The interrupt event will cause a CPU interrupt if it has been configured and enabled in the Interrupt Controller. The interrupt occurs regardless of the outcome of the program or erase operation; successful or unsuccessful. The only exception is the No Operation (NOP) programming operation (NVMOP = 0), which is used to manually clear the error flags and does not create an interrupt event on completion, but does clear the WR bit.

Flash Controller interrupts are not persistent, and therefore, no additional steps are required to clear the cause or source of the interrupt. It is only necessary to clear the appropriate IFSx bit prior to exiting the interrupt service routine.

Once the Interrupt Controller is configured, the Flash event will cause the CPU to jump to the vector assigned to the Flash event. The CPU will then begin executing code at the vector address. The user software at this vector address should perform the required operations, and then exit. For more information on interrupts, how to configure them, and the vector address table details, refer to the **Section 8. "Interrupts"** (DS61108) in the "PIC32 Family Reference Manual" and the "Interrupt Controller" chapter in the specific device data sheet.

#### 52.7.1 Interrupts and CPU Stalling

Code cannot be fetched by the CPU from the same Flash bank, either BFM or PFM, which is the target of the programming operation. When this operation is attempted, the CPU will cease to execute code (stall) while the programming operation is in progress. CPU code execution does not resume until the programming operation is complete, and when this occurs, any pending interrupts, including those from the Flash Controller, will be processed in order of priority.

Note that code that is already loaded into the processor cache will continue to execute up to the point where an attempt is made to fetch code or data from the same Flash panel as the active programming operation. At this point the CPU will stall.

In situations where all executable code and data constants are located in the bank opposite of the target of all programming operations, the Flash event interrupt allows the system to initiate a Flash operation, and then commence code execution and use the interrupt service routine to flag the completion of the programming operation. Using this technique, it is possible to design a system with background Flash programming functionality for live updates of Flash memory.

Stalling can also be avoided by placing any needed executable code in SRAM during Flash programming.

© 2013 Microchip Technology Inc. Preliminary DS61193A-page 52-19

#### 52.8 ERROR DETECTION

The NVMCON register includes two bits for detecting error conditions during a program or erase operation. They are Low-Voltage detect error, LVDERR (NVMCOM<12>) and Write Error, WRERR (NVMCON<13>).

The WRERR is set each time the WR bit (NVMCON<15>) is set, initiating a programming operation. WRERR is cleared on successful completion of the flash operation and at the same time that WR is cleared and as such should not be polled until the Flash Controller clears WR. When the WRERR is set, any attempt to initiate programming or erase operation is ignored. WRERR must be cleared before commencing flash program or erase operations.

LVDERR is set when a Brown out Reset (BOR) occurs during a programming operation. The only reset which clears LVDERR is a power on reset (POR). Other reset types do not affect LVDERR. When the LVDERR is set, any attempt to initiate programming or erase operation is ignored. LVDERR must be cleared before commencing flash program or erase operations.

Both the WRERR and LVDERR can be cleared manually in software by initiating a flash operation (setting WR) with NVMOP set to NOP (0x00). Note that executing the NVMOP NOP command clears WRERR, LVDERR and WR but does not generate an interrupt event on completion.

Table 52-3: Programming Error Cause and Effects

Cause of Error	Effect on Programming Erase Operation	Indication
A low-voltage event occurred during a programming sequence.	The last programming or erase operation may not have completed.	LVDERR = 1, WRERR = 1
A non-POR reset occurred during programming.	Programming or erase operation is aborted.	WRERR = 1
Attempt to program or erase a page out of the Flash memory range.	Erase or programming operation is not initiated.	WRERR = 1
Attempt to erase or program a write protected PFM page.	Erase or programming operation is not initiated.	WRERR = 1
Attempt to erase or program a write protected BFM page.	Operation occurs, but the page is not programmed or erased.	WRERR = 0
Bus master error or row programming data underrun error during programming.	Programming or erase operation is aborted.	WRERR = 1

#### 52.9 NVMKEY REGISTER UNLOCKING SEQUENCE

Important register settings that could compromise the Flash memory if inadvertently changed are protected by a register unlocking sequence. This feature is implemented using the NVMKEY register. NVMKEY is a write-only register that is used to implement an unlock sequence to help prevent accidental writes or erasures of Flash memory or accidental changes to the SWAP bit (NVMCON<7>) and write permission settings.

In some instances the operation is also dependent on the setting of the WREN bit (NVMCON<14>), as shown in Table 52-4.

Table 52-4: NVMKEY Register Unlocking and WREN

Operation	WREN Setting	Unlock Sequence Required
Changing value of SWAP (NVMCON<7>)	0	Yes
Changing value of NVMOP<3:0> (NVMCON<3:0>)	0	No
Setting WR (NVMCON<15>) to start a write or erase operation	1	Yes
Changing any fields in the NVMPWP register	Don't care	Yes
Changing any fields in the NVMBWP register	Don't care	Yes

The following steps must be followed in the exact order as shown to enable writes to registers that require this unlock sequence:

- Write 0x00000000 to NVMKEY.
- 2. Write 0xAA996655 to NVMKEY.
- 3. Write 0x556699AA to NVMKEY.
- 4. Write the value to the register requiring the unlock sequence.

To ensure a successful write to the register as shown in Step 4, Steps 2 through 4 must be executed without any other activity on the peripheral bus that is in use by the Flash Controller. Interrupts and DMA transfers that access the same peripheral bus as the Flash Controller must be disabled. Refer to the specific device data sheet to determine which peripherals share the same peripheral bus as the Flash Controller. In addition, the operation in Step 4 must be atomic. The Set, Clear, and Invert registers may be used, where applicable, for the target register in Step 4.

Example 52-1 shows code written in the C language to initiate a NVM Operation (NVMOP) command. In this particular example, the WR bit is being set in the NVMCON register, and therefore, must include the unlock sequence. Note the use of the NVMCONSET register, which sets the WR bit in a single instruction without changing other bits in the register. Using NVMCONbits.WR = 1 will fail, as this line of code compiles to a read-modify-write sequence.

#### Example 52-1: Initiate NVM Operation (Unlock Sequence Example)

```
void NVMInitiateOperation(void)
           int_status;
                          // storage for current Interrupt Enable state
    int
          dma_susp;
                          // storage for current DMA state
    // Disable Interrupts
   asm volatile("di %0" : "=r"(int_status));
    // Disable DMA
   if(!(dma_susp=DMACONbits.SUSPEND))
       DMACONSET=_DMACON_SUSPEND_MASK;
                                            // suspend
        while((DMACONbits.DMABUSY));
                                           // wait to be actually suspended
   NVMKEY = 0x0;
   NVMKEY = 0xAA996655;
   NVMKEY = 0x556699AA;
   NVMCONSET = NVMCON_WR;
                                            // must be an atomic instruction
   // Restore DMA
   if(!dma_susp)
        DMACONCLR=_DMACON_SUSPEND_MASK;
                                        // resume DMA activity
    // Restore Interrupts
   if(int_status & 0x00000001)
       asm volatile("ei");
   }
```

**Note:** Once the unlock codes have been written to the NVMKEY register, the next activity on the same peripheral bus as the Flash Controller will reset the lock. As a result, only atomic operations can be used. Setting register fields using structures compile into a read-modify-write operation, and will fail.

#### 52.10 WORD PROGRAMMING

The smallest block of data that can be programmed in a single operation is one 32-bit word. The data to be programmed must be written to the NVMDATA0 register, and the address of the word must be loaded into the NVMADDR register before the programming sequence is initiated. The instruction word at the physical location pointed to by the NVMADDR register is then programmed. Programming occurs on 32-bit word boundaries; therefore, bits 0 and 1 of the NVMADDR register are ignored.

Once a word is programmed, it must be erased before it can be programmed again, even if changing a bit from an erased '1' state to a '0' state.

Word programming will only succeed if the target address is in a page that is not write-protected. Programming to a write-protected PFM page will fail and result in the WRERR bit being set in the NVMCON register. Programming a write-protected BFM page will fail, but does not set the WRERR bit.

A programming sequence consists of the following steps:

- Write 32-bit data to be programmed to the NVMDATA0 register.
- 2. Load the NVMADDR register with the address to be programmed.
- 3. Set the WREN bit = 1 and NVMOP bits = 1 in the NVMCON register. This defines and enables the programming operation.
- Initiation of the programming operation (see 52.9 "NVMKEY Register Unlocking Sequence").
- 5. Monitor the WR bit of the NVMCON register to flag completion of the operation.
- 6. Clear the WREN bit in the NVMCON register.
- 7. Check for errors and process accordingly.

Example 52-2 shows code for Word programming, where a value of 0x12345678 is programmed into location 0x1D008000.

#### Example 52-2: Word Programming

```
// Set up Address and Data Registers
   NVMADDR = 0x1D008000;  // physical address
   NVMDATA0 = 0x12345678;
                              // value
// set the operation, assumes WREN = 0
   NVMCONbits.NVMOP = 0x1; // NVMOP for Word programming
// Enable Flash for write operation and set the NVMOP
   NVMCONSET = NVMCON_WREN;
// Start programming
   NVMInitiateOperation();  // see Example 52-1
// Wait for WR bit to clear
   while(NVMCON & NVMCON_WR);
// Disable future Flash Write/Erase operations
   NVMCONCLR = NVMCON_WREN;
// Check Error Status
   if(NVMCON & 0x3000)
                             // mask for WRERR and LVDERR
       // process errors
   }
```

#### 52.11 QUAD WORD PROGRAMMING

The process for Quad Word programming is identical to Word programming except that all four of the NVMDATAx registers are used. The value of NVMDATA0 is programmed at address NVMADDR, NVMDATA1 at NVMADDR + 0x4, NVMDATA2 at NVMADDR + 0x8, and NVMDATA3 at address NVMDATA + 0xC.

Quad Word programming is always performed on a quad word boundary; therefore, bits 3 through 0 are ignored.

Quad Word programming will only succeed if the target address is in a page that is not write-protected. Once a Quad Word is programmed, it must be erased before any word in it can be programmed again, even if changing a bit from an erased '1' state to a '0' state.

Example 52-3 shows code for Quad Word Programming where a value of 0x11111111 is programmed into location 0x1D008000, 0x222222222 into 0x1D008004, 0x33333333 into 0x1D008008, and 0x444444444 into location 0x1D00800C.

#### **Example 52-3: Quad Word Programming**

```
// Set up Address and Data Registers
   NVMADDR = 0x1D008000;  // physical address
                             // value written to 0x1D008000
   NVMDATA0 = 0x11111111;
   NVMDATA1 = 0x22222222;
                             // value written to 0x1D008004
   NVMDATA2 = 0x333333333;
                             // value written to 0x1D008008
   NVMDATA3 = 0x44444444;
                             // value written to 0x1D00800C
// set the operation, assumes WREN = 0
   NVMCONbits.NVMOP = 0x2; // NVMOP for Quad Word programming
// Enable Flash for write operation and set the NVMOP
   NVMCONSET = NVMCON_WREN;
// Start programming
   NVMInitiateOperation();  // see Example 52-1
// Wait for WR bit to clear
   while(NVMCON & NVMCON_WR);
// Disable future Flash Write/Erase operations
   NVMCONCLR = NVMCON_WREN;
// Check Error Status
   if(NVMCON & 0x3000)
                            // mask for WRERR and LVDERR bits
       // process errors
```

#### 52.12 ROW PROGRAMMING

The largest block of data that can be programmed is a row, which varies by device. Refer to the "Flash Program Memory" chapter in the specific device data sheet to determine the row size.

Unlike Word and Quad Word Programming, where the data source is stored in SFR memory, Row programming source data is stored in SRAM. The NVMSRCADDR register is a pointer to the physical location of the source data for Row programming.

Like other Non-volatile Memory (NVM) programming commands, the NVMADDR register points to the target address of the operation. Row programming always occurs on row boundaries; therefore, for a device with an instruction word row size of 512, bits 0 through 9 of the NVMADDR register are ignored.

Row Word programming will only succeed if the target address is in a page that is not write-protected. Once a row is programmed, it must be erased before any word in it can be programmed again, even if changing a bit from an erased '1' state to a '0' state.

Example 52-4 shows code for Row programming. Array rowbuff is populated with data and programmed into a row located at physical address 0x1D008000.

**Note:** When assigning the value to the NVMSRCADDR register, it must be converted to a physical address.

#### Example 52-4: Row Programming

```
unsigned int rowbuff[512]; // example is for a 512 word row size.
int x;
                           // loop counter
// put some data in the source buffer
   for (x = 0; x < (sizeof(rowbuff) * sizeof(int)); x++)
       ((char *)rowbuff)[x] = x;
// set destination row address
   NVMADDR = 0x1D008000;
                             // row physical address
// set source address. Must be converted to a physical address.
   NVMSRCADDR = (unsigned int)((int)rowbuff & 0x1FFFFFFF);
// define flash operation
   NVMCONbits.NVMOP = 0x3; // NVMOP for Row programming
// Enable Flash Write
   NVMCONSET = NVMCON_WREN;
// commence programming
   NVMInitiateOperation();  // see Example 52-1
// Wait for WR bit to clear
   while(NVMCON & NVMCON_WR);
// Disable future Flash Write/Erase operations
   NVMCONCLR = NVMCON_WREN;
// Check Error Status
   if(NVMCON & 0x3000)
                              // mask for WRERR and LVDERR bits
       // process errors
```

#### 52.13 PAGE ERASE

A page erase performs an erase of a single page of either PFM or BFM. Refer to the **"Flash Program Memory"** chapter in the specific device data sheet for the page size for your device.

The page to be erased is selected using the NVMADDR register. Pages are always erased on page boundaries; therefore, for a device with an instruction word page size of 4096, bits 0 through 11 of the NVMADDR register are ignored.

A page erase will only succeed if the target address is a page that is not write-protected. Erasing a write-protected page will fail and result in the WRERR bit being set in the NVMCON register.

Example 52-5 shows code for a single page erase operation at address 0x1D008000.

#### Example 52-5: Page Erase

```
// set destination page address
   NVMADDR = 0x1D008000; // page physical address
// define flash operation
   NVMCONbits.NVMOP = 0x4; // NVMOP for Page Erase
// Enable Flash Write
   NVMCONSET = NVMCON_WREN;
// commence programming
   NVMInitiateOperation();  // see Example 52-1
// Wait for WR bit to clear
   while(NVMCON & NVMCON_WR);
// Disable future Flash Write/Erase operations
   NVMCONCLR = NVMCON_WREN;
// Check Error Status
   if(NVMCON & 0x3000)
                           // mask for WRERR and LVDERR bits
       // process errors
```

#### 52.14 PROGRAM FLASH MEMORY ERASE

Program Flash memory can be erased in its entirety or by bank. Three discreet NVMOP commands are implemented to accomplish this:

- Erase the entire PFM area (both PFM banks)
- · Erase the upper PFM bank
- · Erase the lower PFM bank

When erasing the entire PFM area, code must be executing from BFM. When erasing a single upper or lower PFM bank, code must either be executing from BFM or from the PFM bank that is not being erased.

Program Flash memory erase operations will only succeed if no pages are write-protected in the bank being erased. When erasing the entire PFM area, PFM write protection must be completely disabled.

Example 52-6 shows code for erasing the upper program Flash bank.

#### Example 52-6: Program Flash Erase

```
// define flash operation
   NVMCONbits.NVMOP = 0x6;
                                 // NVMOP for upper bank PFM erase
// Enable Flash Write
   NVMCONSET = NVMCON_WREN;
// commence programming
   NVMInitiateOperation();
                                // see Example 52-1
// Wait for WR bit to clear
   while(NVMCON & NVMCON_WR);
// Disable future Flash Write/Erase operations
   NVMCONCLR = NVMCON_WREN;
// Check Error Status
   if(NVMCON & 0x3000)
                             // mask for WRERR and LVDERR bits
       // process errors
```

© 2013 Microchip Technology Inc. Preliminary DS61193A-page 52-27

## **PIC32 Family Reference Manual**

#### 52.15 OPERATION IN POWER-SAVING MODES

The Flash Controller does not operate in power-saving modes. If a WAIT instruction is encountered when programming, the CPU will stop execution (stall), wait for the programming operation to complete, and then enter the power-saving mode.

#### 52.16 OPERATION IN DEBUG MODE

Programming operations will continue to completion if processor execution is halted in Debug mode.

#### 52.17 EFFECTS OF VARIOUS RESETS

Devices Resets other than a Power-on Reset (POR), reset the SWAP bit in the NVMCON register and the entire contents of the NVMPWP and NVMBWP registers. All other register content persists through a non-POR reset.

All Flash Controller registers are forced to their reset states upon a POR.

## 52

# Flash Memory with Support for Live Update

#### 52.18 RELATED APPLICATION NOTES

This section lists application notes that are related to this section of the manual. These application notes may not be written specifically for the PIC32 device family, but the concepts are pertinent and could be used with modification and possible limitations. The current application notes related to Flash Memory with Support for Live Update include the following:

Title Application Note #

No related application notes at this time.

N/A

**Note:** Please visit the Microchip Web site (www.microchip.com) for additional application notes and code examples for the PIC32 family of devices.

# **PIC32 Family Reference Manual**

#### **52.19 REVISION HISTORY**

Revision A (May 2013)

This is the initial released version of the document.

#### Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not
  mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

# QUALITY MANAGEMENT SYSTEM CERTIFIED BY DNV ISO/TS 16949

#### **Trademarks**

The Microchip name and logo, the Microchip logo, dsPIC, FlashFlex, KEELOQ, KEELOQ logo, MPLAB, PIC, PICmicro, PICSTART, PIC<sup>32</sup> logo, rfPIC, SST, SST Logo, SuperFlash and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, HI-TECH C, Linear Active Thermistor, MTP, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Silicon Storage Technology is a registered trademark of Microchip Technology Inc. in other countries.

Analog-for-the-Digital Age, Application Maestro, BodyCom, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, HI-TIDE, In-Circuit Serial Programming, ICSP, Mindi, MiWi, MPASM, MPF, MPLAB Certified logo, MPLIB, MPLINK, mTouch, Omniscient Code Generation, PICC, PICC-18, PICDEM, PICDEM.net, PICkit, PICtail, REAL ICE, rfLAB, Select Mode, SQI, Serial Quad I/O, Total Endurance, TSHARC, UniWinDriver, WiperLock, ZENA and Z-Scale are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

 $\ensuremath{\mathsf{SQTP}}$  is a service mark of Microchip Technology Incorporated in the U.S.A.

GestIC and ULPP are registered trademarks of Microchip Technology Germany II GmbH & Co. & KG, a subsidiary of Microchip Technology Inc., in other countries.

All other trademarks mentioned herein are property of their respective companies.

© 2013, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

Printed on recycled paper.

ISBN: 978-1-62077-183-9

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.



## **Worldwide Sales and Service**

#### **AMERICAS**

Corporate Office

2355 West Chandler Blvd. Chandler, AZ 85224-6199

Tel: 480-792-7200 Fax: 480-792-7277 Technical Support:

http://www.microchip.com/

support

Web Address: www.microchip.com

Atlanta

Duluth, GA Tel: 678-957-9614 Fax: 678-957-1455

**Boston** 

Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago

Itasca, IL Tel: 630-285-0071 Fax: 630-285-0075

Cleveland

Independence, OH Tel: 216-447-0464 Fax: 216-447-0643

**Dallas** 

Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

Detroit

Farmington Hills, MI Tel: 248-538-2250 Fax: 248-538-2260

Indianapolis

Noblesville, IN Tel: 317-773-8323 Fax: 317-773-5453

Los Angeles

Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608

Santa Clara

Santa Clara, CA Tel: 408-961-6444 Fax: 408-961-6445

Toronto

Mississauga, Ontario,

Canada

Tel: 905-673-0699 Fax: 905-673-6509

#### ASIA/PACIFIC

**Asia Pacific Office** 

Suites 3707-14, 37th Floor Tower 6, The Gateway Harbour City, Kowloon Hong Kong

Tel: 852-2401-1200 Fax: 852-2401-3431

Australia - Sydney

Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

China - Beijing

Tel: 86-10-8569-7000 Fax: 86-10-8528-2104

China - Chengdu

Tel: 86-28-8665-5511 Fax: 86-28-8665-7889

China - Chongqing

Tel: 86-23-8980-9588 Fax: 86-23-8980-9500

China - Hangzhou

Tel: 86-571-2819-3187 Fax: 86-571-2819-3189

China - Hong Kong SAR Tel: 852-2943-5100

Fax: 852-2401-3431

China - Nanjing

Tel: 86-25-8473-2460 Fax: 86-25-8473-2470

China - Qingdao

Tel: 86-532-8502-7355 Fax: 86-532-8502-7205

China - Shanghai

Tel: 86-21-5407-5533 Fax: 86-21-5407-5066

China - Shenyang

Tel: 86-24-2334-2829 Fax: 86-24-2334-2393

China - Shenzhen

Tel: 86-755-8864-2200 Fax: 86-755-8203-1760

China - Wuhan

Tel: 86-27-5980-5300 Fax: 86-27-5980-5118

China - Xian

Tel: 86-29-8833-7252 Fax: 86-29-8833-7256

China - Xiamen

Tel: 86-592-2388138 Fax: 86-592-2388130

China - Zhuhai

Tel: 86-756-3210040 Fax: 86-756-3210049

#### ASIA/PACIFIC

India - Bangalore

Tel: 91-80-3090-4444 Fax: 91-80-3090-4123

India - New Delhi

Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune

Tel: 91-20-2566-1512 Fax: 91-20-2566-1513

Japan - Osaka

Tel: 81-6-6152-7160 Fax: 81-6-6152-9310

Japan - Tokyo

Tel: 81-3-6880- 3770 Fax: 81-3-6880-3771

Korea - Daegu

Tel: 82-53-744-4301 Fax: 82-53-744-4302

Korea - Seoul

Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Kuala Lumpur

Tel: 60-3-6201-9857 Fax: 60-3-6201-9859

Malaysia - Penang

Tel: 60-4-227-8870 Fax: 60-4-227-4068

Philippines - Manila Tel: 63-2-634-9065

Fax: 63-2-634-9069

Singapore

Tel: 65-6334-8870 Fax: 65-6334-8850

Taiwan - Hsin Chu

Tel: 886-3-5778-366 Fax: 886-3-5770-955

Taiwan - Kaohsiung

Tel: 886-7-213-7828 Fax: 886-7-330-9305

Taiwan - Taipei

Tel: 886-2-2508-8600 Fax: 886-2-2508-0102

Thailand - Bangkok

Tel: 66-2-694-1351 Fax: 66-2-694-1350

#### **EUROPE**

Austria - Wels

Tel: 43-7242-2244-39 Fax: 43-7242-2244-393

Denmark - Copenhagen

Tel: 45-4450-2828 Fax: 45-4485-2829

France - Paris

Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

**Germany - Munich** 

Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

Italy - Milan

Tel: 39-0331-742611 Fax: 39-0331-466781

Netherlands - Drunen

Tel: 31-416-690399 Fax: 31-416-690340

Spain - Madrid

Tel: 34-91-708-08-90 Fax: 34-91-708-08-91

**UK - Wokingham** Tel: 44-118-921-5869 Fax: 44-118-921-5820

11/29/12