## XSCOPE DISPLAY ON XCORE 200 EXPLORER KIT

- 1. Create a new project in xTIMEcomposer studio.
- 2. Copy the source file in the **src** folder.
- 3. Expand the project folder in the **Project Explorer** pane.
- 4. Right click on the **Makefile** and select **Open with --> Text Editor.**
- 5. Add the following line in the **Makefile**

```
XCC FLAGS = -Wall -02 -report -fxscope -g
```

6. In the **Project Explorer** right click on **config.xscope** --> **Open With--> Text Editor.** 

```
7. Add the following line in the file:
```

```
<xSCOPEconfig ioMode="basic" enabled="true">
```

```
<Probe name="x" type="CONTINUOUS" datatype="UINT" units="Value" enabled="true"/>
<Probe name="y" type="CONTINUOUS" datatype="UINT" units="Value" enabled="true"/>
<Probe name="r" type="CONTINUOUS" datatype="UINT" units="Value" enabled="true"/>
<Probe name="g" type="CONTINUOUS" datatype="UINT" units="Value" enabled="true"/>
<Probe name="b" type="CONTINUOUS" datatype="UINT" units="Value" enabled="true"/>
</xSCOPEconfig>
```

- 8. On the project, Rigth click, selct **Run as --> Run Configurations.**
- 9. Under **Device Options** select **hardware**, Under **Target IO Options** select **xSCOPE(viaxCONNECT/UART)**
- 10. Scroll down Under **Additional xrun command options** enter **--xscope-port localhost:10234** 11. Click **Apply** and click **Run.**

