Line Balancing & Efficiency Guide

Department: Production & Industrial Engineering

Key Concepts:

- Cycle Time: Time taken by one operator to complete one operation.
- Bottleneck: The slowest operation in the line.
- Efficiency Formula: (Standard Minute Value (SMV) x Units Produced) / (Total Minutes Worked) x 100.

Line Balancing Steps:

1. Calculate total SMV for the style.
2. Identify bottleneck operations.
3. Redistribute work elements to balance the line.
4. Monitor hourly production and adjust.

Target Efficiency: 65-75% for woven tops, 55-65% for knit tops.