


earstudio ES100

QUICK START GUIDE

POWER

ON Press & hold Play/Pause Button for more than 2 seconds

OFF Press & hold Play/Pause Button for more than 4 seconds



PLAY(AUDIO)

PLAY Press Play/Pause Button once

PAUSE Press Play/Pause Button once

HANDS-FREE CALLING

RECEIVE CALL Press Play/Pause Button once

REJECT CALL Press & hold Play/Pause Button for more than 2 seconds

END CALL Press Play/Pause Button once



R-CMI-Ad2-ES100
KC Battery Certificate ID:
YU10664-17008



FCC ID: 2A0JCES100



022-100059

For more information, please visit www.ear-studio.com


earstudio ES100

クイックスタートガイド

電源 ON/OFFの方法

電源 ON: PLAY/PAUSEボタンを、正面に青のLED表示が1度点灯するまで、2秒以上押し続ける。

電源 OFF: PLAY/PAUSEボタンを、正面に赤のLED表示が1度点灯するまで、4秒以上押し続ける。



音楽再生の方法

再生: PLAY/PAUSEボタンを1度押すと、再生が始まる。

一旦停止: 再生中に、PLAY/PAUSEボタンを1度押すと、一旦停止状態になる。

再生中の電話の着信について

受信: 再生中に電話がかかってきた場合は、そのままの状態でもPLAY/PAUSEボタンを1度押すと、受信できる。

着信拒否: 呼び出し中に、PLAY/PAUSEボタンを2秒以上押し続けると、拒否される。

受信終了: 通話が終了した場合は、PLAY/PAUSEボタンをもう1度押すと、終了され、再生中ならば音楽再生が始まる。



R-CMI-Ad2-ES100

KC Battery Certificate ID:
YU10664-17008



FCC ID: 2A0JCES100



022-100059

For more information, please visit www.ear-studio.com