12 LS 430 (RHD) (Cont. next page) SRS Power Source P21 PRETENSIONER REAR RH P18 PRETENSIONER FRONT LH PRETENSIONER IGNITION SW A26 A, A27 B, A28 C AIRBAG SENSOR ASSEMBLY 1 IC1 2 IC1 BATTERY A29 AIRBAG SQUIB(Front Passenger Airbag Assembly) A11 AIRBAG SENSOR FRONT RH A30 AIRBAG SQUIB A10 AIRBAG SENSOR FRONT LH S43 SIDE AIRBAG SQUIB RH P19 PRETENSIONER FRONT RH Right side of instrument panel

12 LS 430 (RHD) (Cont' d)

