INSTALLATION

BR0C9-05

 $Installation \cite[sto]{\tt be[done]} n \cite[the[reverse]{\tt order[of[removal](See[page[BR-18])]} \\ HINT:$

- Before installation, adjust the ength of the brake booster push od See page BR-27).
- After[installation,[fill[the[brake[jeservoir[with[brake[fluid,[bleed[the[brake[system[]See[page[BR-4),[and check for leaks.]
- •□ Check@and@adjust@he@brake@pedal@See@bage@BR-6).