INSTALLATION SAIB-02

1. INSTALL FRONT HEIGHT CONTROL SENSOR AND ACCELERATION SENSOR

- (a) Align the matchmarks on the height control sensor link and bracket.
- (b) Install the nut and connect the sensor link.

Torque: 5.4 N·m (55 kgf·cm, 48 in.·lbf)

(c) Install the front height control sensor and acceleration sensor with the 2 bolts.

Torque: 7.8 N·m (80 kgf·cm, 69 in.·lbf)

- 2. CONNECT CONNECTOR
- 3. INSTALL FRONT LEFT FENDER LINER
- 4. INSTALL FRONT WHEEL

Torque: 103 N·m (1,050 kgf·cm, 76 ft·lbf)

5. CHECK[VEHICLE[HEIGHT](See[page[\$A-5])