
05I1R-01

CHECK MODE PROCEDURE



1. CHECK MODE (SIGNAL CHECK)

- (a) Connect the hand-held tester to the DLC3.
- (b) Turn the ignition switch to the ON position.
- (c) Select the "SIGNAL CHECK", and proceed checking with the intelligent tester II.