① : Engine Room No.1 R/B

: Engine Room No.1 J/B

Engine Compartment Left (See Page 8)

* 1:H-LP R LWR * 2:H-LP L LWR

