


FI0Y2-01

INSPECTION







INSPECT FUEL TANK AND LINE

- Check the fuel lines for cracks or leakage, and all connections for deformation.
- (b) Check the fuel tank vapor vent system hoses and connections for looseness, sharp bends or damage.
- Check the fuel tank for deformation, cracks, fuel leakage (c) or tank band looseness.
- (d) Check the filler neck for damage or fuel leakage.
- Hose and pipe connections are as shown in the illustra-(e)

If a problem is found, repair or replace the parts as necessary.