FAIL-SAFE CHART

05HZY-01

If the television camera ECU detects a malfunction, the fail safe functions shown in the table below are activated.

Malfunction parts	Detecting condition	Function
Television camera assy	• Transmission of television camera malfunction signal	Stops signal reception and displays a dark screen
Television camera ECU	Malfunction of television camera ECU unit	Stops system operation