## **FLOOR SHIFT ASSY**


## **COMPONENTS**

N·m (kgf·cm, ft·lbf)


: Specified torque

Instrument Cluster Finish Panel Center Lower Instrument Panel Garnish Sub-assy LH Instrument Cluster Finish Panel End Instrument Panel Safety Pad Sub-assy No.1 Instrument Panel Finish Panel Glove Compartment Plate Choke Knob Hole Cover Coin Box Assy Instrument Cluster Finish Panel Instrument Panel Under Cover Sub-assy No.1 Instrument Panel Under Cover 8.3 (85, 74 in.·lbf) Sub-assy No.2 Instrument Cluster Finish Panel LWR Floor Shift Assy 8.3 (85, 74 in.·lbf) Instrument Panel w/ Smart key Finish Panel Lower Center 13 (130, 9) Instrument Panel Cup Holder Assy Console Box Duct No.1 Console Box Console Box Plate Rear Console Armrest Assy Cigar Lighter Hole Bezel

G28937



Floor Shift Gear Shifting Rod Sub-assy



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

G29897

