DTC	U0123	COMMUNICATION ERROR OF YAW RATE SENSOR	
-----	-------	--	--

## **CIRCUIT DESCRIPTION**

This circuit detects the yaw rate of the vehicle and transmits its signal to the skid control ECU and cruise control ECU (distance control ECU).

DTC No.	DTC Detection Condition	Trouble Area
U0123	While dynamic radar cruise control is either preparing for operation or operating, ECM continuously receives yaw rate sensor malfunction signal for certain amount of time	Communication circuit Yaw rate sensor (Deceleration sensor) Cruise control ECU (Distance control ECU) ECM

## **INSPECTION PROCEDURE**

## HINT:

This circuit uses CAN communication. Therefore, if there are any malfunctions in the communication circuit, one or more DTCs in the CAN communication system will be output.

Go to CAN COMMUNICATION SYSTEM (See Pub. No. RM1049E, page 05-3306)