05HZG–01

LOCATION

Rack & Pinion Power
Steering Gear Assy
• PPS Linear Solenoid Valve
  Assy

Combination Meter

Power Steering ECU Assy

Driver Side J/B
• ABS–IG Fuse

N

F46220