
Position of Parts in Instrument Panel

[LHD]



- A14 A/C Control Assembly
- A15 A/C Control Assembly
- A16 A/C Control Assembly
- A17 A/C Room Temp. Sensor
- A18 A/C Room Temp. SW (Driver's Side)
- A19 A/C Room Temp. SW (Front Passenger's Side)
- A20 A/T Shift Lever Illumination
- A21 Absorber Control SW
- A22 Accel Position Sensor
- A23 Air Suspension ECU
- A24 Air Suspension ECU
- A25 Air Suspension ECU
- A26 Airbag Sensor Assembly
- A27 Airbag Sensor Assembly
- A28 Airbag Sensor Assembly
- A29 Airbag Squib (Front Passenger Airbag Assembly)
- A30 Airbag Squib (Steering Wheel Pad)
- A31 Automatic Light Control Sensor and A/C Solar Sensor (Front)

- B 2 Blower Motor
- B 3 Brake Pedal Load Sensing SW
- C 5 Cellular Phone
- C 6 Center Cluster Integration Panel
- C 7 Cigarette Lighter (Front)
- C 8 Cigarette Lighter (Rear)
- C 9 Clearance Sonar Buzzer (Front)
- C10 Clock
- C11 Coin Box Illumination
- C12 Combination Meter
- C13 Combination SW
- C14 Combination SW
- C15 Console Box Illumination