ANTENNA CORD SUB-ASSY REPLACEMENT

27141 01

HINT:

- •□ LOCATION: SEE PAGE 67-2.
- Installation is in the reverse order of removal.
- 1. REMOVE[LUGGAGE[COMPARTMENT[FLOOR[MAT][SEE[PAGE]75-47]
- 2. REMOVE DECK TRIM SIDE BOARD RH (SEE PAGE 75-47)
- 3. REMOVE[REAR[FLOOR[FINISH[PLATE][SEE[PAGE]75-47]]
- 4. REMOVE[LUGGAGE[COMPARTMENT[TRIM[COVER[FRONT][SEE[PAGE[75-47]
- 5. REMOVE[LUGGAGE[COMPARTMENT[TRIM[COVER[ASSY[RH][SEE[PAGE[75-47]
- 6. REMOVE[ROOF[HEADLINING[ASSY[]SEE[PAGE[76-52]]
- 7. REMOVE ANTENNA CORD SUB-ASSY
- (a) Disconnect the connector.
- (b) Remove the bolt.
- (c) Disengage the 5 clips and remove the antenna cord sub-assy.

